



TROX TVE Control Units Owner's Manual

[Home](#) » [TROX](#) » TROX TVE Control Units Owner's Manual 

TROX TVE Control Units Owner's Manual




Contents

- [1 CAN A DAMPER BLADE PROVIDE MEASUREMENT AND REGULATE?](#)
- [2 TROX SERVICES](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)

CAN A DAMPER BLADE PROVIDE MEASUREMENT AND REGULATE?

YES! IT'S CALLED TVE.


With the new volume flow controller of Type TVE, upstream conditions, installation dependent on airflow direction and strictly limited volume flow rate control ranges are a thing of the past.



SIMPLE. PRECISE. EFFICIENT.

Three optimized TROX control units distinguish themselves by their outstanding quality, easy commissioning and precise function.

For more information just go to [Special Leaflet](#) or visit our product pages.



DESIGN MANUAL AIRFLOWCONTROL

Physical Principles, Standard Notes, system overviews, and more help you plan the right control engine





TROX SERVICES

PRODUCTSEARCH A-Z

Find out quickly and simply.



TROX EASY PRODUCT FINDER

Fast. Reliable. Innovative.



TOUR DE COMPETENCE

Competence exciting staged



TROX® TECHNIK

Documents / Resources

	TROX TVE Control Units [pdf] Owner's Manual TVE Control Units, TVE, Control Units, Units
---	---

References

- [X WELKOM - BIENVENUE | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X Tour de Competence | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X Min/Max actuators | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X Modulating actuators | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X Open/Close actuators | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X Retrofit kits | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X Variable Actuators | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X Adjustment devices | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X EN | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X EN-Ex | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X RN | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X RN-Ex | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X VFC | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X VFL | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X Contact | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X Compact, static | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X Easy | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X RC | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X RETROFIT | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X TROX UNIVERSAL | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X Universal, dynamic | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X Universal, static | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X Control unit TROX UNIVERSAL | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X Expansion module EM-AUTOZERO | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [X Expansion module EM-BAC-MOD | S.A. TROX Belgium/TROX Belgium N.V.](#)

- [!\[\]\(83eb2aa26b610eb6a9dca7cf4702d681_img.jpg\) Expansion module EM-IP | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [!\[\]\(94dfacbf937cdd7da4837a6fcd8fc785_img.jpg\) Expansion module EM-TRF | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [!\[\]\(dae8c3c5fa7c80febd6526a5e8a853bf_img.jpg\) Expansion module EM-TRF-USV | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [!\[\]\(8f38ab9775d1331a4e1fd6648d0a83f1_img.jpg\) VAV TERMINAL UNIT TYPE TVE | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [!\[\]\(5e48b3241d711ef916255d822ab3415f_img.jpg\) VFR | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [!\[\]\(c4c3604751fde0df44855086d7798e30_img.jpg\) GENERAL PURCHASING CONDITIONS | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [!\[\]\(a16ee0329f478adb49fd7876490e96fe_img.jpg\) EL | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [!\[\]\(a8a494e883c31c6f4a74584cc935a790_img.jpg\) WL | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [!\[\]\(8a50a875cd94cd57f6a7348a4d34b45f_img.jpg\) WT | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [!\[\]\(7ddc0498d10972f0f157498fccf65370_img.jpg\) Products | S.A. TROX Belgium/TROX Belgium N.V.](#)
- [User Manual](#)