

Trueque 2ACKH-213 Wireless Keyboard And Mouse



Trueque 2ACKH-213 Wireless Keyboard And Mouse User Manual

[Home](#) » [Trueque](#) » Trueque 2ACKH-213 Wireless Keyboard And Mouse User Manual 

Contents

- [1 Trueque 2ACKH-213 Wireless Keyboard And Mouse](#)
- [2 Product Specification](#)
- [3 You will receive](#)
- [4 How to set up](#)
- [5 Indicator Light](#)
- [6 Multimedia button description](#)
- [7 FAQ](#)
- [8 FCC](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)
- [10 Related Posts](#)



Trueque 2ACKH-213 Wireless Keyboard And Mouse



Product Specification

Keyboard parameters:


Product Size	430x216x36mm
Product Weight	688g±20g
Connectivity	2.4G Wireless Connection
Power	2 AAA battery
Operating Voltage	3V
Connection Distance	8-10M
Power Saving	Enter sleep mode after 10min without action
Work<ing Distance	Within 10 meters
Key Life	10 Million Strokes

Mouse parameters:

Mouse DPI	800-1200-1600
Power	1 AA battery
Connection Distance	8-10M
Power Saving	Enter sleep mode after 8min without action

Compatible Systems: Windows XP, Windows 7/8/10/11, Mac


You will receive




User Manual x1



USB Receiver x1




Mouse x1




Keyboard x1

How to set up

1. **Step 1:** Please put the USB receiver into your computer.




2. **Step 2:** Put batteries in the keyboard and mouse, then turn on the mouse.



3. **Step 3:** The keyboard and mouse will automatically connect to the computer, no driver is needed.

Indicator Light

LED Indicator of the Keyboard



1. Num Lock

- The Num Lock indicator will turn red when the Num Lock is activated.



















2. Caps Lock

- The Caps Lock indicator will turn red when Caps Lock is activated.

3. Low battery warning


- The indicator light will flash slowly when the battery is almost empty.

Multimedia button description

	Media		Mail
	Volume-		My Computer
	Volume+		Favorites
	Mute		Previous page of website
	Previous Track		Next page of website
	Next Track		Refresh
	Play/Pause		Search
	CD stop		Stop
	Homepage		Calculator

FAQ

1. The keyboard and mouse can not be connected.

- **A:** Please switch on the keyboard, and press  the LED indicator light will flash quickly.
- Plug the 2.4GHz USB receiver into the computer. Within 10 seconds, put the keyboard at 10 cm near the receiver for pairing.
- When the light turns off, the keyboard pairing is successful.

2. What should I do if the keyboard gets delayed or stuck?

- **A:** Please check there is no 2.4GHz device (e.g. router) nearby to interfere with the connection.
- Please check there is no full metal case that may block the signal.

3. Where is my USB receiver?

- **A:** The USB receiver is placed on top of the keyboard inside the package, please look for it carefully.
- Please contact us to get a free replacement if you have lost the USB receiver.

FCC

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference
2. This device must accept any interference received, including interference that may cause undesired operation.

Note


The multimedia keys are for Win 8 and Win 10, for other systems, there may be no function for some combined keys. This equipment has been tested and found to comply with the limits for a Class B digital device, under part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Email: truequeservice@outlook.com

Documents / Resources

	Trueque 2ACKH-213 Wireless Keyboard And Mouse [pdf] User Manual 2ACKH-213 Wireless Keyboard And Mouse, 2ACKH-213, Wireless Keyboard And Mouse, Keyboard And Mouse, Mouse, Keyboard
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.