



TRUPER TOL-3 Instant Folding Canopy Instruction Manual

[Home](#) » [TRUPER](#) » TRUPER TOL-3 Instant Folding Canopy Instruction Manual 



Code: 66075
Model: TOL-3

Contents

1 TOL-3 Instant Folding

Canopy

2 Parts list

3 Documents / Resources

3.1 References

TOL-3 Instant Folding Canopy

THIS RECREATIONAL PRODUCT REQUIRES TWO PEOPLE TO ASSEMBLE.



WARNING: KEEP ALL FLAME AND HEAT SOURCES AWAY FROM THIS PRODUCT FABRIC.

This product is made of flame-resistant fabric. It is not fireproof. The fabric will burn if left in continuous contact with a flame source.

THIS RECREATIONAL ITEM IS NOT INTENDED FOR USE AS A PERMANENT STRUCTURE.

This product has been developed and is intended to provide protection from sun and light rain. DO NOT use any gas or flame sources under or near this product. Excess water build-up can cause the frame system to become unstable, and collapse, causing injury. Any personal accessories or modifications to product should be removed before the onset of inclement weather such as heavy rain, wind, lightning, hail, snow, etc. This product should be completely dismantled to avoid permanent damage to product components and avoid any possibility of personal injury. This product is not a toy. This product is not designed for use by children without adult supervision. Under no circumstances should this product be used as a permanent or temporary storage facility for children's toys, garden tools, personal belongings or similar valuables.


Parts list



A (1) Canopy Top



B (1) Gazebo frame



C (1) Carry bag w/wheels




D (8) Stakes



E (4) Ropes


Step 1

1. Empty contents of bag(s) and confirm all parts are included and undamaged. Do this at home before you leave on your trip.
2. Select a smooth level site and spread out your gazebo.
3. With two people located opposite each, should be open the frame. Each person must hold two legs to open of coordinate way the frame until about 5 ft.




Step 2


1. Center canopy top over the frame, lining up corners with frame corners. Attach velcro fasteners on the corners ONLY. After fitting each corner of canopy to frame, each person must hold a leg on diagonal corners to open totally frame. One person stands in place while the other walks to frame open out.
2. Secure sides of canopy to frame with velcro fasteners provided (2 on each side). Canopy has been designed to have a tight fit over frame.
3. Secure all remaining velcro fasteners located on underside of canopy to gazebo frame.



Step 3



1. Adjust desired height by sliding legs upward until the lift button locking into place. Raise each leg one notch at a time, making sure all four legs are level before proceeding to the next notch.
2. Stake gazebo by driving stakes through the holes at the foot of each leg. Tip: Use additional weights (sand bags, other heavy objects) on each foot or place legs twelve inches down into sand to help secure set up for beach use. Stakes alone will not secure gazebo in sand or soft soil.
3. To stabilize the gazebo, unroll the guy ropes attached to the webbing loops. Make a loop at the opposite end of the guy line using the plastic slider and place the loop over the gazebo stake. Drive the stake into the ground to secure. Adjust the plastic slider to tighten the guy rope. Repeat for each guy rope.



Reverse the above steps to take it down.



www.truper.com

04-2021

Documents / Resources



[TRUPER TOL-3 Instant Folding Canopy](#) [pdf] Instruction Manual

TOL-3, 66075, TOL-3 Instant Folding Canopy, Instant Canopy, Folding Canopy, Canopy, TOL-3 Folding Canopy, Instant Folding Canopy, 10ftx10ft Canopy

References

-  [Truper® - Es mucha herramienta](#)

Manuals+.