



TR6564-C FAIRY
WIND CHIME LIGHT



Tryme TR6564-C Fairy Wind Chime Light Instruction Manual

[Home](#) » [Tryme](#) » Tryme TR6564-C Fairy Wind Chime Light Instruction Manual 

Contents

- [1 Tryme TR6564-C Fairy Wind Chime Light](#)
- [2 INTRODUCTION](#)
- [3 SPECIFICATIONS](#)
- [4 WHAT'S IN THE BOX](#)
- [5 FEATURES](#)
- [6 SETUP GUIDE](#)
- [7 CARE & MAINTENANCE](#)
- [8 TROUBLESHOOTING](#)
- [9 PROS & CONS](#)
- [10 WARRANTY](#)
- [11 FREQUENTLY ASKED QUESTIONS](#)
- [12 References](#)



Tryme TR6564-C Fairy Wind Chime Light



INTRODUCTION

Give your landscape a mystical glow with the Tryme TR6564-C Fairy Wind Chime Light. This solar-powered wind chime is made for outdoor elegance and creates a captivating atmosphere with its colour-changing LED lights and calming tunes. The integrated Ni-MH 1.2V/AA 600mAh battery is effectively charged by the 2V 120mA solar panel, providing up to 10 hours of illumination once fully charged.

This fairy-themed wind chime is ideal for patios, balconies, or backyards because it is made of weather-resistant materials. It is lightweight but sturdy, with dimensions of 4.72 x 4.72 x 23.6 inches and a weight of 14.4 ounces. It costs \$24.29. It was introduced on December 23, 2022, and is made by Tryme. Charm, peace, and environmentally friendly efficiency are all provided by the Tryme TR6564-C, whether you're upgrading your own outdoor area or giving it to a special someone.

SPECIFICATIONS

Brand	Tryme
Price	\$24.29
Solar Panel	2V 120mA
Power Source	Solar Powered
Storage Battery	Ni-MH 1.2V/AA 600mAh Battery
Charging Time	6-8 hours
Working Time	8-10 hours (full charge)
Product Dimensions	4.72 L x 4.72 W x 23.6 H inches
Manufacturer	Tryme
Item Weight	14.4 ounces
Item Model Number	TR6564-C
Batteries Required	1 AA battery
Date First Available	December 23, 2022



WHAT'S IN THE BOX

- Wind Chime Light
- Manual

FEATURES

- **Delicate Fairy Design:** Fairy figures lend a mystical touch to any outdoor environment.
- **Solar-Powered Operation:** It doesn't need energy to charge during the day and automatically glows at night.
- **7-Color LED Lights:** For a surreal impression, colours alternate between red, green, orange, blue, yellow, purple, and white.
- **Waterproof Construction:** Made to resist high temperatures, rain, snow, and frost.
- **Sturdy Material:** Crafted from premium materials to guarantee extended outdoor use.
- **Energy-Efficient:** Stores energy using an effective Ni-MH 1.2V/AA 600mAh battery and solar power.
- **Simple Installation:** Just hang it anywhere that receives plenty of sunlight; no wiring is needed.
- **8–10 Hours of Illumination:** Up to 10 hours of bright illumination at night are possible with a full charge.
- **Charming Outdoor Décor:** Perfect for eaves, patios, gardens, balconies, and walkways.
- **Gentle Wind Chime Sound:** This creates a gentle, pleasing wind chime.
- **Excellent Gift Choice:** Ideal for holidays, birthdays, Mother's Day, and Father's Day.
- **Lightweight & Compact:** Weighing only 14.4 ounces, it is simple to handle and install.
- **Auto-On/Off Feature:** Automatically turns on at nightfall and off at sunrise.
- **Eco-Friendly:** Encourages sustainable energy and lowers electricity consumption.



SETUP GUIDE

- **Unpack the Wind Chime:** Remove all packaging and inspect it for damage.
- **Pick a Good Location:** For best charging, choose an outdoor area that receives direct sunlight.
- **Activate the Solar Panel:** If necessary, flip on the switch on the solar panel.
- **Attach the Hanging Hook:** Use the integrated hook or string to firmly hang the chime.
- **Ensure the Solar Panel Faces Up:** The 2V, 120mA solar panel needs to be oriented to get the most sunlight possible.
- **Test the Lights:** Place your hand over the solar panel to check if the LED lights turn on.
- **Adjust the Height:** Make sure there is adequate room for movement and that it hangs freely.
- **Secure Against Wind:** Ensure it is securely fastened to avoid excessive swaying in windy environments.
- **Charge Before First Use:** Let it charge for six to eight hours in the sun before using.
- **Track Performance:** Observe how well it illuminates at night and adjust the location if necessary.
- **Use Indoors:** Position it near a bright window for indoor charging.
- **Look for Obstructions:** Ensure no structures or overhanging branches block the sun.
- **Try Various Locations:** If brightness is insufficient, move it to a sunnier spot.
- **Protect in Severe Weather:** Although waterproof, it is best to relocate it during storms.
- **Enjoy the Glow & Chime:** Relax and appreciate the soft chime and colour-changing fairy lights.

CARE & MAINTENANCE

- **Clean the Solar Panel Regularly:** Wipe it with a gentle cloth to remove dust or debris blocking sunlight.
- **Check the Battery Periodically:** If the lights stop working, replace the 1.2V AA battery.
- **Avoid Shaded Areas:** Ensure it receives maximum sunlight for optimal charging.
- **Check for Loose Parts:** Tighten any screws or hooks that may loosen over time.
- **Prevent Water Accumulation:** Although waterproof, do not immerse in water to prolong longevity.
- **Store During Harsh Winters:** Keep indoors during extremely cold temperatures to protect components.
- **Handle Carefully:** Avoid dropping or striking the wind chime to prevent damage.
- **Avoid Harsh Chemicals:** Do not use strong solvents or detergents for cleaning.
- **Monitor LED Performance:** If the lights dim, the battery may need replacement.
- **Adjust Position Seasonally:** Change placement to match sunlight angles throughout the year.
- **Secure Against Strong Winds:** Reinforce in high-wind areas to prevent excessive movement or detachment.
- **Clean Hanging Parts:** Keep fairy figures and chime components free from dust and dirt.
- **Test the On/Off Function:** If lights fail to turn on, ensure the switch is in the correct position.
- **Prevent Insect Buildup:** Check the solar panel for debris or insects periodically.
- **Ensure Long-Term Use:** With proper care, your Tryme TR6564-C Fairy Wind Chime will last for years.



TROUBLESHOOTING

Issue	Possible Cause	Solution
Light not turning on	Insufficient sunlight	Place in direct sunlight for at least 8 hours.
Dim lighting	Battery not fully charged	Ensure the solar panel is clean and gets enough exposure.
Wind chimes not making sound	Low wind conditions	Move to a location with better airflow.
Lights flickering	Loose battery connection	Check and secure the battery compartment.
Short lighting duration	Aging battery	Replace the rechargeable battery.
No color change in LED	LED malfunction	Contact the manufacturer for support.
Water inside the light	Heavy rain exposure	Dry thoroughly and ensure proper sealing.
Charging issue	Dust or dirt on solar panel	Clean the panel with a soft cloth.
Lights turning off quickly	Faulty sensor placement	Ensure it's not near bright artificial lights at night.
No sound from wind chimes	Chime parts tangled	Gently untangle and reposition.

PROS & CONS

Pros

1. Solar-powered, eliminating the need for electricity
2. Weatherproof design for year-round outdoor use
3. Beautiful fairy-themed, colour-changing LED lights
4. Long-lasting illumination of up to 10 hours
5. Easy to install with no wiring required

Cons

1. Requires full sunlight for optimal performance
2. Battery life may decrease over time
3. Wind chimes may not be loud enough for some users
4. Not suitable for extremely windy conditions
5. Charging efficiency may be affected on cloudy days

WARRANTY

The Tryme TR6564-C Fairy Wind Chime Light comes with a **one-year limited warranty**, covering manufacturing defects and performance issues. If your product stops working within the warranty period, you may be eligible for repair or replacement. Ensure you keep the purchase receipt and contact Tryme customer support for assistance.

FREQUENTLY ASKED QUESTIONS

How long does the Tryme TR6564-C Fairy Wind Chime Light take to charge?

It requires 6-8 hours of direct sunlight to fully charge.

How many hours does the Tryme TR6564-C Fairy Wind Chime Light stay illuminated?

When fully charged, it provides 8-10 hours of soft glowing light at night.

What are the dimensions of the Tryme TR6564-C Fairy Wind Chime Light?

This model measures 4.72 x 4.72 x 23.6 inches, making it a decorative addition to gardens, patios, and balconies.

What type of battery does the Tryme TR6564-C Fairy Wind Chime Light use?

It uses a Ni-MH 1.2V/AA 600mAh rechargeable battery, which stores solar energy for nighttime use.

How much does the Tryme TR6564-C Fairy Wind Chime Light weigh?

It weighs 14.4 ounces, making it lightweight and easy to hang anywhere outdoors.

How is the Tryme TR6564-C Fairy Wind Chime Light powered?

It is 100% solar-powered, meaning it charges during the day and automatically lights up at night without needing external electricity.

What is the price of the Tryme TR6564-C Fairy Wind Chime Light?

The Tryme TR6564-C is priced at \$24.29.

Why is my Tryme TR6564-C Fairy Wind Chime Light not turning on at night?

Ensure the solar panel is getting at least 6-8 hours of direct sunlight and check if the battery is installed properly.

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.