



TThotel E3 Reader Encoder User Manual

[Home](#) » [TThotel](#) » TThotel E3 Reader Encoder User Manual 

TThotel E3 Reader Encoder



Contents

- [1 CARD Reader/Encoder E3](#)
- [2 Light/sound status](#)
- [3 Steps](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

CARD Reader/Encoder E3

Model: E3

Dimensions: 70mm x 70mm x 26mm

Power interface: Type-C USB

Power input: 5V/500mA

Radio frequency: 13.56Mhz

Support card type: Mi Fare S50

Light/sound status



When the device is powered on:


- **Green light:** Card encoder mode
- **Blue light:** Card reader mode

Voice prompt on passing a card:


- 🔊 **Success on encoding/reading a card :** One short beep

Steps

1. Connect the USB cable with PC



2. Plug the USB into the card encoder



3. Install drive program for the card encoder

Disclaimer

We continuously optimize products as new technologies and features are developed. For this reason, we reserve the right to make alterations to the products without prior notice.



Documents / Resources

	TThotel E3 Reader Encoder [pdf] User Manual E3, E3 Reader Encoder, E3, Reader Encoder, Encoder
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.