

**Contents** [ [hide](#) ]

- [1 Tumama TM388 Timer Box](#)
- [2 Battery installation](#)
- [3 How to use](#)
- [4 WARNING:](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)




## Tumama TM388 Timer Box



**Model:** TM388


**LOT NO.:** APR507FAJ74-105-X

## Battery installation



Powered by 3 x AA batteries (Not included in the package)

## How to use



1. Turn on.
2. Recording button: Short press to play the recording, long press to save the recording.
3. Music button: Short press to play music, pause music.
4. Head nod and arm embrace when playing music and voice recording.

## **WARNING:**

- This product contains small parts. Please do not swallow to avoid choking hazards. Not suitable for children under three years old.
- Children's play must be under the supervision of adults, and adults take out toys from the package and complete the installation!
- To avoid accidental swallowing or asphyxiation, please do not allow children to play with toys that is breaking apart!
- Only the adults can install and replace the battery.
- The package is not a toy, please keep it away from children.
- To be used under the direct supervision of an adult.

- Keep away from ignition sources.

## Battery notices

- This product uses 3 1.5V “AA” non-rechargeable batteries.
- The battery should be taken out and loaded in accordance with the polarity and voltage signs on the toy battery box.
- The battery should not be short-circuited.
- Non-rechargeable batteries cannot be charged.
- Different types of batteries or old and new batteries cannot be mixed to use.
- Only the same or equivalent battery as the recommended battery to be used. The used battery should be taken out of the toy. If it is not used for a long time, please take out the battery in the toy.
- The power terminals must not be short-circuited.
- Cannot connect to more than the recommended number of power supplies.



## We'd like to hear from you!

Should you have any suggestions for our product, please let us know.



Email: [support@tumama-kids.com](mailto:support@tumama-kids.com)

[Tumama-kids.com](http://Tumama-kids.com)

(C/Tumama Kids Care (ShenZhen) Company Limited All Rights Reserved

## Documents / Resources



کتاب  
說明書  
Handbuch  
Instructions  
Manual  
Manuale  
取扱説明書  
설명서  
Handledning  
Podrecznik  
Manual  
Pysoasactao  
Instruktioner  
Manual  
Model: TM388  
LOT NO.: AP00207476-005-X

## [Tumama TM388 Timer Box \[pdf\]](#) User Manual

TM388, TM3882, TM388 Timer Box, TM388, Timer Box, Box

## References

- [User Manual](#)

box, Timer Box, TM388, TM388 Timer Box, TM3882,

Tumama Tumama

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

## Search:

e.g. whirlpool wrf535swhz

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.