




# TUNAI Wand Bluetooth Transmitter User Manual

[Home](#) » [TUNAI](#) » TUNAI Wand Bluetooth Transmitter User Manual 



TUNAI WAND  
BLUETOOTH TRANSMITTER

	<a href="http://www.tunai-creative.com">www.tunai-creative.com</a>
	<a href="https://www.facebook.com/tunai.global/">www.facebook.com/tunai.global/</a>
	<a href="https://www.instagram.com/tunai_creative_eng/">www.instagram.com/tunai_creative_eng/</a>

## Contents

### [1 IMPORTANT NOTICE](#)

### [2 WARRANTY](#)

### [3 TUNAI WAND OVERVIEW](#)

### [4 INSTALLATION](#)

### [5 Documents / Resources](#)

#### [5.1 References](#)

### [6 Related Posts](#)

## IMPORTANT NOTICE

- DO NOT expose the product under direct sunlight for long hours
- DO NOT disassemble the product, unauthorized disassembly will result in a warranty to expire
- USE ONLY power adapters with 5V output

## WARRANTY


TUNAI provides a one-year product warranty, please keep your purchase proof and package.  
The warranty does not cover the following :

1. Consumable parts (example: exterior coating damage)
2. Appearance damage
3. Damage caused by improper use of other products
4. Damage caused by failure to comply with instructions
5. Purchased from an unauthorized seller
6. Unauthorized disassembly of the product
7. Damage caused by accident, abuse, improper use, fire, earthquake, or other external causes.

– TUNAI WAND User Manual –

## TUNAI WAND OVERVIEW

Button



## INPUT PORTS




- USB : Power supply and USB audio input
- AUX : 3.5mm audio input
- SDPIF : Optical audio input

## BUTTON

- Short press: Mode change / Wake up
- Long press: Force WAND to enter pairing mode

## LED Indicator

### LED Color

	White	AUX
	Blue	SPDIF
	Orange	Micro USB

### LED Status

Rapid Flash	Pairing Mode
Slow Flash	Available for the previously paired device to connect
LED On	Connected
LED Off	LED goes off automatically after 5 minutes

## INSTALLATION

1. Connect WAND and USB power adapter with the included micro USB cable. LED will flash once powered.
2. Connect WAND and the audio source to the input port using the corresponding cable (micro USB and 3.5mm to RCA is included).

## PAIRING

### ENTER PAIRING MODE

1. WAND will enter pairing mode when powered for the first time.
2. LED will flash rapidly when entering pairing mode.
3. To force re-enter pairing mode, long-press the button for 5 seconds.

## PAIRING WITH BLUETOOTH HEADPHONES


1. Force both WAND and Bluetooth headphones to enter pairing mode. WAND will enter pairing mode automatically when powered for the first time.
2. WAND will be connected with Bluetooth headphones automatically once both enter pairing mode.
3. LED indicator stop flashes once paired

## AUDIO CODECS

WAND supports aptX for high-quality audio, aptX for low latency, and standard SBC. To connect with aptX or aptX low latency, Bluetooth headphones will need to also support these audio CODECs. Otherwise, standard SBC will be used for the connection.

Connection priority : aptX low latency > aptX > SBC.

## Documents / Resources

	<p><a href="#">TUNAI Wand Bluetooth Transmitter</a> [pdf] User Manual Wand, Bluetooth Transmitter</p>
---	---

## References

- [Facebook](#)
- [TUNAI Creative](#)

