

TUO TTS-1195-2 Temperature Sensor User Manual

Home » TUO » TUO TTS-1195-2 Temperature Sensor User Manual

Contents

- 1 TUO TTS-1195-2 Temperature
- Sensor
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 Getting started
- 5 Pairing & activation
- 6 Pairing & activation
- 7 Battery replacement
- 8 Resetting the sensor
- 9 Mounting & removable stand
- 10 Mounting & removable stand
- 11 Legal information
- 12 Documents / Resources
 - 12.1 References
- 13 Related Posts



TUO TTS-1195-2 Temperature Sensor



Product Information

Specifications

- Product Name: TUO Temperature Sensor
- · Compatibility: Compatible with home hubs
- Reset Button: Located on the backplate, can be accessed with a small pin
- · Magnetic Stand: Removable with adhesive included for wall mounting
- Warning: Contains a magnet, keep away from people with pacemakers or other medical devices affected by magnetic fields
- · Legal Compliance: Complies with part 15 of FCC rules

Product Usage Instructions

Pairing the TUO Temperature Sensor

To start using the TUO Temperature Sensor, you need to pair it with your home hub. Make sure your network is compatible.

Resetting the Device

If you need to reset the TUO Temperature Sensor, follow these steps:

- 1. Remove the backplate of the device.
- 2. Locate the reset button and push it in once to reboot the device.
- 3. If you want to completely reset the device, push and hold the reset button for 10 seconds. Please note that this will remove the device from the platform you are using and will require re-pairing.

Mounting the Sensor

The TUO Temperature Sensor comes with a removable magnetic stand. If you wish to mount the sensor to your wall, follow these steps:

- 1. Remove the base of the sensor.
- 2. Use the adhesive included on the back of the product to attach it to the desired surface.

Important Safety Instructions

Magnet Warning: This device contains a magnet and should be kept away from people with pacemakers or other medical devices that may be affected by magnetic fields. It is important to keep the device at a safe distance from these individuals to avoid any potential harm or interference with their medical devices. Failure to follow the safety instructions and warnings provided in the user manual may result in injury, damage to property, or other harmful consequences.

Legal Information

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

If this device causes harm to television reception, you can try the following measures to correct the interference:

- Re-orient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Consult a dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by TUO Accessories LLC can void the user's authority to operate this device. This equipment should be installed and operated with a minimum distance of 0cm between the radiator and your body.


FAQ

Q: Where should I keep my Matter Setup Code?

A: Please keep your Matter Setup Code in a safe place. You will need it to securely add the TUO Temperature Sensor to your home.

Getting started

Pull the battery safety tab from the back of the TUO Temperature Sensor. When you see the LED blink 5 times, followed by 3 blinks, that means the device is in pairing mode.




Pairing & activation

- Pair the TUO Temperature Sensor to the home hub of your choice. Ensure your network has a compatible thread Border Router.
- To learn more about thread Border Routers, head to http://findtuo.com/borderrouter


Pairing & activation

Turn the TUO Temperature Sensor around to reveal the pairing code. Scan or type in the manual pairing code in the platform of your choice.



Battery replacement

When it is time to replace the battery, simply turn the TUO Temperature Sensor around and remove the backplate.




Resetting the sensor

- With the backplate removed, you can push the reset button with a small pin. Push it in once to reboot the device.
- Push it in and hold for 10 seconds to completely reset the device. Please note that this will remove the device from the platform you are using and will require re-pairing.

Mounting & removable stand

The TUO Temperature Sensor comes with a removable magnetic stand. If you wish to mount the sensor to your wall, simply remove the base and use the adhesive included on the back of the product.



Warning

Magnet warning: This device contains a magnet and should be kept away from people with pacemakers or other medical devices that may be affected by magnetic fields. It is important to keep the device at a safe distance from these individuals to avoid any potential harm or interference with their medical devices. Please note that failure to follow the safety instructions and warnings provided in the user manual may result in injury, damage to property, or other harmful consequences

Mounting & removable stand

Legal information

- This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.
- This equipment has been tested and found to comply with the limits for a Class B digital device under part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation, this device generates uses and can radiate radio frequency energy, and if not installed and used by instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.
- If this device does cause harm to television reception, which can be determined by turning the equipment off and on, you are encouraged to try to correct the interference by one or more of the following measures: reorient or relocate the receiving antenna, increase the separation between the equipment and receiver, or consult a dealer or an experienced radio/TV technician for help.
- Changes or modifications not expressly approved by TUO Accessories LLC can void the user's authority to

operate this device.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This
equipment should be installed and operated with a minimum distance of 0cm between the radiator and your
body

Please keep your Matter Setup Code in a safe place. You need it to securely add a TUO Temperature Sensor to your home.

findtuo.com

Model: TTS1195 • FCC ID:

Documents / Resources



TUO TTS-1195-2 Temperature Sensor [pdf] User Manual TTS-1195-2 Temperature Sensor, TTS-1195-2, Temperature Sensor, Sensor

References

• User Manual

Manuals+, Privacy Policy