



## Tupperware PremiaGlass Serve and Store Container User Manual

[Home](#) » [Tupperware](#) » Tupperware PremiaGlass Serve and Store Container User Manual 

# Tupperware

PremiaGlass Serve and Store Container  
User Manual



## Contents

- [1 PremiaGlass Serve and Store Container](#)
- [2 FEATURES & BENEFITS](#)
- [3 USE AND CARE](#)
- [4 CLEANING GUIDELINES](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

## PremiaGlass Serve and Store Container

© 2022, Tupperware – All Rights Reserved.

Tupperware PremiaGlass Serve & Store Container offers versatility at its best – crafted of 100% borosilicate glass, the multi-purpose container delivers the flexibility of using it in the freezer, microwave and oven. It is also uniquely designed with aesthetically beautiful yet functional smart locking lids that is Instagram worthy and a sleek addition to any kitchen.



## FEATURES & BENEFITS

- **Crystal-Clear Glass Base:** Crystal Clear Clarity base makes it easy to see what's inside.
- **Clip-Secure Lid System – 100% Airtight & Leak Proof Performance:** 4-latch smart-locking lids that uses secure fitting lids with silicone seal to keep food 100% air-tight and leak-proof.
- **Multipurpose – Bake-Store-Reheat-Serve:** Tupperware PremiaGlass is made of borosilicate glass that can go safely from freezer to the microwave or pre-heated oven (without the lid) all in the same dish so it saves you the hassle of extra washing!
- **Made with 100% Borosilicate Glass:** With heat-resistant glass material that can withstand temperature up to 300°C / 572°F.
- **10% lighter than tempered glass:** Lightness that lifts a burden off your wrist.
- **Stain and Odor Resistant:** Made from non-porous glass that does not absorb food odor, flavors or stains.
- **Stackable:** Allow you to maximize space on pantry and fridge.
- **Removable Gasket:** for easy cleaning and sanitizing.
- Freezer, Dishwasher, Oven and Microwave Safe (without the lid)
- **Made with heat resistant:** glass that never warps or crack with proper use & care.

## USE AND CARE

- **Microwave Safe:** Use for reheating purpose in microwave without browning element. When reheating in the microwave, remove lid and cover with paper towel to prevent splatters.
- **Oven Safe:** Only glass vessels can be used in conventional ovens and lids should be removed at all times. Oven safe temperature is up to 300°C / 572°F.
- **Refrigerator and Freezer Safe:** When using the glass vessel for storing food in refrigerator or freezer, please remove the lid and allow glass vessel to sit for 1 – 2 minutes before placing in the microwave and/or oven. When freezing, only fill container 75% to allow room for expansion.
- Do not use on or under a flame or other direct heat sources.
- Do not use on stovetop, under browning element, on a grill or in a toaster oven.

## CLEANING GUIDELINES

- Always wash and dry your products before first use to avoid gasket coming off due to manufacturing residues.
- Removable gasket for easy cleaning.
- Wash in hot, soapy water and rinse well, or wash in the dishwasher.
- When placing in dishwasher, avoid mechanical shock by allowing sufficient space between the glass vessels.
- Upon using in oven, ensure to cool down the glass properly before washing, to avoid thermal shock.
- To remove any stubborn stains or food residue, soak briefly in warm soapy water before washing.
- Do not use abrasive cleaning pads or abrasive cleaners, as these will scratch the base and plastic lid.

### !!! WARNING !!!

As with all glass products, failure to carefully follow the use and care instructions may cause the product to break, which could result in property damage and serious personal injury.

### THE TUPPERWARE COMMITMENT

Our products reflect our commitment to making a measurable impact on the world around us. At Tupperware, we design all products with minimizing plastic and food waste in mind. By creating quality, durable and reusable products made to stand the test of time, we're supporting our mission to reduce waste for the longevity of our planet, our people and the communities in which we live and work.


The Tupperware PremiaGlass Serve & Store Container is covered by a Tupperware warranty against any material or manufacturing defects that may occur when using the product according to directions and in normal household use. This warranty does not include replacement for damage to the product resulting from negligent use or misuse of the product.

If your product is covered by warranty, please refer to the warranty terms applicable to your country for a full description of coverage.

Your Tupperware product is meant to be used again and again. If for any reason your product is damaged and not covered by warranty or you no longer need your product, please be responsible and recycle it, or let us know if we can help you.

# Tupperware

## Documents / Resources

 <p>PremiaGlass Serve &amp; Store Container</p> <p>Tupperware</p>	<p><a href="#">Tupperware PremiaGlass Serve and Store Container</a> [pdf] User Manual</p> <p>PremiaGlass Serve and Store Container, PremiaGlass, Serve and Store Container, Store Container, Container</p>
--	--