



TURBO GEARS F1 AW24 Remote Controlled Vehicle Instruction Manual

Home » TURBO GEARS » TURBO GEARS F1 AW24 Remote Controlled Vehicle Instruction Manual

Contents

- 1 TURBO GEARS F1 AW24 Remote Controlled **Vehicle**
- **2 Product Information**
- **3 Product Usage Instructions**
- 4 Battery installation
- **5 FEATURES**
- 6 Documents / Resources
 - **6.1 References**



TURBO GEARS F1 AW24 Remote Controlled Vehicle



Product Information

Specifications:

• Dimensions: 43mm x 3mm x 24mm

Recommended Age: 4+Manufacturer: PLDZ

· Country of Origin: China

Product Usage Instructions

Safety Information:

This remote-controlled vehicle is recommended for children aged 4 and above. Please remove the toy from the packaging before giving it to a child. Keep the packaging, instructions, or labels as they contain important information. The toy may produce flashes that could trigger epilepsy in sensitive individuals.

Battery Installation:

To install the batteries, follow these steps:

- 1. Open the battery compartment.
- 2. Insert 5 x 1.5V AA batteries, ensuring correct polarity (+ and -).
- 3. Securely close the battery compartment.

Battery Replacement:


If the toy stops functioning properly, replace the batteries with new ones for optimal performance.


FAQ:

- Q: What age is this remote-controlled vehicle suitable for?
 - A: This toy is recommended for children aged 4 years and older.
- Q: Where is the product manufactured?
 - A: The product is manufactured in China and imported by various distributors as listed in the manual.
- Q: What should I do if the toy produces flashes that could trigger epilepsy?

A: If the toy's flashing lights are a concern, discontinue use and consult a healthcare professional, especially if you or your child are sensitive to such stimuli.

Battery installation





- Batteries should be installed by an adult.
- Batteries to be used: 5 x 1.5V "AA".
- The figure shows the battery assembly.
- Please be careful to ensure safety when removing/replacing the batteries.
- Turn off the product before removing/replacing the batteries.
- Unscrew the screws and/or pry open the cover, remove the batteries safely.
- When inserting batteries, ensure that the plus and minus terminals (+ and) are aligned correctly.
- Replace with new batteries before use.
- Alkaline batteries are recommended for better performance.
- Replace the batteries if the product does not work properly.

Batteries not included.

Radio-frequency: 27.145MHz.MAX RF power: -27.66dBm.

FEATURES



R/C VEHICLES. Material: ABS, TPR

Warning. Not suitable for children under the age of 36 months. Small parts. Choking hazard. The toy is recommended for children over 4 years of age. Remove all packaging before giving the toy to a child. Keep the packaging / leaflet/label for future reference as it contains important information. This toy produces flashes that may trigger seizures for individuals with photosensitive epilepsy.

Produced for: PEPCO Poland Sp. z o.o., ul. Strzeszyńska 73A, 60-479 Poznań Poland, NIP (NIF) 782-21-31-

157.

Produced for: PLDZ, Pattison House, Midland Road, Walsall, WS1 3TX



MULTICOLOR 5 • SKU 60144601 SKU (Pdl) 865135 STYLE 601446 • A/W24 • B/X

Documents / Resources

TURBO GEARS F1 AW24 Remote Controlled Vehicle [pdf] Instruction Manual F1 AW24, F1 AW24 Remote Controlled Vehicle, Remote Controlled Vehicle, Controlled Vehicle, Vehicle

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.