



typecase KB201T-083-V2 Keyboard Case for iPad Mini 6 User Manual

[Home](#) » [typecase](#) » typecase KB201T-083-V2 Keyboard Case for iPad Mini 6 User Manual 

Contents

- [1 typecase KB201T-083-V2 Keyboard Case for iPad Mini 6](#)
- [2 TECHNICAL SUPPORT](#)
- [3 SETUP](#)
- [4 SHORTCUT MAP](#)
- [5 SHORTCUT MAP](#)
- [6 Symbol](#)
- [7 TOUCHPAD FUNCTION](#)
- [8 INSTALLATION AND REMOVAL](#)
- [9 ROTATION AND USAGE](#)
- [10 TO CHARGE THE KEYBOARD](#)
- [11 TROUBLESHOOTING](#)
- [12 PRODUCT SPECS](#)
- [13 IC CAUTION](#)
- [14 FCC CAUTION](#)
- [15 Documents / Resources](#)
 - [15.1 References](#)
- [16 Related Posts](#)

typecase®

typecase KB201T-083-V2 Keyboard Case for iPad Mini 6



TECHNICAL SUPPORT

If you encounter any difficulties or have inquiries, please do not hesitate to reach out to us at your earliest convenience.

For the quickest and most efficient support experience, please contact us directly through one of the following channels, rather than through Amazon.

1. Email: support@typecase.co
2. Phone: 832 – 303 – 5080
3. Chat: <https://typecase.co/support>



SETUP

To Pair with Your iPad

1. Turn the ON/OFF switch to the 'ON' position.



2. The Bluetooth indicator light will start to blink. If it doesn't, hold down the button for 3 seconds.
3. Go to the Settings app and turn on Bluetooth. (The device is connected when the Bluetooth indicator stops flashing.)




4. In the Bluetooth section of the Settings app, select 'Typecase Flexbook' under 'MY DEVICES'.

5. Tap 'Pair' in the pop-up window as shown.



Note: To pair with new devices, repeat steps 1-5.

Pairing complete when "Connected" indicator appears.



SHORTCUT MAP

Notice: Long Hold rx1 in any app to view available shortcuts.




Long Hold - App specific shortcut shows up (e.g. when you are in an App, hold this key and you will see all the shortcuts that can be used in this App).

control + fn = Touchpad ON/OFF

control + fn = Virtual Keyboard ON/OFF


C + R + L = Reset the keyboard

System




SHORTCUT MAP


Multitasking













Slide Over

















Format



















Split View































 +  +  = Tile Window Left
 +  +  = Tile Window Right
 +  = Next Window
 +  = Enter Fullscreen

Edit

 +  = Jump to last word
 +  = Jump to next word
 +  = Jump to top of the page
 +  = Jump to bottom of the page
 +  = Jump to begin of the line
 +  = Jump to end of the line
 +  = Switch language and typewritingspace

	+		=Select All
	+		=Cut
	+		=Copy
	+		=Paste
	+		=Undo Typing
	+		=Find
	+		=Dictation
	+		=Emoji

Symbol

	+		=®		+		=≥		+		=Δ		+		=Ω		+		=β
	+		=©		+		=≤		+		=π		+		=≈		+		=Σ
	+		=≠		+		=÷		+		=√		+		=μ		+		=∞

TOUCHPAD FUNCTION

Notice: Make sure bluetooth is connected and touchpad function is turned on!

Tap

Tap with a single finger until it feels a little touch feeling.



Drag

Tap and hold an item, then swipe your finger across the trackpad to move it.

Open Program

Expansion Dock

Swipe the pointer across the bottom of the screen with one finger.

**View Slide Over**

Use one finger to swipe the pointer past the right edge of the screen. To hide Slide Over, swipe right again.




Open Control Center

Use one finger to move the pointer to select the status icons at the top right, then click.

Or, select the status icons at the top right, then swipe up with one finger.

Move Up Or Down

Swipe up or down with two fingers.

**Zoom**




Place two fingers close together, open to enlarge, or pinch to zoom out.

Open "Today" View

When the Home or Lock screen is visible, swipe right with two fingers.

Open APP Switcher

Swipe up with three fingers, pause and lift your finger.



Tap and Hold



Tap and hold with a single finger.

Awake

Click the touchpad or press any key on the keyboard.

Go To Home Screen

Swipe the pointer across the bottom of the screen with one finger, and when the Dock appears, swipe the pointer across the bottom of the screen again.



Open Notification Center



Use one finger to move the pointer to select the status icons at the top left, then click.
Or, use one finger to move the pointer past the top of the screen near the middle.

Move Left Or Right

Swipe left or right with two fingers.

Open Searching

From Home Screen Swipe down with two fingers.



Secondary click

Click with two fingers to show the quick actions menu for items like icons on the Home Screen, messages in a mailbox, and the Camera button in Control Center.

Or, you can press the Control key while you click the trackpad.




Go To Home Screen

Swipe up with three fingers.

Shift Between

The Open APP




Swipe left or right with three fingers.



INSTALLATION AND REMOVAL




Installation

1. Align iPad's bottom with the keyboard case.
2. Press and hold the middle of the upper edge of the iPad.
3. Press the top corners of the iPad to securely fit into the case.



Removal

1. Press and hold the middle of the upper edge of the iPad.
2. Push the top corners to detach the case.
3. Pull up to remove iPad.



ROTATION AND USAGE




Rotate 360° by twisting



Opens up to 180°



WARNING





TO CHARGE THE KEYBOARD

1. Turn on the keyboard (if battery indicator is flashing, please charge the keyboard).
Plug the charging cable (included) into the keyboard and power adapter (not included, iPad or iPhone power adapter recommended);



iPad adapters


- Battery indicator turns red when keyboard is charging;


- Battery indicator turns blue when charging is complete.

TROUBLESHOOTING

If your keyboard is not functioning properly, please follow these steps to resolve the issue:

1. Ensure Bluetooth is enabled on your iPad or other Bluetooth device.
2. Verify that the keyboard is within 33 feet range.
3. Confirm that the keyboard is charged.
4. Turn on the keyboard, check the battery level by indicator.



5. Press the  key and check the Bluetooth connection status.
6. Ensure the keyboard has successfully paired via Bluetooth.

If you are encountering unwanted cursor move when typing, or some keys like 7,8,9,U,O,J,K,L cannot be entered, please Turn OFF AssistiveTouch> Mouse Keys as follows:


1. On your iPad, go to Settings > Accessibility and select Touch.
2. Select AssistiveTouch, then select Mouse Keys.
3. Turn Off Mouse Keys



TROUBLESHOOTING

If you are encountering unwanted auto-correction or punctuation, follow these steps:

1. Open the Settings app > General > Keyboard > Hardware Keyboard.
2. Turn OFF the options for Auto-Capitalization, Auto-Correction, and “.” shortcut (refer to the accompanying picture for reference).



If you experience difficulty pairing your keyboard via Bluetooth, please follow these steps:

1. Delete any previously paired Bluetooth devices on your iPad.
2. Turn off Bluetooth on your iPad.
3. Restart your iPad.
4. Turn on Bluetooth on your iPad.
5. Turn off and on the keyboard.
6. Repeat the pairing steps as described on page 2 and 3 of the manual.

If you're still having problems troubleshooting your keyboard, try doing a hard reset:

Hold down C+R+L on the keyboard, until the keyboard indicators begin to flash. The keyboard will be reset.

PRODUCT SPECS

- Operating distance: 10 meters (33 feet)
- Modulation System: GFSK
- Working voltage: 3.0-4.2V
- Working current: 0.88-200mA
- Sleeping current: < 125µA
- Charging current: < 800mA
- Continuous working time without backlight: 60 hours
- Charging time: < 2.5 hours
- Charging voltage: 5V
- Key's life span: > 5 million strokes
- Operating temperature: -10 ± 55° C
- Maintenance: Please preserve the
- keyboard under normal temperature and recharge under normal voltage.

IC CAUTION

This device complies with Industry Canada licence-exempt RSS standard(s).

Operation is subject to the following two conditions:

1. This device may not cause interference. and
2. This device must accept any interference, including interference that may cause undesired operation of the device.

FCC CAUTION

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the

user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

RF warning for Portable device

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Documents / Resources

 <p>typecase TOUCH USER MANUAL</p> <p>compatible with iPad Mini 6th Gen</p> <p>For warranty registration and product support:</p> <p>1-800-888-8888</p>	<p>typecase KB201T-083-V2 Keyboard Case for iPad Mini 6 [pdf] User Manual</p> <p>KB201T-083-V2 Keyboard Case for iPad Mini 6, KB201T-083-V2, Keyboard Case for iPad Mini 6, Case for iPad Mini 6, iPad Mini 6, Mini 6</p>
--	---

References

- [User Manual](#)