



typecase KB201TM-100 Keyboard Case for iPad 10th Generation User Manual

[Home](#) » [typecase](#) » typecase KB201TM-100 Keyboard Case for iPad 10th Generation User Manual 

typecase KB201TM-100 Keyboard Case for
iPad 10th Generation User Manual

typecase® TOUCH

USER MANUAL



For warranty registration and product support:



typecase.co/resources



+1(832) 303-5080



support@typecase.co

Contents

- 1 TECHNICAL SUPPORT
- 2 SETUP
- 3 SHORTCUT MAP
- 4 TOUCHPAD FUNCTION
- 5 INSTALLATION AND REMOVAL
- 6 ROTATION AND USAGE
- 7 BATTERY AND CHARGING
- 8 TROUBLESHOOTING
- 9 PRODUCT SPECS
- 10 IC CAUTION
- 11 FCC CAUTION
- 12 Documents / Resources
 - 12.1 References

TECHNICAL SUPPORT

If you encounter any difficulties or have inquiries, please do not hesitate to reach out to us at your earliest convenience.



For the quickest and most efficient support experience, please contact us directly through one of the following channels, rather than through Amazon.

1. Email: support@typecase.co
2. Phone: 832 – 303 – 5080
3. Chat: <https://typecase.co/support>

SETUP

To Pair with Your iPad:

1. Turn the **ON/OFF** switch to the '**ON**' position.
2. The Bluetooth indicator light will start to blink. If it doesn't, hold down the '**Pair**' button for 3 seconds.
3. Go to the Settings app and turn on Bluetooth. (The device is connected when the Bluetooth indicator stops flashing.)




4. In the Bluetooth section of the Settings app, select '**Typecase Flexbook**' under '**MY DEVICES**'.

5. Tap '**Pair**' in the pop-up window as shown.


***Note: To pair with new devices, repeat steps 1-5.**

Pairing complete when "**Connected**" indicator appears.








SHORTCUT MAP

Notice: Long Press  in any app to view available shortcuts.







Keyboard



 +  = Lock Screen

 +  +  = Reset the keyboard



System




 +  = Go to Home Screen



 +  = Siri




 +  = Go to Home Screen



 +  +  = Show App Library

 +  = Quick Note

 +  +  = Screenshots

 +  = Show Dock

 +  +  = Screenshots and Markup



 +  = Control Center

 +  +  = Show Dock








 +  = Notification Center

 +  = Search







 +  = Show Keyboard Shortcuts

 +  = Switch App

















Multitasking

-  +  = App Switcher
-  +  = Show All Windows
-  +  = Previous App
-  +  = Next App































Format

-  +  = Bold
-  +  = Italic
-  +  = Underline












Edit

-  +  = Jump to last word
-  +  = Jump to next word
-  +  = Jump to top of the page
-  +  = Jump to bottom of the page
-  +  = Jump to begin of the line
-  +  = Jump to end of the line
-  +  = Select All
-  +  = Switch language and typewritingspace









Symbol

- | | | | | |
|---|---|---|--|---|
|  +  = ® |  +  = ≥ |  +  = Δ |  +  = Ω |  +  = β |
|  +  = © |  +  = ≤ |  +  = π |  +  = ≈ |  +  = Σ |
|  +  = ≠ |  +  = ÷ |  +  = √ |  +  = μ |  +  = ∞ |

Slide Over

-  +  +  = Move to Left Slide Over
-  +  +  = Move to Right Slide Over
-  +  = Show Slide Over
-  +  +  = Next Slide Over Window

Split View

-  +  +  = Tile Window Left
-  +  +  = Tile Window Right
-  +  = Enter Fullscreen

Notice: Make sure bluetooth connected and touch pad function turned on!



Tap

Tap with a single finger until it feels a little touch feeling.



Tap and Hold

Tap and hold with a single finger.



Drag

Tap and hold an item, then swipe your finger across the trackpad to move it.



Awake

Click the touchpad or press any key on the keyboard.



Open Program Expansion Dock

Swipe the pointer across the bottom of the screen with one finger.



Go To Home Screen

Swipe the pointer across the bottom of the screen with one finger, and when the Dock appears, swipe the pointer across the bottom of the screen again.




View Slide Over

Use one finger to swipe the pointer past the right edge of the screen. To hide Slide Over, swipe right again.



Open Notification Center

Use one finger to move the pointer to select the status icons at the top left, then click.
Or, use one finger to move the pointer past the top of the screen near the middle.



Open Control Center

Use one finger to move the pointer to select the status icons at the top right, then click.
Or, select the status icons at the top right, then swipe up with one finger.



Move Left Or Right

Swipe left or right with two fingers.




Move Up Or Down

Swipe up or down with two fingers.



Open Searching From Home Screen

Swipe down with two fingers.



Zoom

Place two fingers close together, open to enlarge, or pinch to zoom out.



Secondary click

Click with two fingers to show the quick actions menu for items like icons on the Home Screen, messages in a mailbox, and the Camera button in Control Center.
Or, you can press the Control key while you click the trackpad.



Open "Today" View

When the Home or Lock screen is visible, swipe right with two fingers.



Go To Home Screen

Swipe up with three fingers.



Open APP Switcher

Swipe up with three fingers, pause and lift your finger.




Shift Between The Open APP

Swipe left or right with three fingers.

INSTALLATION AND REMOVAL


Installation:

1



Gently attach the iPad to the back cover.

2



Pull up to remove the iPad from the back cover.

ROTATION AND USAGE




Rotate 360° by twisting




Opens up to 180°


WARNING



BATTERY AND CHARGING


To Check The Battery Status Of The Keyboard

Press  on the keyboard. The battery level will be indicated by the number of lit indicators.



1. battery level is between 100% and 70%
2. battery level is between 70% and 40%
3. battery level is between 40% and 10%
4. battery level is less than 10%

Note: If the keyboard has been connected to an iPad, you can also check the battery status through the iPad's battery widget.




To Charge The Keyboard

1. Turn on the keyboard (if battery indicator is flashing, please charge the keyboard).
2. Plug the charging cable (included) into the keyboard and power adapter (not included, iPad or iPhone power adapter recommended);
 - a) Battery indicator turns red when keyboard is charging;
 - b) Battery indicator turns blue when charging is complete.

TROUBLESHOOTING

If your keyboard is not functioning properly, please follow these steps to resolve the issue:

1. Ensure Bluetooth is enabled on your iPad or other Bluetooth device.
2. Verify that the keyboard is within 33 feet range.
3. Confirm that the keyboard is charged.
4. Turn on the keyboard, press  to check the battery level by indicator.
5. Press the 'Pair' key and check the Bluetooth connection status.
6. Ensure the keyboard has successfully paired via Bluetooth.

If you are encountering unwanted cursor move when typing, or some keys like 7,8,9,U,O,J,K,L cannot be entered, please Turn OFF Assistive Touch> Mouse Keys as follows:

1. On your iPad, go to Settings > Accessibility and select Touch.
2. Select Assistive Touch, then select Mouse Keys.
3. Turn Off Mouse Keys



If you are encountering unwanted auto-correction or punctuation, follow these steps:

1. Open the Settings app > General > Keyboard > Hardware Keyboard.
2. Turn OFF the options for Auto-Capitalization, Auto-Correction, and “.” shortcut (refer to the accompanying picture for reference).



If you experience difficulty pairing your keyboard via Bluetooth, please follow these steps:

1. Delete any previously paired Bluetooth devices on your iPad.
2. Turn off Bluetooth on your iPad.
3. Restart your iPad.
4. Turn on Bluetooth on your iPad.
5. Turn off and on the keyboard.
6. Repeat the pairing steps as described on page 2 and 3 of the manual.

If you're still having problems troubleshooting your keyboard, try doing a hard reset:

Hold down C+R+L on the keyboard, until the keyboard indicators begin to flash. The keyboard will be reset.

PRODUCT SPECS

Operating distance: 10 meters (33 feet)
Modulation System: GFSK
Working voltage: 3.0-4.2V

Working current: 0.88-200mA
Sleeping current: < 125µA
Charging current: < 800mA
Continuous working
time without backlight: 60 hours
Charging time: < 2.5 hours
Charging voltage: 5V
Key's life span: > 5 million strokes
Operating temperature: -10 ± 55°C
Maintenance: Please preserve the keyboard under normal temperature and recharge under normal voltage.

IC CAUTION

This device complies with Industry Canada licence-exempt RSS standard(s).
Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device.

FCC CAUTION

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

*RF warning for Portable device:

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Documents / Resources

 <p>typecase TOUCH USER MANUAL</p> <p>For warranty registration and product support:</p> <p>WARRANTY REGISTRATION CALL 1-800-800-8000 PRODUCT SUPPORT</p>	<p>typecase KB201TM-100 Keyboard Case for iPad 10th Generation [pdf] User Manual KB201TM-100 Keyboard Case for iPad 10th Generation, KB201TM-100, Keyboard Case for iPad 10th Generation, Case for iPad 10th Generation, iPad 10th Generation, 10th Generation</p>
---	--

References

- [User Manual](#)

Manuals+. **Privacy Policy**

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.