



U-PROX Wireless Multifunction Button User Manual

[Home](#) » [U-PROX](#) » U-PROX Wireless Multifunction Button User Manual 

U-PROX BUTTON Wireless Multifunction Button User Manual

Contents

- [1 WIRELESS MULTIFUNCTION BUTTON](#)
- [2 TECHNICAL SPECIFICATIONS](#)
- [3 REGISTRATION](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

WIRELESS MULTIFUNCTION BUTTON



www.u-prox.systems/doc_button



www.u-prox.systems




support@u-prox.systems

Is a part of the U-Prox security alarm system
User manual

Manufacturer: Integrated Technical Vision Ltd. Vasyl Lypkivsky str. 1, 03035, Kyiv, Ukraine



https://www.u-prox.systems/doc_button



U-Prox Button – is a wireless key fob / button designed to control the U-Prox security system.

It has one soft key and a LED indicator for interaction with the user of the alarm system. Can be used as a panic button, fire alarm button, medical alert key fob or button, for confirmation of patrol arrival, for switching on or off relay, etc. Button press time is adjustable.

The device is registered for the user of the control panel and is configured with the U-Prox Installer mobile application.

Functional parts of the device (see picture)

1. Top case cover
2. Bottom case cover
3. Fastening strap
4. Button
5. LED indicator
6. Mounting bracket

TECHNICAL SPECIFICATIONS

Power	3V, CR2032 lithium battery included
Service life of battery	up to 5 years
Communication	ISM-band wireless interface with several channels
Dimensions	ITU region 1 (EU, UA): 868.0 to 868.6 MHz, bandwidth 100kHz, 10 mW max., up to 300m (in line of sight); ITU region 3 (AU): 916.5 to 917 MHz, bandwidth 100kHz, 10 mW max., up to 300m (in line of sight).
Operating temperature	-10°C to +55°C
Radio frequency	Ø 39 x 9 x 57 mm
Bracket dimensions	Ø 43 x 16 mm
Case colour	white, black
Weight	15 grams

COMPLETE SET

1. U-Prox Button;
2. CR2032 battery (pre-installed);
3. Mounting bracket
4. Mounting kit;
5. Quick start guide


CAUTION. RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT TYPE. DISPOSE USED BATTERIES ACCORDING TO THE NATIONAL REGULATIONS

WARRANTY


Warranty for U-Prox devices (except batteries) is valid for two years after the purchase date. If the device operates incorrectly, please contact support@u-prox.systems at first, maybe it can be solved remotely.

REGISTRATION


REGISTRATION



INDICATION




INSTALLATION



U-PROX BUTTON

Documents / Resources



[U-PROX Wireless Multifunction Button](#) [pdf] User Manual
Wireless Multifunction Button, Multifunction Button, Button