



**Wrist  
Transformation  
Device with  
Tyranno Core  
Disk**



# Ubuy Wrist Transformation Device with Tyranno Core Disk Instructions

[Home](#) » [ubuy](#) » Ubuy Wrist Transformation Device with Tyranno Core Disk Instructions 

## Contents

- [1 Ubuy Wrist Transformation Device with Tyranno Core Disk](#)
- [2 Product Introduction](#)
- [3 Product Specifications](#)
- [4 Safety Precautions](#)
- [5 Package Contents](#)
- [6 Operating Instructions](#)
- [7 Maintenance](#)
- [8 Warranty Information](#)
- [9 Frequently Asked Questions](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)
- [11 Related Posts](#)



**Ubuy Wrist Transformation Device with Tyranno Core Disk**



**Product Introduction**

Product Overview: The Dino Core DINO TUNER is an interactive wrist device that includes the Tyranno Core Disk, bringing the excitement of the Dino Core series to life.

**Key Features**

- Interactive LCD display
- Sound effects and voice commands
- Removable Tyranno Core Disk
- Adjustable wrist strap
- Role-play transformation features

**Product Specifications**

Power Source	AAA Batteries (2x) – Not included
Display Type	LCD Screen
Audio	Built-in speaker
Material	ABS Plastic
Age Recommendation	5+ years

**Safety Precautions**

**Important Safety Warnings:**

- Not suitable for children under 3 years due to small parts
- Adult supervision required for battery installation
- Do not expose to water or extreme temperatures
- Keep Core Disk clean and free from debris
- Do not attempt to disassemble the unit

## **Battery Information:**

- Requires 2 AAA batteries (not included)
- Do not mix old and new batteries
- Remove batteries if device won't be used for an extended period
- Replace all batteries at the same time

## **Package Contents**

- 1x Dino Tuner wrist device
- 1x Tyranno Core Disk
- 1x Adjustable wrist strap
- 1x Instruction manual
- 1x Character card

## **Operating Instructions**

### **Basic Operation:**

1. Install batteries following polarity indicators
2. Adjust and secure wrist strap
3. Press power button to activate device
4. Insert Tyranno Core Disk when prompted
5. Follow on-screen instructions for transformation sequences

### **Special Features:**

- Press Mode button to cycle through different functions
- Use arrow buttons to navigate menus
- Hold action button for special moves
- Remove and reinsert Core Disk for transformation sequences

## **Maintenance**

### **Care Instructions:**

- Clean with soft, dry cloth only
- Store in a cool, dry place
- Remove batteries if not in use for long periods
- Keep Core Disk slot free from dust and debris
- Regular battery check recommended

## **Warranty Information**

**This product includes a standard manufacturer's warranty:**


- 90-day warranty against manufacturing defects
- Keep original packaging and receipt
- Contact authorized distributor for warranty claims
- The warranty does not cover water damage or misuse

<file:///C:/Users/admin/Downloads/dino-tuner-manual.html>

Frequently Asked Questions

- **Q: Can the wrist strap be adjusted for different wrist sizes?**
  - A: Yes, the wrist strap of the Dino Tuner is adjustable to fit various wrist sizes.
- **Q: Is the Tyranno Core Disk required for all functions of the device?**
  - A: The Tyranno Core Disk is essential for certain transformation sequences and functions of the Dino Tuner.
- **Q: How do I know when to replace the batteries?**
  - A: If you notice a decrease in sound quality or display dimness, \it may be time to replace the batteries.

Documents / Resources

	<p><a href="#">Ubuy Wrist Transformation Device with Tyranno Core Disk</a> [pdf] Instructions  Wrist Transformation Device with Tyranno Core Disk, Transformation Device with Tyranno Core Disk, Device with Tyranno Core Disk, Tyranno Core Disk</p>
--	---

References

- [User Manual](#)

Manuals+. Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.