




UCTRONICS U6178 Upgraded 2U Rackmount for Raspberry Pi 4 Instruction Manual

[Home](#) » [UCTRONICS](#) » UCTRONICS U6178 Upgraded 2U Rackmount for Raspberry Pi 4 Instruction Manual 

UCTRONICS

Assembly Instruction
SKU: U6178



www.uctronics.com


Contents

- [1 PACKING LIST](#)
- [2 EXPLODED VIEW](#)
- [3 STEP](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

PACKING LIST



2U Rackmount×1



Mounting plates for
Raspberry Pi 4B×12



M6*12 Screws×4




M2.5*4 Countersunk Screws ×24



M2.5*4 Screws×48

EXPLODED VIEW




STEP




The Raspberry Pi 4B motherboard is not included.

1. Fixed the Raspberry Pi 4B board with M2.5 screws




2. Inserted the mounting plate from the front of the rackmount



3. Mounted with M2.5 screws.

Documents / Resources



[UCTRONICS U6178 Upgraded 2U Rackmount for Raspberry Pi 4](#) [pdf] Instruction Manual U6178, Upgraded 2U Rackmount for Raspberry Pi 4, Raspberry Pi 4 Rackmount, 2U Rackmount, Upgraded 2U Rackmount