

UGREEN CM662 USB 3.0 Switch 2 Computers Sharing USB C and A Devices User Manual

Home » UGREEN » UGREEN CM662 USB 3.0 Switch 2 Computers Sharing USB C and A Devices User Manual

Contents

- 1 UGREEN CM662 USB 3.0 Switch 2 Computers Sharing USB C and A **Devices**
- 2 Product Overview
- **3 Connection**
- **4 Specifications**
- **5 Package Contents**
- 6 Documents / Resources
 - **6.1 References**
- 7 Related Posts



UGREEN CM662 USB 3.0 Switch 2 Computers Sharing USB C and A Devices



Specifications

Model: CM662P/N: 15705

Input: USB-C 5.0VOutput: USB-A

• Power Supply Input: 2.0A Max

Switching Mode: Button/desktop controller
Compatible Systems: Windows/macOS/Linux

• Dimensions: [Dimensions]

Product Overview

- 1. Signal Switch Button
- 2. USB Signal Indicator
- 3. USB-C Power Port
- 4. USB-A Input Port
- 5. Mini USB Port (for desktop controller)
- 6. USB-C Output Port
- 7. USB-A Output Port

Connection

To use the USB 3.0 Sharing Switch, follow these steps:

- 1. Connect the USB-C power port to a charger or power source.
- 2. Connect your PC, laptop, or desktop controller to the switch using the USB-A input port.
- 3. Connect your mouse, keyboard, USB flash drive, printer, and other USB devices to the USB-A output ports.

Tips

- The LED signal indicator stays on after the product is connected normally.
- Switch signals (USB 1-2) by pressing the switch button or using the desktop controller.

Package Contents

- USB 3.0 Sharing Switch
- Desktop Controller

FAQ

- 1. Q: How many devices can I connect to the USB 3.0 Sharing Switch?
 - A: You can connect up to 4 USB devices to the USB-A output ports.
- 2. Q: Can I switch between USB signals using the desktop controller?

A: Yes, you can switch between USB signals by using either the switch button or the desktop controller.


3. Q: What are the compatible systems for the USB 3.0 Sharing Switch?

A: The USB 3.0 Sharing Switch is compatible with Windows, macOS, and Linux systems.

USB 3.0 Sharing Switch 2 In 4 Out


Model: CM662P/N: 15705

Product Overview



- 1. Signal Switch Button
- 2. USB Signal Indicator
- 3. USB-C Power Port
- 4. USB-A Input Port
- 5. Mini USB Port (for desktop controller)
- 6. USB-C Output Port
- 7. USB-A Output Port

Connection



Tips

- 1. The LED 1 signal indicator stays on after the product is con-nected normally.
- 2. Switch signals (USB 1-2) by pressing the switch button or desktop controller.

Specifications

Input	2×USB-A, 1×Mini USB
Output	3×USB-A, 1×USB-C
USB Standards	USB3.0, supports transfer rate of up to 5Gbps
Power Supply Input	USB-C 5.0V 2.0A Max
Switching Mode	Button/desktop controller
Compatible Systems	Windows/macOS/Linux
Dimensions	L123×W54×H17(mm)/ L4.8×W2.1×H0.7 (inch)

The data are measured by UGREEN lab but may vary based on specific circumstances.

Notes

- Do not throw or drop the product or subject it to strong physical shock.
- Do not dismantle or fix the product by yourself, please con-tact UGREEN after-sales service if necessary.
- Please do not leave the product in extreme temperature or moist environments.
- Please deal with the product following local regulations.
- · Keep out of the reach of children.

Package Contents

- 1 × USB 3.0 Sharing Switch 2 In 4 Out
- 1 × Desktop Controller
- 2 × USB Cables (1.5 m/4.9 ft)
- 1 × User Manual

Documents / Resources

UGREEN

USB 3.0 Sharing Switch 2 In 4 Out

<u>UGREEN CM662 USB 3.0 Switch 2 Computers Sharing USB C and A Devices</u> [pdf] User M anual

UserManua

CM662, 15705, CM662 USB 3.0 Switch 2 Computers Sharing USB C and A Devices, USB 3.0 Switch 2 Computers Sharing USB C and A Devices, 3.0 Switch 2 Computers Sharing USB C and A Devices, 2 Computers Sharing USB C and A Devices, Sharing USB C and A Devices, USB C and A Devices

References

• User Manual

Manuals+, Privacy Policy