



ULINE Manual Tape Dispenser with Heater User Manual

[Home](#) » [ULINE](#) » ULINE Manual Tape Dispenser with Heater User Manual



Contents [[hide](#)]

[1 H-1359](#)

[1.1 MANUAL TAPE DISPENSER WITH
HEATER](#)

[2 Documents / Resources](#)


[3 Related Posts](#)

H-1359

MANUAL TAPE DISPENSER WITH HEATER

1-800-295-5510

uline.com




#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
1	Top Cover Assembly	1	H-1358-TPCVR	RP40310
2	Top Cover Hinge with Screw Includes: · Hinge (2) · Nut (2) · Screw (2)	1	H-1360-40311	RP40311
3	Water Bottle with Valve Includes: · Bottle (1) · Duckbill Valve (1) · Tank (1)	1	H-1358WB	RP40401
4	Brush Tank	1	H-1358-BRTNK	RP40405

5	Moistening Brush	1	H-1358B	RP40407
6	Right Side Cover Assembly Includes: · Side Cover (1) · Screw (6) · Hole Plug (1) · Stop Assembly (1)	1	H-1359-SDCVR	RP41301H
7	Power Switch	1	H-1359-PWRSW	RP150536
8	Handle Includes: · Handle Arm (1) · Handle (1) · Handle Insert (1) · Washer (1) · Screw (1) · Nut (1)	1	H-1358-HNDL	RP41257
9	Handle Hole Plug	1	—	RP43102

	Inch Measuring Strip (Not Shown)	1	_____	RP41260
	Metric Measuring Strip (Not Shown)	1	_____	RP41262
	Stop Bolt (Not Shown)	1	H-1358-KNOB	RP41290

PAGE 2 OF 27




PAGE 3 OF 27

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
1	Ramp	1	_____	RP40315

2	Pressure Plate	1	H-1358-PLATE	RP40505
3	Top and Free Roller Assembly Includes: · Roller (1) · E-Clip (2) · Side Cover (1)	1	—	RP40522
4	Left Side Cover	1	H-1358-LCVR	RP-40305
5	Rear Water Bottle Bracket	1	H-1358-WBBKT	RP40404
6	Front Water Bottle Bracket	1	H-1358WBB	RP40403
7	Cutter Guard	1	H-1358-CUTTR	RP40325

8	Pinch Roll Assembly Includes: · Pin (1) · Spring (2) · E-Clip (6) · Shaft (1) · Holder (1) · Roll (1)	1	H-1358-40540	RP40540
9	Cutter Return Spring Assembly Includes: · Spring (1) · Damper (1) · Screw (1) · Nut (2) · S-Hook (1)	1	H-1358-SPRIN	RP41905
10	10 Cutter Slide Bolt	1	H-1358-41904	RP41904
	Fixed Blade Stop (Not Shown)	1	—	RP40825



PAGE 5 OF 27


#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
1	Foot Channel	1	—	RP40110
2	Rubber Foot	1	—	RP40115
3	Tape Channel Plate	1	H-1358-TCP	RP40515
4	Tape Guide Assembly Includes: · Turnbuckle (1) · Guide RHS (1) · Guide LHS (1)	1	—	RP40550

5	90° Strain Relief	1	_____	RP42956
6	Dome Plug	1	_____	RP42957
7	SPlit Bushing	1	_____	RP42958
8	Urethane Feed Wheel w / Shaft	1	H-1360-40235	RP40235
9	Gearbox Motor Mount Frame	1	_____	RP41101
10	Drive Gear With Springs Includes: · Drive Gear (1) · Spring (1)	1	H-1359-GEAR	RP5065X
11	Clutch Roller Assembly Includes: · Clutch (1) · Pin (1)	1	H-362-CLUTCH	RP5063X

12	Brush Tank Cover with Rod & Bushing Includes: · Weighted Tank Cover (1) · Screw (2) · Brass Bushing (1) · Rod (1)	1	H-1360-BTCRB	RP40516
13	Tape Weight with Screw Includes: · Weighted Tank Cover (1) · Screw (1) · Pin (1)	1	H-1358-TPWGT	RP40517
14	3/8 Bearing	1	—	RP40231
15	1/2 Bearing	1	—	RP41221
16	Dead Roller	1	H-1360-40560	RP40560

17	Handle Shaft Assembly Includes: · Shaft (1) · Screw (4) · E-Clip (1)	1	H-1358-41220	RP41220
18	Washer	1	—	RP16172

PAGE 6 OF 27



PAGE 7 OF 27

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
---	-------------	------	----------------	---------------

1	Tape Basket/Motor Cover	1	—	RP40320
2	Cover Actuating Arm Assembly Includes: · Arm (2) · Spring (2) · E-Clip (6) · Shaft (1) · Screw #16 (2) · Nut (2)	1	H-1358-41258	RP41258


3	Cutter Replacement Arm Includes: · Cutter Blade Holder (1) · Cutter Blade Movable (1) · Fixed Blade (1) · Spring (4) · Fixed Blade Shoe (1) · Set Screw (1) · Screw (4) · Bushing (4) · Cutter Guide (2)	1	H-1360-BLREP	RP40703
4	Cutter Blade Movable Includes: · Cutter Blade Movable (1) · Screw (2) · Set Screw (1)	1	H-1358-BLADE	RP40710

5	Cutter Blade Fixed Includes: · Fixed Blade (1) · Spring (4) · Fixed Blade Shoe (1) · Screws (2)	1	H-1358-FIXED	RP40715
6	Cutter Spring Fixed Blade	1	H-1360-40740	RP40740

7	Heater/Thermostat Assembly 110V Includes: · Water Tank Holder (1) · Thermostat 110V (1) · Screw (9) · Nut (2) · Heater 110V (1) · Wire (1) · Wire Connection (4)	1	H-1360-42978	RP42978
7	Heater/Thermostat Assembly 200V Includes: · Water Tank Holder (1) · Thermostat 110V (1) · Screw (9) · Nut (2) · Heater 110V (1) · Wire (1) · Wire Connection (4)	1	—	RP42810

#	DESCRIPTION	QTY.	ULINE PART NO.	MFG. PART NO.
8	Thermostat Assembly 1 10V Includes: · Thermostat 110V (1) · Screw (2) · Nut (2) · Wire #16 (1) · Wire Connection (1)	1	—	RP43977
9	3/8 Bearing	1	—	RP40231
10	1/2 Bearing	1	—	RP41221
11	Cutter Guard Clip	1	H-1360-40236	RP40236
12	Stop Bolt and Nut	1	H-1358-KNOB	RP41290
13	Water Tank Holder	1	H-1358-40352	RP40352

Documents / Resources

	ULINE Manual Tape Dispenser with Heater [pdf] User Manual Manual Tape Dispenser with Heater, H-1359
---	--