




ULINE Platform Dial Scale H-8540 User Manual

[Home](#) » [ULINE](#) » ULINE Platform Dial Scale H-8540 User Manual 

Contents

- [1 ULINE Platform Dial Scale H-8540](#)
- [2 OPERATION](#)
- [3 SPECIFICATIONS](#)
- [4 CALIBRATION](#)
- [5 INSTRUCTIONS](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)





OPERATION

NOTE: Before using the scale, remove the wood pieces taped to both posts on top of the scale. There is a one-year warranty for parts and labor on the scale.

SPECIFICATIONS

- H-176: 13 x 13 x 14³/₄"
- H-177: 10¹/₄ x 10¹/₄ x 10³/₄"
- Weight measured in ounces and pounds

CALIBRATION

Turn calibration knob clockwise or counterclockwise until arrow aligns to zero.

INSTRUCTIONS


1. Calibrate scale.
2. Place item to be weighed on scale platform.
3. View scale head on to get an accurate reading.

1-800-295-5510

uline.com



Documents / Resources

	ULINE Platform Dial Scale H-8540 [pdf] User Manual ULINE, Platform Dial Scale, H-8540
---	---