

ULINE Tip and Roll Kit For 3-Row Bleachers H-4755 User Guide


[Home](#) » [ULINE](#) » ULINE Tip and Roll Kit For 3-Row Bleachers H-4755 User Guide 

ULINE Tip and Roll Kit For 3-Row

Bleachers H-4755 User Guide

ULINE H-4755
TIP AND ROLL KIT FOR
3-ROW BLEACHERS

1-800-295-5510
uline.com



uline.com




WARNING! Due to outdoor wind hazards, bleachers with tip and roll kits, while suitable for indoor or outdoor use, should only be tipped up onto the casters when indoors in order to prevent them from tipping back over unintentionally.


Contents

- [1 TOOLS NEEDED](#)
- [2 PARTS](#)
- [3 ASSEMBLY](#)
- [4 Documents / Resources](#)
- [5 Related Posts](#)

TOOLS NEEDED



Electric Drill
with Flathead Bit



Socket Wrench



1/2" Deep Well
Socket



9/16" Deep Well
Socket

PARTS



Screw x 12



Washer x 12



5/16" Flange Nut x 12




3/8" Flange Nut x 4



5" Swivel Caster x 2




5" Swivel Caster with Brake x 2




Rubber Foot Pad x 12

ASSEMBLY


1a. Each of the three bleacher frames has four predrilled holes along the bottom. (See Figure 1)



1b. Attach four rubber foot pads to the predrilled holes using a screw, washer and 5/16" flange nut. (See Figure 2)



2a. Each of the three bleacher frames has two predrilled holes along the back. (See Figure 3)




2b. Insert the casters into the predrilled holes and attach using 3/8" flange nuts. (See Figure 4)




NOTE: Casters with brakes go on the bottom holes.



NOTE: Casters go on the outside frames only. There are no casters on the middle frame.



	<p>ULINE Tip and Roll Kit For 3-Row Bleachers H-4755 [pdf] User Guide</p> <p>Tip and Roll Kit For 3-Row Bleachers, H-4755</p>
---	---