

# UltraPro 57056 Wi-Fi Add-on Switch User Manual

Home » UltraPro » UltraPro 57056 Wi-Fi Add-on Switch User Manual



Wi-Fi Add-on Switch Users Manual

This Wi-Fi add-on switch allows you to control power to a connected series of compatible lighting fixtures. The entire connected series of lights can be turned ON/OFF with this single module.



IMPORTANT: BEFORE INSTALLING, READ ALL SAFETY INSTRUCTIONS LISTED AT THE END OF THIS MANUAL.

See reverse for easy-to-follow instructions and exclusive deals.

Thank you for your purchase!

Exclusive deals

Instructions made easy



Read instructions or watch the easy-to-follow video. Scan code or visit <a href="byjasco.com/57056">byjasco.com/57056</a>i



For deals, to register your purcha he code or visit <a href="byjasco.com/de">byjasco.com/de</a>



Home automation is in your palm with Wi-Fi smart devices and accessories at byjasco.com/ultrapro



Like our product? Leave a review on your favorite retailer website or <a href="mailto:amazon.com">amazon.com</a>

Having problems? Let us know how we can help. Call 1-800-654-8483 between 7 AM-8 PM, M-F, Central Time.

# **Contents**

- 1 INSTALLATION
- **2 OPERATION**
- **3 FCC STATEMENT:**
- 4 Documents /


Resources

**5 Related Posts** 

## **INSTALLATION**


# STEP 1: CHOOSE TO INSTALL LOCATION

This installation will use the power and linking cords included with your UltraPro light fixture. Make sure that the 5ft. power cord will reach the nearest outlet, and that the linking cord will reach the nearest light fixture. The mounting location should be indoors, dry and able to support the module.




# **STEP 2: MARK SCREW LOCATIONS**

With a pencil, mark the screw locations using the keyholes on either end of the module for guidance.




# **STEP 3: PRE-DRILL HOLES**

Pre-drill holes for the screws using the pencil marks for guidance. Use a 1/16in. drill bit for softwoods and a 3/32in. drill bit for hardwoods.




# **STEP 4: INSERT SCREWS**

Insert the screws (included) with a #1 Phillips screwdriver, leaving 1/8in. beyond the surface.




# **STEP 5: MOUNT SWITCH**

Align the keyholes on the module with the screws to secure it into place. Fasten the screws as needed using only the screwdriver.



## STEP 6: CONNECT WITH A LIGHT FIXTURE

Insert the 2-pin connector of the linking cord (included with the light fixture) into the 2-pin connector on the module. Insert the 3-pin connector of the linking cord into the 3-pin connector of the first light fixture. **NOTE:** Other linking cord lengths are available at byjasco.com.



## STEP 7: PLUG INTO OUTLET

Insert the 3-pin connector of the power cord into the 3-pin connector on the module. Plug the power cord into a 120VAC 60Hz outlet.

# **OPERATION**

Remotely operate your Wi-Fi add-on switch with the easy-to-use UltraPro app. Follow the in-app instructions and available resources to set up your smart device. Download the app






# https://byjasco.com/ultrapro-wifi-app/

Scan the QR code above or search UltraPro on the Apple App Store or on Google Play.







Create an account in the UltraPro app

Follow the on-screen instructions to add devices, create schedules and control the smart switch from anywhere **3 Pair the Switch** 



- 1. Manually turn every light fixture in the sequence ON.
- 2. Follow the on-screen instructions to add the module.

The indicator light on the module will flash while it is searching for the network, and will turn solid when connected to the app.

You will now be able to operate the lights while using the app.

- DO NOT INSTALL THE SWITCH WHILE PLUGGED IN OR WITH PLUGGED-IN LIGHTING FIXTURES.
- DO NOT ALTER THE CONNECTORS IN ANY WAY.
- SAVE THESE INSTRUCTIONS FOR FUTURE USE.

# 4. voice control

Compatible with Amazon Alexa and Google Assistant







Follow the steps in the Amazon Alexa or Google Assistant app to connect the UltraPro app, or select "Support" in the UltraPro app.

**ELECTRICAL RATINGS: WI-FI MODULE** 

LINE VOLTAGE: 120V MAXIMUM CURRENT: 0.4A MAXIMUM WATTAGE: 48W

DO NOT EXCEED THE MAXIMUM ELECTRICAL RATINGS LISTED ABOVE. TO MAKE SURE YOUR INSTALLATION WILL NOT EXCEED RATINGS, ADD THE CURRENT (A) OR WATTAGE (W) RATING FOR ALL LIGHT FIXTURES THAT WILL BE CONNECTED TO THE SWITCH. THE TOTAL SUM OF THE CURRENT OR WATTAGE FOR ALL CONNECTED LIGHT FIXTURES CAN NOT EXCEED THE MAXIMUM LISTED ABOVE FOR THE TYPE OF MODULE BEING INSTALLED.

#### **FCC STATEMENT:**

Suppliers Declaration of Conformity

Model #: 57056 Jasco Products Co.,

10 E. Memorial Rd., Oklahoma City, OK 73114,

# www.byjasco.com

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**FCC NOTE:** The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

# WARNING RISK OF ELECTRIC SHOCK

- · DO NOT USE IN WET LOCATIONS.
- · USE INDOORS ONLY.

- USE ONLY INSULATED STAPLES OR PLASTIC TIES TO SECURE THE CORDS.
- ROUTE AND SECURE THE CORDS SO THAT THEY WILL NOT BE PINCHED OR DAMAGED.
- NO SERVICEABLE PARTS.

#### **RISK OF FIRE**

- DO NOT EXCEED ELECTRICAL RATING
- USE ONLY WITH BRIGHT LINK-COMPATIBLE LIGHTING FIXTURES.
- NOT INTENDED FOR USE ABOVE STOVES, COOKTOPS, SINKS, OR OTHER HEAT-PRODUCING APPLIANCES, SUCH AS COFFEE MAKERS, TOASTERS, OR TOASTER OVENS.
- NOT INTENDED FOR RECESSED INSTALLATION IN CEILINGS OR SOFFITS.
- DO NOT CONCEAL POWER SUPPLY CORDS OR LINK CORDS INSIDE A WALL, CEILING, SOFFIT, KITCHEN CABINET, OR SIMILAR PERMANENT STRUCTURE.
- DO NOT RUN POWER SUPPLY CORDS OR LINK CORDS THROUGH HOLES IN WALLS, CEILINGS, OR FLOORS.

App Store is a service mark of Apple Inc. Google and Google Play are trademarks of Google LLC.

#### **MADE IN CHINA**

Distributed by Jasco Products Company LLC, 10
E. Memorial Rd., Oklahoma City, OK 73114.
This Jasco product comes with a two-year limited warranty.
Visit <a href="https://www.byjasco.com">www.byjasco.com</a> for warranty details.
Questions? Contact our U.S.-based
Consumer Care at 1-800-654-8483 between 7 AM-8 PM, M-F, Central Time.
57056 v2 06/21





#### **Documents / Resources**



<u>UltraPro 57056 Wi-Fi Add-on Switch</u> [pdf] User Manual 57056, Wi-Fi Add-on Switch, 57056 Wi-Fi Add-on Switch, Switch

Manuals+