



UMAX UB913 U-Smart Motion Sensor User Guide

[Home](#) » [UMAX](#) » UMAX UB913 U-Smart Motion Sensor User Guide 




Contents

- [1 U-SmartMotion Sensor](#)
- [2 U-Smart • Android & iOS](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)


U-Smart Motion Sensor

U-Smart • Android & iOS

Create an account.



Click on +. Click on **U-Smart Motion Sensor**.




The sensor can be powered by batteries or by USB.

Battery power: Turn the back case counter-clockwise and insert two AAA batteries.

USB power: Plug microUSB cable into the port on the sensor and plug the cable to a phone charger (5V 2A).



Follow the instructions in the application to connect in **EZ mode** or **AP mode**. The WiFi network to which you want to connect the sensor must be of the **2.4 GHz** type, 5 GHz networks are not supported. WiFi password cannot contain special characters ~!@#\$\$%^&*()



1. Information about the sensor
2. Motion detection records
3. Automation
4. Battery and notifications

Battery: 2x AAA 1.5V, WiFi: 802.11 b/g/n 2.4GHz, Operating temperature: -10°C to 50°C, Operating humidity: under 95%

Manufacturer
Umax Czech a.s.,
Kolbenova 962/27e,
198 00 Prague 9,
Czech Republic

Technical support and service center

+420 800 118 629 servis@umax.cz

Umax Czech a.s., Kolbenova 962/27e, 198 00 Prague 9, Czech Republic



www.umax.cz

Umax.cz

UMAX Czech Republic

UMAX Czech



Importer hereby declares that this wireless device is in compliance with the essential requirements and other relevant provisions of the R&TTE Directive and Radio Equipment Directive 2014/53/EU, as applicable. A copy of the EU Declaration of Conformity is available at www.umax.cz.



Do not dispose of electrical appliances as unsorted municipal waste, use separate collection facilities. Contact your local authority for information regarding the collection systems available. If electrical appliances are disposed of in landfills or dumps, hazardous substances can leak into the groundwater and get into the food chain, damaging your health and well-being. Please contact your local or regional waste authority for more information on collection, reuse and recycling programs.

© 2021 Umax Czech a.s. All rights reserved. Umax and the Umax logo are trademarks of Umax Czech a.s. Apple and the Apple logo are trademarks of Apple Inc. Google Play and the Google Play logo are trademarks of Google LLC. All other trademarks and trade names are those of their respective owners.



Documents / Resources



[UMAX UB913 U-Smart Motion Sensor](#) [pdf] User Guide

UB913, U-Smart Motion Sensor, UB913 U-Smart Motion Sensor, Motion Sensor