

uni HDF01 USB C HDMI Adapter User Manual

Contents

- [1 HDF01 USB C HDMI Adapter](#)
- [2 Product Information](#)
 - [2.1 Compatible List \(incomplete list\)](#)
 - [2.2 Non-Compatible List \(incomplete list\)](#)
 - [2.3 Documents / Resources](#)
 - [2.3.1 References](#)
 - [2.4 Related Posts](#)

HDF01 USB C HDMI Adapter

Product Information

The product is a video adapter designed to connect your device to a monitor or TV. It supports video transmitting and requires devices with compatible ports and video capabilities. The adapter is not compatible with certain devices, hubs, docks, and gaming consoles such as Nintendo Switch. It does not support charging and is intended for video transmission only. The product comes with an 18-month warranty.

Compatible List (incomplete list)

Apple: MacBook Pro (After 2016); MacBook Air (After 2018); MacBook (After 2015); Mac Mini (After 2018); iPad Pro; iMac (dopo il 2017); iMac Pro; iPad Air 2020/ 2019
Microsoft: Surface Laptop 4/3; Surface Go / Go 2; Surface Pro 7; Surface Book 3/2
Dell: Dell Latitude 7373/5570/5490/5400 (2019); XPS 13/15; Precision 15"/ 17"
Lenovo: Think Pad 13/ X1/ T490; Yoga C940/C740/910; Yoga 720 (13KB); Yoga 900 13 (80 MK); Idea pad S940 / S740
Samsung: Galaxy TabPro S / Tab S7/ S6/ S5/ S4
ASUS: Zenbook S UX391 / Flip 13 UX362, Classic-Serie
HP: ENVY 13/17/ X360, EliteBook x360 / 1030/1040/ Elite Dragonfly, Spectre X360 15/13; Folio 13, Pavilion X360 15, Chromebook X360
Google: Chromebook Pixel (2015) / Pixelbook / Pixel Slate
Huawei: Matebook X / X Pro / E / Pro, MateBook 13/14
Razer: BladeStealth
Samsung: 21/S20/ S20+/ S20 Ultra/ S10e/ S10/ S10+/ S9/ S9+/ S8/ S8+; Note 20/10/10+/9/8
Huawei: P40 / P40 Pro / Mate 40 / Mate 40 Pro / P30 / P30 Pro / Mate 30 / Mate 30 Pro / P20 / P20 Pro / Mate 20 / Mate 20 Pro / Mate 20 X / Mate 10 / Mate 10 Pro
HTC: 10 / U11 / U11 + / U12 + / U19e

OnePlus: 9/ 9 Pro/ 8/ 8Pro / 7/7 Pro
Lumia: 950/950 XL
LG: G5/G6, LG V20
OPPO: R17 Pro
Razer: Razer Phone / Razer Phone 2

Non-Compatible List (incomplete list)

MacBook Air 7.2
Lenovo: Ideapad 320 / Ideapad S340 / Ideapad D330 /
Ideapad due, Yoga 530
Asus: ZenBook 13 /14
Apple: All Lightning iPad
Samsung: Galaxy Tab3 / tab S3 / Tab A / Tab A 10.1 (T510)/
tab A 10.5 2018 / Tab S6 Lite, M20 / M30s / J6 / XCover 4s
Lenovo: Tab M10 /M10 Plus / TAB 4 PLUS TB-X704F / TAB 4 Plus /
TAB P10, Yoga Tab 3 Plus
Huawei: MediaPad T5 / M5 / M5 Lite / M3 / dtab d-01K / dtab d-02H
Samsung: Samsung A Series, A21 SC-42A / A30 /A30 au (SCV43)
/ A32 / Galaxy A41 docomo (SC-41A) / A51 5G SC-54A / M20 / M30s
/ J6 / XCover 4s, Galaxy S6 / S7 / Note 8 (SC-01K) / Note 8 (SM-N9500)
Galaxy Feel2 SC-02L / J7 / J7 star
SONY: Xperia 5 (SOV41)/ 5 901SO/ 5 SOG02/ 8 (SOV42)/ 10
/ 10 plus/ 10 II/ 10 II SO-41, Xperia Ace(SO-02L) / A SO-04E/ XA1/XA2,
Xperia XZ series/ Compact series, Xperia L1/L2/L3
Huawei: P9 / P10 / P10 Lite /P20 Lite / P30 Lite / P Smart Z
/ P30 Pro HW-02L, Mate 9 / Mate 20 Lite, Honor 10 / 10 Lite / 9 / 9X
/ Magic 2, HUAWEI Nova Series
Xiaomi: Mi 8 / Mi 9 / Mi 9T / Mi A3 / Mi Max 3 / Mi Note 10 Pro,
pocophone F1, Redmi Note 7 / Redmi Note 8 Pro / Note 9s
Nintendo Switch, Go Pro, Amazon Fire Tablet
Oneplus: 2 / 3T / 5 / 5T/ 6 / 6T
LG: Stylo / L-01L docomo / V30+ L-01K
Google: Pixel 2 / 3 / 3XL / 4a-5G / 5All Aquos phone (except R5G)

Documents / Resources

	uni HDF01 USB C HDMI Adapter [pdf] User Manual HDF01, HDF01 USB C HDMI Adapter, USB C HDMI Adapter, HDMI Adapter, Adapter
---	--

References

- [User Manual](#)