



**PFT1 Series LED and  
TFD Monitors Plasma  
and Projectors**



# UNICOL PFT1 Series LED and TFD Monitors Plasma and Projectors Instruction Manual

[Home](#) » [UNICOL](#) » UNICOL PFT1 Series LED and TFD Monitors Plasma and Projectors Instruction Manual 

## Contents

- [1 UNICOL PFT1 Series LED and TFD Monitors Plasma and Projectors](#)
- [2 Product Information](#)
- [3 FAQ](#)
- [4 Overview](#)
- [5 COMPONENTS](#)
- [6 Installation Instructions](#)
- [7 CONTACT](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)



**UNICOL PFT1 Series LED and TFD Monitors Plasma and Projectors**



## Product Information

### Specifications



- **Product Models:** PFT1, PFT3, PFT4, PFT9, PFT21
- **Screen Size:** 33-110 inches
- **Maximum Weight Capacity:** 120kg

### FAQ

- **Q:** How much weight can the product support?
- **A:** The product has a maximum weight capacity of 120 kg. Please check model-specific details before installation.
- **Q:** What tools are required for installation?
- **A:** You will need a 5mm Allen Key, PozidriveScrewdriver, and a 17mm Spanner or Socket.

### Overview

- PFT1 / PFT3 / PFT4 / PFT9 / PFT21



- Screen Size: 33-110"
- Guide Max. Weight: 120kg

Please check model-specific details before installing\*

## WARNING

- Please carefully inspect the product before assembling it.
- If you notice any apparent damage, call your carrier claims agent and do not continue the installation until it has been reviewed. Please watch for pinch points.
- Do not put your fingers between moveable parts.
- Do not tamper with or disassemble any spring-loaded parts.
- Before installing, make sure that the supporting surface will support five times the combined load of the solution and the hardware.
- Never exceed the maximum load capacity.
- Please also lay out all components to ensure that you have all of the required parts before proceeding (see the BOM list on the following page).
- Use of this product for anything other than its specified use may result in failure or personal injury.
- This product is intended for indoor use only. We recommend using a qualified tradesperson for installation.
- Use an assistant or lifting equipment to lift and position products.
- For support, please call: +44 (0)1865 767676 or email: [sales@unicol.com](mailto:sales@unicol.com)

#	TOOLS REQUIRED
1	5mm Allen Key
2	Pozidrive Screwdriver
3	17mm Spanner / Socket


INSTALLERS REQUIRED

- 1-2


COMPONENTS



2



3



1




4

#	DESCRIPTION	QTY
1	Base	1
2	Mast	1
3	Screen Mount Backplate	1
4	Screen Mount Arms	2

## Installation Instructions


### STEP 1

- Identify the base and place it on a solid surface.



### STEP 2


- Fit mast to the base using the 4 x M8 x 20 dome head allen screws provided. Screw into the mast from under the base.



### STEP 3


- Fit the screen mount backplate to the mast using the 4 x M10 x 25 hex screws provided.

- The height position of the screen is dependent on which holes are used in the mast. Remember to leave enough room for the screen to fit above the base.
- There is also height adjustment on the screen mount arms if further adjustment is required.




#### STEP 4

- Utilising the grip locks (top), tag locks (bottom), and fixing pack provided with your mount, attach the arms to the back of your screen.
- Ensure the arms are the correct way up before tightening – the 'hook' part of the arm should be at the top.




#### STEP 5

- Dependent on screen size and weight, with the help of another, lift the screen with the top tilted forward and place the hook part of the arms onto the top rail of the backplate. Allow the screen arms to rest on the backplate vertically. While still holding the screen position it centrally on the top rail by sliding it side to side.




## STEP 6

- The bottom of the screen is secured by screwing the bottom arm positive screws so they impinge on the bottom rail of the backplate (do not fully tighten yet).
- There is a small amount of adjustment to level the screen by tightening or loosening one or both top arm screws. Once level tighten all arm screws.



## STEP 7

- Cable up and carry out functional tests to complete installation.




## CONTACT

- 01865 767676
- [sales@unicol.com](mailto:sales@unicol.com)
- [www.unicol.com](http://www.unicol.com)



## Documents / Resources



[UNICOL PFT1 Series LED and TFD Monitors Plasma and Projectors](#) [pdf] Instruction Manual

PFT1, PFT3, PFT4, PFT9, PFT21, PFT1 Series LED and TFD Monitors Plasma and Projectors, PFT1 Series, LED and TFD Monitors Plasma and Projectors, Monitors Plasma and Projectors, Plasma and Projectors, Projectors

## References

- [User Manual](#)

### Manuals+ Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.