




# UNICOL WB2 Multi Purpose Wall Bracket Installation Guide

[Home](#) » [UNICOL](#) » UNICOL WB2 Multi Purpose Wall Bracket Installation Guide 

UNICOL WB2 Multi Purpose Wall Bracket




## Contents


- [1 Other Models](#)
- [2 COMPONENTS](#)
- [3 Installation Instructions](#)
- [4 Customer Support](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)

## Other Models


WB0




WBO2



WB1



**WB**



**Guide Max. Weight:** 60kg

Please check model specific details before installing

## **WARNING**


Please carefully inspect the product before assembling. If you notice any apparent damage, call your carrier claims agent and do not continue the installation until it has been reviewed. Please watch for pinch points. Do not put your fingers between moveable parts. Do not tamper with or disassemble any spring loaded parts. Before installing, make sure that the supporting surface will support five times the combined load of the solution and the hardware. Never exceed the maximum load capacity. Please also layout all components to ensure that you have all of the required parts before proceeding (see BOM list on following page). Use of this product for anything other

than its specified use may result in failure or personal injury. This product is intended for indoor use only. We recommend using a qualified trades person for installation. Use an assistant or lifting equipment to lift and position products.


#	TOOLS REQUIRED
1	3/16th Allen Key
2	Pozidrive Screwdriver
3	
4	
5	

INSTALLERS REQUIRED
1-2


COMPONENTS




#	DESCRIPTION	QTY
1	WB0 – Peg Version	1



#	DESCRIPTION	QTY
1	WB02 – Socket Version	1



#	DESCRIPTION	QTY
1	WB1 – Peg Version	1



#	DESCRIPTION	QTY
1	WB2 – Socket Version	1

#	OPTIONAL EQUIPMENT	QTY
1	Projector Suspension Unit – PS U	1
1	Screen Mount Adapter – (PS1 s hown)	1


#	OPTIONAL EQUIPMENT	QTY
1	Column	
1	Projector Suspension Unit – PSU	
1	Screen Mount Adapter – (PS1 shown)	

Installation Instructions

WB, 0, 02, 1 & 2 Wall Fixing

STEP 1 – (WB, 0, 02, 1 & 2)

Determine where you want to install your wall arm. Mark and fix into position through the six fixing holes using suitable anchors & screws. Please consider cabling and wall fixings prior to installation. Please check surface is capable of supporting 5x the combined solutions weight.




## **WB, 0 & 1 – Adding PSU**

### **STEP 2 – (WB, 0 & 1)**

Unscrew Through-Bolt located on the socket of the PSU. Locate socket onto the Peg of the Wall Arm and push upwards. Refit Through-Bolt ensuring it locates through the peg of the Wall Arm.

**Typical PSU shown**




### **WB, 0 & 1 – Adding Screen Mount Adapter**

#### **STEP 3 – (WB, 0 & 1 )**

Unscrew Through-Bolt located on the socket of the Screen Mount Adapter. Locate socket onto the Peg of the Wall Arm and push upwards. Refit Through-Bolt ensuring it locates through the peg of the Wall Arm.


**Typical Screen Mount Adapter PS1 shown**





#### **STEP 4 – (WB, 0 & 1 )**

Fully tighten Through-Bolts. Take up any slack using grub screws in sockets. Cable along wall arm & apertures in Screen Mount Adapter & PSU sockets. Follow PZX/W, PLX/W Instructions to fit Screen. Follow PSU Instructions to fit Projector.




## **WB, 02 & 2 – Adding PSU & Column**

### **STEP 1 – (WB, 02 & 2)**


Unscrew Through-Bolts located on the sockets of the Wall Arm and PSU. Place column onto the Peg of the Wall Arm and push upwards. Refit Through-Bolt ensuring it locates through the peg of the Wall Arm. Repeat this operation to join the PSU to the other end of the column.

**Typical PSU shown**



**STEP 2 – (WB, 02 & 2)**

Fully tighten both Through-Bolts. Take up any slack using grub screws in socket. Cable through column and apertures in Wall Arm & PSU sockets. Follow PSU Instructions to fit Projector.




## **WB, 02 & 2 – Adding Screen Mount Adapter & Column**

### **STEP 1 – (WB, 02 & 2)**


Unscrew Through-Bolts located on the sockets of the Wall Arm and Screen Mount Adapter. Place column onto the Peg of the Wall Arm and push upwards. Refit Through-Bolt ensuring it locates through the peg of the Wall Arm. Repeat this operation to join the Screen Mount Adapter to the other end of the column.

**Typical Screen Mount Adapter PS1 shown**



**STEP 2 – (WB, 02 & 2)**

Fully tighten both Through-Bolts. Take up any slack using grub screws in socket. Cable through column and apertures in Wall Arm & Screen Mount Adapter sockets. Follow PZX/W, PLX/W Instructions to fit Screen.




Customer Support

01865 767676  
[sales@unicol.com](mailto:sales@unicol.com)  
[www.unicol.com](http://www.unicol.com)



---

## Documents / Resources

	<p><a href="#">UNICOL WB2 Multi Purpose Wall Bracket</a> [pdf] Installation Guide WB2, WB2 Multi Purpose Wall Bracket, Multi Purpose Wall Bracket, Purpose Wall Bracket, Wall Bracket, Bracket</p>
---	--

## References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.