




UniFi G2 Access Reader Installation Guide

[Home](#) » [Unifi](#) » UniFi G2 Access Reader Installation Guide 



G2 Access Reader Installation Guide



Contents

1 G2 Access Reader


2 Documents /
Resources

2.1 References


G2 Access Reader




1



b








1









4



















Internet



UniFi OS


Console



Switch



PoE++




Download
App



n

1 

2 





If you need further assistance, visit our [Help Center](#) or contact [Ubiquiti Support](#).


©2022 Ubiquiti Inc. All rights reserved. Ubiquiti, Ubiquiti Networks, the Ubiquiti U logo, Unifi, and Unifi Connect are trademarks or registered trademarks of Ubiquiti Inc. in the United States and in other countries.



App Store and the Apple logo are trademarks of Apple Inc., registered in the U.S. and other countries.

Google Play and the Google Play logo are trademarks of Google LLC.

All other trademarks are the property of their respective owners.

Documents / Resources





[UniFi G2 Access Reader](#) [pdf] Installation Guide
G2, G2 Access Reader, Access Reader, Reader



- [!\[\]\(27c3f183a8911a7dac26d53c513f13df_img.jpg\) Ubiquiti Account](#)