



unitech HT730 UHF RFID Rugged Handheld Terminal User Guide

[Home](#) » [unitech](#) » unitech HT730 UHF RFID Rugged Handheld Terminal User Guide 

Contents

- [1 unitech HT730 UHF RFID Rugged Handheld Terminal](#)
- [2 Package](#)
- [3 Product View](#)
- [4 Inserting Micro SD Card](#)
- [5 Install/Remove the Protective Cover](#)
- [6 Charging the Battery](#)
- [7 Install the Battery](#)
- [8 Checking LED Status](#)
- [9 Remove the Battery](#)
- [10 Attach the Hand Strap](#)
- [11 Documents / Resources](#)
 - [11.1 References](#)
- [12 Related Posts](#)



unitech HT730 UHF RFID Rugged Handheld Terminal



Package

Please make sure the following contents are in the HT730 UHF RFID rugged handheld terminal gift box. If something is missing or damaged, please contact your unitech representative.

The Package Contents

- 6700mAh Battery
- Hand Strap
- Protective Cover
- Battery Cover

Optional Accessories

- USB 3.0 Type-C Cable
- Power Adaptor
- 1-Slot / 4-Slot Charging Cradle
- 1-Slot USB Cradle
- -Slot / 4-Slot Ethernet Cradle
- 4-Slot Battery Charger
- 3-Pin Power Cord
- Glass Screen Protector

Product View




1. Receiver
2. Power Key
3. Battery Lock
4. SD Card Slot
5. Scanner Window
6. RFID Reader Antenna
7. Scanner Trigger Key
8. LED Indicator
9. Hand Strap Hole
10. USB Type-C Port
11. POGO Pin


Inserting Micro SD Card

Micro SD Card Slot:


1. Push up SD card holder to unlock.



2. Flip the card holder open to insert SD card.



3. Close the card holder and slide down to lock position. Ensure that it is installed properly.



Install/Remove the Protective Cover

- To install the protective cover, snap its hooks into the grooves below the gun grip (optional).
- Grab and pull out the protective cover to remove it.

Charging the Battery

For regular use, you can charge the terminal for 5 hours to recharge the battery to full capacity. Charging the terminal with USB Type-C cable: Connect the USB Type-C cable to the USB port on HT730, and connect the other end of the USB cable to AC power adapter, then plug into the electrical outlet.

Note: It is highly recommended to use the Unitech USB Type-C cable and AC power adapter to charge the terminal.

Install the Battery

1. Make sure the battery lock is in the unlock position.



2. Align and insert the battery from the top side. Press down and make sure to leave half of the battery strap outside.



3. Align the hooks on the battery cover with the battery compartment, then press down the battery cover.



4. Push the battery lock to the right to secure the battery.



Checking LED Status

LED	Description
Red Light	<ul style="list-style-type: none"> ■ Battery Charging ■ Twinkling together to indicate battery low status (less than 15%) when power is on. ■ Twinkling alternatively to indicate that battery is not installed or not installed well when battery charger was plug-in.
Green Light	<ul style="list-style-type: none"> ■ Battery Fully charged ■ Barcode scan good read
Blue Light	Message
No LED (Red and Green) display when battery is out.	

Remove the Battery

- Pull the plastic sheet and lift upward to remove the battery.



WARNING!


There is a risk of fire and burns if the battery is handled improperly. DO NOT disassemble, crush, puncture, short external contacts, or dispose the battery pack in fire or water. DO NOT attempt to open or service the battery. Dispose of used batteries according to local recycling guidelines in your area.

CAUTION

To ensure the unit working properly, please keep all connectors away from the contaminants staying inside of them such as dust, grease, mud, and water. The negligence may cause the unit to no communicate, short-circuit, Overheat and so on. If the connector is damaged, please ensure the connector is fully repaired before using the unit to avoid causing short circuits.

Attach the Hand Strap

1. Thread the end of the hand strap through the strap holes on the bottom of the gun grip.
2. Pull the other end of the strap through the loop on the threaded end.



Learn more about other HT730 UHF accessories:


If you would like to charge the terminal with the other HT730 UHF accessories, such as a 1-Slot / 4-Slot Charging Cradle, 1-Slot / 4-Slot USB Cradle, 1-Slot / 4-Slot Ethernet Cradle, or charge the battery with the HT730 four-slot battery charger, please scan the barcode below to download related files:



- <http://www.ute.com/>

Copyright 2022 Unitech Electronics Co., Ltd. All rights reserved. Unitech is a registered trademark of Unitech Electronics Co., Ltd.

Documents / Resources

	<p>unitech HT730 UHF RFID Rugged Handheld Terminal [pdf] User Guide HT730 UHF RFID Rugged Handheld Terminal, HT730, UHF RFID Rugged Handheld Terminal, Rugged Handheld Terminal, Handheld Terminal, Terminal</p>
---	--

References

- [unitech Unitech Global | Your Brilliant AIDC Solution Provider](#)