



UNITEK D1022A 11+ 11 in 1 USB-C Ethernet Hub with MST Triple Monitor User Manual

[Home](#) » [UNITEK](#) » UNITEK D1022A 11+ 11 in 1 USB-C Ethernet Hub with MST Triple Monitor User Manual 



D1022A 11+ 11 in 1 USB-C Ethernet Hub with MST Triple Monitor User Manual

Contents

- 1 D1022A 11+ 11 in 1 USB-C Ethernet Hub with MST Triple Monitor
- 2 Product Overview
- 3 Package Contents
- 4 Technical Data
- 5 Documents / Resources
 - 5.1 References



D1022A 11+ 11 in 1 USB-C Ethernet Hub with MST Triple Monitor



uHUB 11+
11-in-1USB-C Triple Display MST Hub
with 4K Video Output, PD100w & SuperSpeed 5Gbps
01022A



Product Overview



Package Contents

- uHUB 11+

- User Manual

Safety Notes

- Do not attempt to service or repair the product yourself. Leave any and all service work to qualified experts.
- Do not open the device or continue to operate it if it becomes damaged.
- Do not modify the product in any way. Doing so voids the warranty.
- Keep this product like all electrical products, out of the reach of children

warranty Disclaimer

UNITEK assumes no liability and provides no warranty for damage resulting from improper installation/mounting, improper use of the product or from failure to observe the operating instructions and/or safety notes.

Technical Data

Compatibility	Us8-C port
Systems Supported (PC, Laptop & Tablet)	Windows XP or later veer, Mac OS X or later veer Linux
USB Specification	USB 3.0

Note


- To use the charging function for the upstream device. it must support USB Power Delivery (PD) or Thunderbolt 3 technology.
- To use the OP, HDMI or VGA function, the device must support DisplayPort Alternate Mode or Thunderbolt3 technology.
- DP, HDMI & VGA MST (Multi-Stream Transport) support for the simultaneous use of two monitors with different content. Passive DisplayPort/HDMI cables (without chipset / signal converter) must be used for MST.
- The MST function is dependent on the graphics card, operating system and monitor used. MacOS does not support MST. For more information, consult the operating instructions or contact the manufacturer.

Service and Support

Further support information can be found here: www.unitek-products.com

Email: support@unitek-products.com

UNITEK

	<p>UNITEK D1022A 11+ 11 in 1 USB-C Ethernet Hub with MST Triple Monitor [pdf] User Manual</p> <p>D1022A, D1056A, D1022A 11 11 in 1 USB-C Ethernet Hub with MST Triple Monitor, 11 11 in 1 USB-C Ethernet Hub with MST Triple Monitor, Ethernet Hub with MST Triple Monitor, MST Triple Monitor, Triple Monitor</p>
---	--

References

- [User Manual](#)