

UNITY M1913 AXON Remote Switch Instruction Manual

Home » UNITY » UNITY M1913 AXON Remote Switch Instruction Manual







INSTALLATION INSTRUCTIONS M1913


Contents

- 1 M1913 AXON Remote
- **Switch**
- **2 CONTENTS**
- 3 Documents / Resources
- **4 Related Posts**

M1913 AXON Remote Switch



CONTENTS




WARNING: ENSURE FIREARM IS UNLOADED


CAUTION: OVER-TORQUING FASTENERS CAN DAMAGE YOUR MOUNT AND WILL NOT BE COVERED BY WARRANTY.




If using mini zip ties (sold separately) for cable management , install them prior to placing assembly on rail . Secure zip ties in loose loop for now .




1. Place the AXON™ Control Module on M1913 Rail in desired location.



- 2. Align the Rail Clamps along the side of the AXON™ Control Module ensuring the logo on each Rail Clamp is upright. The Rail Clamps are interchangable and can be placed on either side.
- 3. Fully seat the Hex Nuts in the recesses in Rail Clamp B.



4. Thread the Cross Bolts in the circular holes in Rail Clamp A via the pass-through and into the Hex Nuts in Rail Clamp B. Finger tight both before applying torque to either. Torque to 5 in-lbs (0.57 Nm).



5. Route cables from AXON™ to devices and fully seat plugs in sockets. Avoid sharp bends and routing over extreme heat areas and sharp edges. If using zip tie loops for cable management, carefully pass slack cable through loops and tighten ties.

INFO@UNITYTACTICAL.COM

©2022 UNITY Tactical. All Rights Reserved.

Specifications subject to change without notice. PATENT PENDING





Documents / Resources



<u>UNITY M1913 AXON Remote Switch</u> [pdf] Instruction Manual M1913 AXON Remote Switch, M1913, AXON Remote Switch, Remote Switch, Switch

Manuals+,