



universal douglays Rouch to Tune 2.0 WiFi and Google Play Instructions

[Home](#) » [universal douglays](#) » universal douglays Rouch to Tune 2.0 WiFi and Google Play Instructions 

Contents

- [1 universal douglays Rouch to Tune 2.0 WiFi and Google Play](#)
- [2 Enabling Wi-Fi](#)
- [3 Uninstalling Original Touch to Tune App](#)
- [4 Logging in to Google Play](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)




universal douglays Rouch to Tune 2.0 WiFi and Google Play




Enabling Wi-Fi

1. Turn on phone
2. Click on "Settings" icon



3. Click on Wi-Fi



4. Turn Wi-Fi on




5. Select network name

6. Login with password, if needed


Uninstalling Original Touch to Tune App

1. Locate existing app on phone
2. Press and hold the app icon until Uninstall/App info dialog box appears
3. Select Uninstall




Logging in to Google Play


1. Turn on phone
2. Click on "Play Store" icon




3. Click Sign In



4. Create account or enter existing account and hit next




5. Search for Touch To Tune App
6. Select the app and download



7. Email TouchtoTune@universaldouglas.com to request password
8. Enter password provided

Documents / Resources

	<p>universal douglays Rouch to Tune 2.0 WiFi and Google Play [pdf] Instructions Rouch to Tune 2.0 WiFi and Google Play, Rouch to Tune, 2.0 WiFi and Google Play, 2.0 and Go ogle Play, WiFi and Google Play</p>
---	---