



**Contents** [ [hide](#) ]

- [1 UNTITLED Opti Plex Desktop Computer](#)
- [2 Product Specifications](#)
- [3 Tools Required](#)
- [4 Assembly](#)
- [5 Placement](#)
- [6 Adjustments](#)
- [7 Maintenance](#)
- [8 FAQs](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)

# UNTITLED


## UNTITLED Opti Plex Desktop Computer



## Product Specifications


- Components included: Desktop board, Crossarm, Desktop poles
- (2), Layerboard, Lockable wheels (4), Adjustable knobs (4), Hooks
- (2), Screwdrivers (1), Screws of various sizes
- Material: Metal and plastic
- Dimensions: [Insert dimensions here]
- Weight: [Insert weight here]

## Tools Required




## Assembly


1. Install 2 at the bottom of the leg on 4 lockable wheels




2. Screw four 6cm Since the tapping on the layerboard




3. Tighten 4 x 6cm Since the tapping and 4 x 4cm flat head screws in the position shown in the picture




4. Insert 2 desktop poles into the bottom of the leg (This step is already installed)




5. Mount the desktop pole on the desktop board with four 3cm flat head screws




6. Tighten 4 adjustable knobs




7. Tighten the 2 hooks on both sides of the desktop plate and the 2 pointed short screws with 4 \* 1 cm flat head screws




8. Installation steps with the monitor stand Screw the monitor poles to the monitor board with a 4 \* 1cm flat head screw



9. Insert the Monitor poles C-slot into the monitor board and tighten the 4 \* 1cm flat head screw



10. Installation completed! 2 types of feet can be switched to use



## Placement

Place the assembled product in a suitable location, ensuring stability and proper alignment.

## Adjustments

Make any necessary adjustments to the height or position of the components to suit your needs.

## Maintenance

Regularly check and tighten screws and knobs to maintain stability. Clean the product with a damp cloth when needed.

## FAQs


**Q: Can I adjust the height of the desktop board?**

A: Yes, you can adjust the height by loosening the adjustable knobs, repositioning the components, and then tightening the knobs securely.

**Q: How do I attach a monitor to the monitor stand?**


A: Follow the provided instructions to mount the monitor poles to the monitor board using the specified screws and slots.


## Documents / Resources

	<a href="#">UNTITLED Opti Plex Desktop Computer [pdf]</a> Instruction Manual Opti Plex Desktop Computer, Plex Desktop Computer, Desktop Computer, Computer
---	---

## References

- [User Manual](#)

 Computer, Desktop Computer, Opti Plex Desktop Computer, Plex Desktop Computer,

 Untitled    Untitled

## Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.