



# **Updesk A3L Dual Motor Height Adjustable Table Instruction Manual**

Home » updesk » Updesk A3L Dual Motor Height Adjustable Table Instruction Manual



#### **Contents**

- 1 Updesk A3L Dual Motor Height Adjustable
- 2 Specifications
- 3 Precautions
- 4 Use and liability
- **5 Parts Diagram**
- **6 Screw List**
- **7 Installation Tools**
- 8 Installation steps
- 9 Hand-control operating instructions
- **10 Reset Operation**
- 11 Instructions for use
- **12 FAQ**
- 13 Documents / Resources
  - 13.1 References
- **14 Related Posts**



**Updesk A3L Dual Motor Height Adjustable Table** 



# **Specifications**

• Model: A3L

• Product: Dual Motor Height-Adjustable Table

• Motor Type: Electric

· Maximum Load Capacity: Not specified

· Adjustment Range: Not specified

# **Hand Controller Operation Instructions**

Refer to the provided manual for detailed hand controller operation instructions.

**Instructions for Use**The height-adjustable desk is designed to be raised and lowered by an electric motor. Ensure it is used in a dry work area and set to an ergonomic height. Any other use is at the user's risk.

### **Preface**

First of all, thank you for purchasing updesk products.

We are very happy to gain your trust, and we will be committed to providing you with great value electric lifting tables. We believe that electric lifting tables will provide you with a healthy and happy experience.

### **Precautions**

- 1. Make sure there are no obstacles during the lifting process of the lifting table
- 2. Make sure the tabletop of the lifting table does not touch any wall
- 3. ake sure the length of the power cord can adapt to the height change of the lifting table

- Keep children away from the electric lift table, controller and hand control panel. Improper operation may cause bodily injury and electric shock.
- Keep all electronic components away from liquids.
- Please do not sit or stand on top of the table stand. Do not lie down or crouch under the table stand.
- Do not place objects higher than 50 cm under the table frame.
- Do not open any parts, including table legs, controllers and hand control panels, as opening may cause the risk of electric shock.
- The product is designed with a duty cycle of 10% (i.e., 2 minutes of work and 18 minutes of rest)
- If you encounter a power outage or unplug the power supply, you may need to manually reset it. Please refer to the instructions in step 11


### Use and liability

Our height-adjustable desk is designed to be raised and lowered by an electric motor and should be used in a dry work area. The height of the desk is adjustable so it can be set to the most ergonomic height. Any other use is at the user's risk. We do not assume any product claims or liability claims resulting from improper use or operation.

### Important reminder:

This manual does not contain any positional expressions or other implications. For this reason, our company reserves the right to modify the manual, and the content may be updated at any time without prior notice.

### **Parts Diagram**




# **Screw List**

| Part | Quantity | Standard        | Schematic diagram |
|------|----------|-----------------|-------------------|
| Α    | 8        | M6x14mm         | <b>•</b>          |
| В    | 12       | M6x12mm         | 9=                |
| С    | 4        | M6x8mm          | •                 |
| D    | 9        | M6x20mm(Preset) | 0-                |
|      | 9        | ST4.8x25mm      | 0-                |
| Е    | 2        | ST4.8x18mm      | 0-                |

| Part | Quantity | Standard     | Schematic diagram |
|------|----------|--------------|-------------------|
| F    | 2        | ST3.5x16mm   | -                 |
| G    | 9        | Upper gasket | 8                 |
| Н    | 9        | Lower gasket | 용                 |
|      | 5        | Wire buckle  | <b>-E3</b> -      |
| J    | 1        | 4mm          |                   |
|      |          |              |                   |

# **Installation Tools**




warning: Using these tools will help you install more conveniently.


# Installation steps

When you install, please check all the parts first to make sure you have received all the parts mentioned in the manual.


1. Adjusting the tensile beam

2.







3. Assembling the feet




4. Assembling the middle arm




5. Assemble the two arms




6. Assemble the rubber stopper and plastic gasket




7. Corresponding to the power box socket and wiring



# 8. Assembling the desktop and power box



9. Assembly Complete



# Hand-control operating instructions



# **Reset Operation**

Tip: You must reset before use

- Before resetting, make sure there are no obstacles within the table's lifting range and that the tabletop does not touch any wall.
- Make sure the power/data cable is connected correctly and that the power cable is long enough to accommodate the height change of the lifting table.

The reset operation is as follows: Press and hold the "V" key to lower the table to the lowest height until the motor stops. When you hear a "beep" sound, release the key to complete the reset operation. Note that you cannot release the "V" key during this process. If you release the key, the reset operation will stop.

### Up and down key operation

- When the " \* " key is pressed, the desktop moves upward until it reaches the highest point on the desktop.
- ullet When the "  ${ullet}$  " key is pressed, the desktop moves downward until it reaches the lowest point on the desktop.

# Position storage and memory operation

• This lifting table has 4 different height position memories, and the stored memory positions are still valid after

power failure.

- The hand controller in the above picture can store 4 memory points. The storage method is as follows. When running to a specific point, press the "M" key, the digital tube displays "S-", and "\_" flashes at the same time. At this time, press the "1-4" key to store the current position to the corresponding label.
- If you want to run to a memory point, you only need to press the label of the corresponding storage position. At this time, the digital tube will display the height of the corresponding label position, and then automatically run to the corresponding height stored so far. During operation, any key can stop the system.

#### **Fault resolution**

If your desk lift isn't working properly, you may need to perform a reset. Unplug the power cord for 20 seconds, then plug it back in and follow the reset instructions.

### Instructions for use

#### Cleaning and maintenance instructions

- 1. daily maintenance, should use a clean soft cloth wipe the surface dust. Do not use wet cloth, hard objects to wipe the surface. Do not contact the surface with acid, alkaline chemicals.
- 2. Metal foot paint part can only use a towel dipped in water and then wrung out before cleaning, avoid contact with acid, alkali and other corrosive liquids.
- 3. In case of minor scratches, gently wipe with a soft cloth repeatedly to smooth out the scratches.
- 4. When you need to use tape to fix the package, avoid directly affixing it to the outer surface of the metal foot type to prevent the paint film from peeling off.
- 5. To avoid ballpoint pen, ink, etc. dirty desktop, such as found on the desktop stains, etc., with a warm wet towel (do not drip) wipe clean, and finally with protective agent care.
- 6. Should avoid sunlight for a long time to irradiate the desktop, placed in high-temperature conditions or placed in a dry environment, so as not to cause local discoloration or fading.

### Slab Top Lift Table

- 1. In the process of using the leather countertop lift table, pay attention to waterproof, moisture-proof and grease-proof.
- 2. The daily cleaning of the plate top lift table can be used to dust the surface duster gently. Cleaning must be carried out in the direction of the wood grain, try not to wipe back and forth.

# **Leather Top Lift Table**

- 1. In the process of using the leather countertop lift table, pay attention to waterproof, moisture, oil stains, powder.
- 2. leather table lifting table in the use of the process is prohibited in the leather table tops vigorously extruded or placed heavy objects, if the leather table tops appeared in the phenomenon of prints, can be used to wait for a hot thin towel across the skin to rebound or with a hot wind blown to the skin rebound can be blown, blowing time should not be too long and too hot and the outlet should not rely on the leather table tops are too close. It is recommended that the table mat can be used to lay on the leather countertop to protect the countertop and then normal use.

- 3. the usual use of hot water cups, should put some coasters on the countertop to prevent the leather countertop overheating cup marks.
- 4. The daily cleaning of the leather lift table can be used chicken feather duster gently dust the surface dust can be.

#### **Precautions**

- 1. Please put it on the level ground when using.
- 2. When the product is to be moved, it should never be pushed on the rough hard ground, and the table legs and table top should be lifted together to move.
- 3. Please do not let children use the lift table alone.
- 4. Please do not sit on the table top, which will easily lead to product damage and danger.
- 5. Do not stand on the table top and use it as a ladder, it is easy to fall and get hurt.
- 6. Do not scratch the surface of the table with sharp and hooked objects, and do not get close to open fire.
- 7. Product placement should be located away from coal fires, radiators and other heat sources, so as not to overheat the furniture resulting in discoloration and aging of the finish material.
- 8. The product should be used in a dry and ventilated place. If water is accidentally poured onto the tabletop, it should be wiped immediately with a dry cloth to prevent it from seeping into the board and causing swelling or mold.
- 9. Please make sure that there is no obstacle in the process of table lifting, the tabletop is not next to the wall, and the length of all the wires meets the table up and down movement.

### **FAQ**

- · Q: What should I do if there is a power outage?
  - A: If there is a power outage, you may need to manually reset the table. Refer to the manual for instructions on how to reset it.
- · Q: Can I modify any parts of the table?
  - A: It is advised not to open any parts of the table, includinglegs, controllers, and hand control panels, as it
    may pose a riskof electric shock.

### **Documents / Resources**



<u>Updesk A3L Dual Motor Height Adjustable Table</u> [pdf] Instruction Manual A3L, A3L Dual Motor Height Adjustable Table, A3L, Dual Motor Height Adjustable Table, Motor Height Adjustable Table, Height Adjustable Table, Adjustable Table, Table

#### References

User Manual

# Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.