



## UPLIFT Desk E7 LED Desk Lamp with Clamp User Guide

[Home](#) » [UPLIFT DESK](#) » UPLIFT Desk E7 LED Desk Lamp with Clamp User Guide 

### UPLIFT Desk E7 LED Desk Lamp with Clamp User Guide




## Contents

- 1 Desk Lamp
- 2 BEFORE USE:
- 3 Specifications
- 4 What in Box
- 5 Touch Pad
- 6 Charging Port
- 7 Switch Function
- 8 How to Use
- 9 How to Pair the Remote Control
- 10 Customer Service
- 11 Documents / Resources
  - 11.1 References

## Desk Lamp

Applicable desktop thickness range: 0.39"- 2.08")



## BEFORE USE:

1. Before using, remove the protective film from the device.
2. Plug into a power outlet to activate the device for the first use time.
3. Do not remove the type labels.


## Specifications

Model Number	L22D	Output Voltage	12V DC 2A
Type of Bulb	LED	USB-C Harging	5V 1A
Color Temperature	2700K/3000K/4200K/5000K/5500K/6500K	Type-C Charging	5V 1A
Brightness	Max, 1600 lm	Control Type	Remote Control/Touch Control
CRI	> 85 Ra	Total Power	24W
Input Voltage	100-240V AC 50/60HZ	IP Grade	IP20

## What in Box

1 x Lamp  
 1 x Remote Control  
 1 x Adapter  
 1 x User Manual

## Touch Pad



## On/ Off Button

“Tag the on off button to turn the lamp on of. Plug into a power ovulatory USB port 1o infer the standby mode, and the power indicator will light up

**On/Off Button**

Tap the on/off button to turn the lamp on/off. Plug into a power outlet or USB port to enter the standby mode, and the power indicator will light up.

**Color Temperature / Brightness Adjustment**

Tap the color temperature button to cycle through 6 color temperature settings. Tap the Brightness Button to adjust 6 brightness levels.

**Night Light**

Decrease screen brightness and reduce eye strain.
















**Charging Port****Light Off:**

Using a single USB or Type-C port can provide a maximum charging current of 2A. Using both ports to charge simultaneously, each port can only output a current of 1A.

**Light On:**


Using a single USB or Type-C port can provide a maximum charging current of 1A. Using both ports to charge simultaneously, each port can only output a current of 0.5A.

**Switch Function**


	Switch	Function
		Signal Indicator
		ON/OFF
		Night Light
		Brightness Increase
		Brightness Decrease Maximum Brightness 6500K
		60 Minutes Timer
		30 Minutes Timer
		Color Temperature Increase
		Color Temperature Decrease
		Reading Mode
		Game Mode
		Work Mode
		Breast-feeding Mode
		Casual Mode

## How to Use

**Step 1:** To attach the clamp to the desk, loosen the knob under the clamp and slide it onto your desk.



**Step 2:** Tighten the knob until the clamp is securely fastened to the edge of your desk.



**NOTE:**

The applicable desktop thickness range is 0.39"-2.08". Please do not clamp the light on uneven surfaces. Please do not clamp the light on fragile countertops such as glass.

**Notice**

- Do not connect the product to a computer as the charging current may damage the computer.
- Do not use the lamp if there are signs of damage or faulty electric cords.
- Avoid any extreme heat sources and direct sunlight exposure.
- Do not use corrosive or abrasive cleaners to clean the surface of the device.
- Please keep all the components of the device dry and clean.
- Do not overstretch the adjustable clamp to prevent damage.

**Warning**

**WARNING:** To avoid electric shock, do not disassemble or tamper with the Lamp or Power adapter, Only use the Power adapter included with this Lamp.

- **WARNING :** Unplug and discontinue use in the event that the following occurs:
  - The power adapter or cord breaks
  - The Lamp's casing or one or more of the joints break
  - The light emits sparks or smoke
  - Abnormal flickering occurs or the LED bulb breaks.
- **WARNING:** Do not place the device near a heat source or exposed fire source, such as an electric heater or oven, fire, candle, or other places that may produce high temperatures. **WARNING:** For indoor use only! Do not expose the device to rain or wet location.

- **WARNING:** Keep the children or pets away from the device and its accessories during assembly to avoid personal hazards and product damage.

## How to Pair the Remote Control

- Make sure that your device is turned on and in pairing mode.
- Press and hold the button on the remote control for 3 seconds until the device flashes twice quickly, indicating that the pairing process has started. The pairing process should be completed within 1 minute.
- If you need to pair multiple devices with one remote control or replace a remote control, you can repeat the first step to pairing the remote control with the new device.
- To restore the device to its factory settings, simply unplug the power and restart it, Then use the pairing method described above to pair the remote control with the device.

## Customer Service

We are greatly appreciative of your business and that you chose our device out of the thousands of items listed on Amazon. Furthermore, we're here for you if you need any assistance with your device as we truly want you to be satisfied with your purchase. We'd like to demonstrate our commitment to quality customer service, by reminding you or making you aware of a 1-year Replacement & Money Back Warranty offered by us. So, if you run into any problem when you receive your product, please get in touch with us by:



Contact via Amazon contact seller"




[Daisy.lu@uergogo.com](mailto:Daisy.lu@uergogo.com)



---

## Documents / Resources

	<p><a href="#">UPLIFT Desk E7 LED Desk Lamp with Clamp</a> [pdf] User Guide E7 LED Desk Lamp with Clamp, E7, LED Desk Lamp with Clamp, Desk Lamp with Clamp, Lamp with Clamp, Clamp</p>
---	---

## References

- [User Manual](#)

