uponor R-208 Smatrix Interface Pulse





# uponor R-208 Smatrix Interface Pulse Instructions

Home » uponor » uponor R-208 Smatrix Interface Pulse Instructions



#### **Contents**

- 1 uponor R-208 Smatrix Interface
- **2 Product Usage Instructions**
- **3 ASSEMBLY INSTRUCTION**
- 4 Documents / Resources
  - 4.1 References



uponor R-208 Smatrix Interface Pulse



### **Specifications:**

• Product Name: Uponor Smatrix Pulse R-208

• Size: 60 mm

Manufacturer: Uponor GmbH

Production Number: 1094646 v5 10 2023

• Product Website: <a href="mailto:smatrixpulse-support.uponor.com">smatrixpulse-support.uponor.com</a>

# **Product Usage Instructions**

#### Installation:

Follow the installation guide provided with the product to ensure proper setup. Make sure to mount the Uponor Smatrix Pulse R-208 securely in a suitable location.

### **Configuration:**

After installation, configure the device according to your preferences by following the instructions in the user manual. Set up any required connections and adjust settings as needed.

### Operation:

To operate the Uponor Smatrix Pulse R-208, use the control interface provided. Follow the user manual for guidance on adjusting temperature settings, modes, and other functions.

#### Maintenance:

Regularly check the device for any dust or debris accumulation that may affect its performance. Clean the device as recommended in the user manual to ensure optimal operation.


#### Frequently Asked Questions (FAQ):


Q: Can I control multiple Uponor Smatrix Pulse R-208 units from a single interface?

**A:** Yes, you can control multiple units by setting up a centralized control system as described in the user manual. Ensure proper configuration for seamless operation.

**Q:** How do I troubleshoot connectivity issues with the Uponor Smatrix Pulse R-208? **A:** If you encounter connectivity issues, check the network settings and connections as outlined in the troubleshooting section of the user manual. Resetting the device may also help resolve issues.

## **ASSEMBLY INSTRUCTION**





Uponor GmbH Industriestraße 56, D-97437 Hassfurt, Germany 1094646 v5\_10\_2023 Production: Uponor / ELO

Uponor reserves the right to change the product portfolio and the related documentation without prior notification, in line with its policy of continuous improvement and development.



www.uponor.com

# **Documents / Resources**



uponor R-208 Smatrix Interface Pulse [pdf] Instructions
R-208 Smatrix Interface Pulse, R-208, Smatrix Interface Pulse, Interface Pulse, Pulse

# References

- O PEX Products for Residential & Commercial Applications | Uponor
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.