

# **Uponor X-265 Smatrix Pulse Controller User Guide**


Home » uponor » Uponor X-265 Smatrix Pulse Controller User Guide 🖫




#### **Contents**


- 1 Uponor X-265 Smatrix Pulse Controller User Guide
- 2 Technical Data
- **3 Safety Instructions**
- 4 Documents / Resources
  - 4.1 References

**Uponor X-265 Smatrix Pulse Controller User Guide** 



Part no. A380265C includes Communication Module (R-208) Part no. A380265A includes Antenna (A-265)








**Technical Data** 














### **Safety Instructions**

This quick guide serves as a reminder for experienced installers. Uponor strongly recommends reading the complete Smatrix Pulse Manual before installing the control system.



# Warning!

The Uponor system uses 120 V, 60 Hz AC power. In case of emergency, immediately disconnect the power.



# Warning!

Electrical installation and service behind secured 120 V AC covers must be carried out under the supervision of a qualified electrician.



# Warning!

The transformer module is heavy and might detach if the controller is held upside down without the cover on.



# Warning!

The Smatrix Pulse system uses CR2032 coin-cell batteries. KEEP OUT OF REACH OF CHILDREN.



## Caution!

To avoid RF / WIFI interference, keep installation/data cables away from power cables of more than 60 V.



### Caution!

If RF / WIFI communication difficulties exist,
Uponor recommends relocating the antenna
to a more optimal position. Do not install Uponor
radio sources closer than 16" / 41 cm from
eachother to avoid interference.



#### Caution!

Ensure that each actuator is connected to the correct channel so that the thermostats are controlling the correct loops.

Connect only one actuator for each channel. Channels 01 and 02 have double outputs (a and b) for two actuators.



#### Caution!

If more than one controller is available in the system, register the thermostat as a system device to the master controller.



#### Caution!

The switches in the public thermostat must be set before registering the thermostat.



### Caution!

The switches in the public thermostat must be set to one of the available functions, otherwise it cannot be registered.



#### Note

Registration of at least one thermostat must be completed before registering a system device.



#### **Uponor Inc.**

5925 148th Street West Apple Valley, MN 55124 USA T 800.321.4739 F 952.891.2008 6510 Kennedy Road Mississauga, ON L5T 2X4 CANADA T 888.594.7726 F 800.638.9517

uponor.com

#### **Read More About This Manual & Download PDF:**

#### **Documents / Resources**



<u>Uponor X-265 Smatrix Pulse Controller</u> [pdf] User Guide X-265 Smatrix Pulse Controller, X-265, Smatrix Pulse Controller, Controller

### References

• © PEX Products for Residential & Commercial Applications | Uponor

Manuals+,