

Contents [[hide](#)]

- [1 Variscite DART-MX91 Evaluation Kit](#)
- [2 Features](#)
- [3 Evaluation kit initial setup](#)
- [4 Setting the host PC for debug](#)
- [5 Frequently Asked Questions](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)



Variscite DART-MX91 Evaluation Kit



Specifications


- Processor: NXP i.MX 91

- Power Input: 12V
- Connectivity: SFP+ 10Gb ETH, Gigabit Ethernet, USB 2.0, USB 3.0, USB Debug, Dual MIPI-CSI, PCIe M.2, HDMI, UART, I2C, SAI, PDM, CAN, GPIO, SPDIF, QSPI, LVDS, ECSPI, Resistive Touch, Capacitive Touch, Line In, Headphones

Features

1. 12V PWR IN (J30)
2. SFP+ 10Gb ETH (J25) – N/A
3. Boot Select Switch (SW8)
4. Gigabit Ethernet #1 (J27)
5. USB 2.0 OTG (J33)
6. Gigabit Ethernet #2 (J26)
7. Dual USB 3.0 Host (J28)
8. FAN 12/5V (J34)
9. micro SD Card slot (J31)
10. USB Debug (J32)
11. Dual MIPI-CSI (J23) – N/A
12. SOM extra PWR (SW1) – LED D7 should be OFF. If not, change the state of SW1
13. PCIe M.2 M Key #1 (J18) – N/A
14. PCIe M.2 M Key #2 (J17) – N/A
15. HDMI (J16) N/A
16. UART, I2C (J6)
17. SAI2, SAI5, PDM, CAN (J7)
18. GPIO, SPDIF (J8)
19. QSPI (J12)
20. LVDS CH0 (J9)
21. LVDS CH1 (J13) – N/A
22. ECSPI, Host wake (J10)
23. Resistive Touch (J5)
24. Capacitive Touch (J4)
25. Line In (J15)
26. User Buttons (SW2-SW5)
27. Headphones (J19)

28. Reset Button (SW6)
29. ON/OFF Button (SW7)
30. SAI1 (J22)
31. Power ON (SW9)



Evaluation kit initial setup

1. Carefully remove the 7" LCD and the Sonata-Board from the package.
2. Connect the 7" LCD display and touch cables to the evaluation kit connectors J9, J4 respectively.

Note: connect the display cable with the red wire on pin 1. Connect the touch cable with the metal contacts facing down.



3. Plug the USB type A to USB-C cable between the USB debug connector (J32) and a PC USB port.

Setting the host PC for debug

1. Download any PC terminal software (e.g. Putty).
2. Set the PC terminal software parameters as follows:
 - Baud Rate: 115200
 - Data bits: 8
 - Stop bits: 1
 - Parity: None
 - Flow Control: None

Booting from eMMC

1. For internal boot:

Set the Boot select switch (SW8) to INT position to boot from the SOM's internal storage.
2. Plug the wall adapter into the 12V power jack (J30) and to a 120VAC~240VAC power source.
3. Set Power ON switch (SW9) to ON state.
4. Boot messages should be printed within the PC terminal window.

Booting from a micro SD card

The microSD card is supplied within the package. Updated SD card images can also be downloaded from the Variscite FTP server. See more details in the recovery SD card section in the Variscite wiki pages.

1. Set Power ON (SW9) to off state.
2. Set Boot select switch (SW8) to EXT side in order to boot from the SD card.
3. Push microSD card into the microSD card slot (J31) of the Sonata-Board.
4. Set Power ON switch (SW9) to ON state.
5. Boot messages should be printed within the PC terminal window.

(Re-)Installing the file system on the eMMC

Please refer to the recovery SD card section in the Variscite wiki pages.

Links

- Wiki page: <https://variwiki.com/index.php?title=DART-MX91>

- DART-MX91 Evaluation kits: <https://www.variscite.com/product/evaluation-kits/dart-mx91-evaluation-kits/>
- DART-MX91 System on Module: <https://www.variscite.com/product/system-on-module-som/cortex-a55/dart-mx91-nxp-i-mx91/>
- Sonata carrier board: <https://www.variscite.com/product/single-board-computers/sonata-board/>
- Customer portal: <https://varisciteportal.axosoft.com/login>

Thank you for purchasing Variscite's product.

For additional assistance please contact: sales@variscite.com

Frequently Asked Questions


Where can I find more information about the product?

You can visit the following links for more details:

- Wiki page: [DARTMX91 Wiki](#)
- DART-MX91 Evaluation kits: [Evaluation Kits](#)
- DART-MX91 System on Module: [System on Module](#)
- Sonata carrier board: [Sonata Carrier Board](#)
- Customer portal: [Customer Portal](#)

If you need further assistance, please contact sales@variscite.com.

Documents / Resources

	Variscite DART-MX91 Evaluation Kit [pdf] User Guide DART-MX91, DART-MX91 Evaluation Kit, Evaluation Kit
---	---

References

- [User Manual](#)

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.