




## Contents [ [hide](#) ]

- [1 VAYDEER LB301 Series Time Locking Container](#)
- [2 Power Supply Method](#)
- [3 Icons and Buttons](#)
- [4 Mode Description](#)
- [5 Setup and Use](#)
- [6 Packing List](#)
- [7 FCC Statement](#)
- [8 FAQ](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)


# VAYDEER

## VAYDEER LB301 Series Time Locking Container




## Power Supply Method

Powered by four AA alkaline batteries.



Note : If the battery dies, plug in any 5V/1A adapter (not included) using the provided cable through the side Type-C port to get emergency power.



**Side**


## Icons and Buttons




When the child lock icon is illuminated, no button operations can be performed.

### Note:


During the time setting process, if no button is pressed for 1 minute, the screen will automatically turn off; in non-setting mode, the screen will automatically turn off after 10 seconds of no button operation.



Lid Front



Side



**Lid Back**

## Mode Description

Switch modes by toggling the mode switch button on the back of the lid.





- M1: Before the timer resets to zero, no override; (default)
- M2: Password box mode, lock after setting a password, and unlock with the set four-digit password.

Note: You need to reset the password, every time you switch the toggle back to M2. (Use this method to reset your password if you have forgotten it.)

## Setup and Use

### M1 Mode Lock Settings






#### Timer Setup

1. Press  to select minutes.hours, or days from right to left;
2. Press  or  to set the selected time (hold for rapid setting);
3. After setting the time, press  ; this begins the locking countdown, and locking

completes after the countdown ends;

4. During the countdown, any button may be pressed to cancel the lock;






## Time addition

1. Press and hold  button for 5 seconds while in the locked state to increase the lock duration;
2. Press  button to select minutes, hours, and days from right to left for setting;
3. Press  or  to set the currently selected time (long press to quickly set);
4. After setting the time, press  to save the additional time immediately;


You can only make the lock time longer with this option. If you try to set a time shorter than what's already left, it won't save your changes.

## M2 Mode Lock Settings


### Password Setting:

1. Switch to M2 mode by toggling the  then enter password setting mode;
2. Press  to switch digit positions;
3. Press  or  to set the selected digit (hold for rapid setting);
4. Press  to confirm and save the password;

### Locking:"

After setting the password, hold the  for 3s to lock immediately.

### Change password:






1. In unlocked state, toggle  switch to reconfigure password parameters.
2. After emergency unlocking your locked device, reset your password using 1 in the guide.

## Unlocking

## 1. Automatic Unlocking:

In M1 mode, automatically unlock when the timer ends;

## 2. Password Unlocking:

In M2 mode, press  to enter password input mode, press  to switch digit positions, and use  or  to set the digits. Press  to confirm password and unlock.

## Emergency unlocking:

For step-by-step instructions, check your emergency unlock card.


## Precautions

Do not store emergency equipment, items, or medications. In case of emergency, scan the QR code on the bottom of the product for self-help unlocking.

## Packing List



Time Locking Container x1



Power Cord x1



Quick Start Guide x1



Emergency Unlock Card x1

[Eaftersale@outlook.com](mailto:Eaftersale@outlook.com)

## NOTE

1. Due to the continuous improvement of our products, some parameters and setting steps may be different with what's in this manual. please refer to the actual product you received.
2. The technical parameters such as product features, parameters, usage, design and all other information in this manual are modified if necessary without prior notice.

Thanks for your understanding.

## **FCC Statement**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

## **RF Exposure Information**

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

# FAQ


• **Q: Can this device be used in areas with high RF exposure?**

A: Yes, the device has been evaluated to meet general RF exposure requirements and can be used in portable exposure conditions without restrictions.

• **Q: What should I do if the device causes interference?**


A: If the device causes interference, try repositioning it or moving it to a different location to minimize interference with other devices.


# Documents / Resources

	<a href="#">VAYDEER LB301 Series Time Locking Container [pdf]</a> User Guide LB301 Series, LB301 Series Time Locking Container, Time Locking Container, Locking Container
---	--

# References

- [User Manual](#)

 VAYDEER

 LB301 Series, LB301 Series Time Locking Container, Locking Container, Time Locking Container,

# Leave a comment

Your email address will not be published. Required fields are marked \*

Comment \*

Name



Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

**Post Comment**

**Search:**

e.g. whirlpool wrf535swhz

**Search**

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.