



Contents [[hide](#)]

[1 VCM 919067 Side Table Insasi](#)

[2 Specifications](#)

[3 Parts](#)

[4 Assembly](#)

[5 Operation](#)

[6 Maintenance](#)

[7 FAQs](#)

[8 Documents / Resources](#)

[8.1 References](#)





VCM 919067 Side Table Insasi







Specifications





- **Dimensions:** 25.5 CM x 45.7 CM x 62.9 CM
- **Model Number:** 919067
- **Components:**
 - NO:H100008 – 5×50 MM
 - NO:H100006 – 4×35 MM
 - NO:P002101 – 20×20 MM
 - NO:H100045 – 12 x 04 x 04 x 04 x PB P2 P2 P1 P3 P2 P5 1 P1 P002101 P3
P002101 4x P1 2x 2 H100008 H100008 4x P3 2x 3 P2 H100008 8x H100008 P2
4 H100006 H100006 4x PB 5 H100045 4x H100045


Warning





Parts






- 1. Identify all components using the provided model numbers.
- 2. Follow the assembly sequence mentioned in the manual for proper setup.
- 3. Ensure all parts are securely connected and aligned.


Assembly

1




2x

2




2x


3



4



5



Operation

1. Once assembled, place the product in the desired location.
2. Refer to the user manual for specific operational instructions based on the model number.
3. Operate the product according to the guidelines provided to ensure optimal performance.

Maintenance

1. Regularly inspect the product for any signs of wear or damage.
2. Clean the product using a damp cloth and mild detergent as needed.
3. Store the product in a dry and safe environment when not in use.

Warning: Serious or fatal crushing injuries can occur from furniture tip-over. To prevent

this furniture from tipping over it must be permanently fixed to the wall. Fixing devices for the wall are not included since different wall materials require different types of fixing devices. Use fixing devices suitable for the walls in your home. For advice on suitable fixing systems, contact your local specialized dealer.

Customer Service

www.vcm.group/service

FAQs

Q: How do I disassemble the product for storage?

A: To disassemble, reverse the assembly steps in the manual carefully to avoid damage.


Q: What should I do if a component is missing?

A: Contact customer support with the model number and missing component details for assistance.

Q: Can I use this product outdoors?

A: Refer to the user manual for information on whether the product is suitable for outdoor use.

Documents / Resources

	<p>VCM 919067 Side Table Insasi [pdf] Installation Guide</p> <p>919067, H100008, H100006, P002101, H100045, 919067 Side Table Insasi, 919067, Side Table Insasi, Table Insasi</p>
---	---

References

- [User Manual](#)

◆ 919067, 919067 Side Table Insasi, H100006, H100008, H100045, P002101, Side Table Insasi, Table Insasi,

■ VCM VCM

—Previous Post

[VCM 919059 Regal INSASI Wood Metal Stand Shelf Installation Guide](#)

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.