



# VEILZOR PC407A 2.4G Wireless Backlight Keyboard Mouse Combo User Manual

[Home](#) » [VEILZOR](#) » VEILZOR PC407A 2.4G Wireless Backlight Keyboard Mouse Combo User Manual 

## Contents

- [1 VEILZOR PC407A 2.4G Wireless Backlight Keyboard Mouse Combo](#)
- [2 Product Usage Instructions](#)
- [3 FCC Warning](#)
- [4 Packing List](#)
- [5 2.4G Wireless Connection](#)
- [6 Overview](#)
- [7 BackLight Functions](#)
- [8 Keys and Function](#)
- [9 Documents / Resources](#)
  - [9.1 References](#)
- [10 Related Posts](#)

# VEILZOR

**VEILZOR PC407A 2.4G Wireless Backlight Keyboard Mouse Combo**



## Product Specifications:

- Model: 1BSUPGUIF
- Power Source: DC adapter
- Weight: 2.5 lbs
- Dimensions: 10" x 6" x 4"

## Product Usage Instructions

### Powering On the Device:

Connect the DC adapter to the power source and plug it into the device. Press the power button to turn on the device.

### Setting Up Functions:

Use the control panel to navigate through different functions. Refer to the user manual for specific instructions on each function.

### Adjusting Settings:

Use the buttons on the device to adjust settings such as volume, brightness, and mode. Follow the on-screen prompts for guidance.

## Frequently Asked Questions (FAQ):

### 1. Q: How do I reset the device?

A: To reset the device, locate the reset button on the back of the device and press it using a pin or paperclip.

### 2. Q: What should I do if the device stops responding?

A: If the device becomes unresponsive, try restarting it by holding down the power button for 10 seconds.

## FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and

2. this device must accept any interference received, including interference that may cause undesired operation.


**NOTE 1:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**NOTE 2:** Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.


## Packing List




1. Keyboard x1
2. Mouse x1
3. USB Receiver x1
4. USB C Charging Cable X1
5. User Manual x1

## 2.4G Wireless Connection


**1** Turn on the power switch.



**2** Take out the USB receiver.



Insert the receiver into computer USB Port.



Power Switch

Win System Indicator

OS System Indicator

Caps Lock Indicator

Low Power Indicator

OFF ON



WIN



MAC




A




Low Power Indicator



Type C Charging Port



Type C Charging Port



Power Switch

Light Control Button

## BackLight Functions

### Keyboard Backlight

1. The keyboard has 4 kinds of lighting effects:

Backlit off < Low(30% brightness)<Mid(60% brightness)<High (100% brightness)











2. Press FN+END keys to adjust the keyboard backlight effects.











### Mouse Backlight

1. The mouse has 22 kinds of RGB lighting effects.
2. The backlight control button is at the bottom of the mouse:
  1. Short press the light button at the bottom to switch light effects circularly
  2. Press and hold the light button for 3 seconds to turn off/on the light.


### Keys and Function

Key	Windows	Mac OS
	Mute	Mute
	Volume -	Volume -
	Volume +	Volume +
	Previous	Previous
	Play/Pause	Play/Pause
	Next track	Next track
	Brightness down	Brightness down
	Brightness up	Brightness up
	Switch App	Switch App
	Select All	Select All

	Copy	Copy
	Paste	Paste
	Save	Save
Fn + 	F1-F12 Lock/Unlock	Not for Mac os
	One Click, Switch to Win System	One Click, Switch to Win System
	One Click, Switch to OS System	One Click, Switch to OS System
	Search	Search
	Lock Screen	Lock Screen

## Keys and Function



1. Press  key to use the keyboard on Windows PC

**The F1-F12 Lock/Unlock function is only for Windows:**

1. **When the F1-F12 is Locked:**


You could use the Multi-Media functions directly. ( Defaulted)

2. **When the F1-F12 is Unlocked:**

You could use Multi-media Functions by Fn +F1-F12 .

Lock /Unlock the F1-F12 Functions by :



2. Press  key to use the keyboard on MAC OS devices.

You could use the Multi-Media Functions directly for Mac OS.

You could use F1-F12 Functions by Fn +F1-F12 .

**(Note:** The F1-F12 Lock/Unlock function is not for Mac OS)

## CORRECT DISPOSAL OF THIS PRODUCT



 (Waste Electrical& Electronic Equipment)


This Marking shown on the product or its literature, indicate that it should not be disposed with other household wastes at the end of its working life.

To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate this from other types of wastes and recycle it responsibly to promote the sustainable reuse of material resources. Household user should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take this item for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This

product should not be mixed with other commercial wastes for disposal.

**Documents / Resources**

	<a href="#">VEILZOR PC407A 2.4G Wireless Backlight Keyboard Mouse Combo</a> [pdf] User Manual PC407A, PC407A 2.4G Wireless Backlight Keyboard Mouse Combo, 2.4G Wireless Backlight Keyboard Mouse Combo, Wireless Backlight Keyboard Mouse Combo, Backlight Keyboard Mouse Combo, Keyboard Mouse Combo, Mouse Combo
---	--

**References**

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.