Manuals+ — User Manuals Simplified.

velleman DVM99 3-In-1 IR Thermometer with Thermistor Probe and Clamp User Manual

DVM99 – erratum

C E

Contents

DVM99 3-In-1 IR Thermometer with Thermistor Probe and Clamp

Erratum to manual of DVM99 dated 04/05/2012 and before. Section 6 Operation. The table in this section should be as follows:

MIN	The MIN function is not supported.
MAX	The MAX function is not supported.
LOCK	Press the IRT button **[D]** to enable LOCK-mode (continuous measurement). Press the hold button on **[E]** to exit LOCKmode.
°C/°F	When °C indication is flashing, press the IRT button [**D]** to switch to °F mode and vice versa.
ε	Press the up ▲**[E]** and down ▼**[D]** buttons to set the emissivity (see §7).

V. 01 12/03/2013
©Velleman nv

Documents / Resources

	velleman DVM99 3-In-1 IR Thermometer with Thermistor Probe and Clamp [pdf] User Manual DVM99, 3-In-1 IR Thermometer with Thermistor Probe and Clamp

Manuals+,