



# velleman RCQC3 Quadcopter With 720p Wi-fi Fpv Camera User Manual

[Home](#) » [Velleman](#) » velleman RCQC3 Quadcopter With 720p Wi-fi Fpv Camera User Manual 

## Contents

- [1 velleman RCQC3 Quadcopter With 720p Wi-fi Fpv Camera](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 General Guidelines](#)
- [5 General Guidelines](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)
- [7 Related Posts](#)



## velleman RCQC3 Quadcopter With 720p Wi-fi Fpv Camera



## Product Information

**Model:** RCQC3

The RCQC3 is a quadcopter drone designed for remote control flying. It features various functions such as fly mode, one key return, take photo/video record, and wifi live video transmission. The drone is stable and easy to control, making it suitable for users of all levels. The device operates on a 2.4 GHz technology, which reduces interference when flying multiple quadcopters simultaneously. It is equipped with a rechargeable high-performance lithium-polymer battery that can be charged using the included USB cable. The recommended age for using this product is 14+.

**Important Note:** Always comply with local rules and regulations when using this device.

## Product Usage Instructions

### Safety Instructions:

- Keep this device away from children under age 14 and unauthorized users.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children under age 14 shall be supervised to ensure that they do not play with the appliance.
- Keep this device away from rain, moisture, splashing, and dripping liquids.
- DO NOT disassemble or open the cover. There are no user-serviceable parts inside the device. Refer to an authorized dealer for service and/or spare parts.
- **Warning:** Do not puncture batteries or throw them in fire as they may explode. Do not attempt to recharge non-rechargeable batteries (alkaline). Dispose of batteries in accordance with local regulations. Keep batteries away from children.

### General Guidelines

- Keep this device away from dust and extreme temperatures.
- Protect this device from shocks and abuse. Avoid brute force when operating the device.
- Familiarize yourself with the functions of the device before actually using it.
- All modifications of the device are forbidden for safety reasons. Damage caused by user modifications to the device is not covered by the warranty.
- Only use the device for its intended purpose. Using the device in an unauthorized way will void the warranty.
- Damage caused by disregard of certain guidelines in this manual is not covered by the warranty, and the dealer will not accept responsibility for any ensuing defects or problems.
- Nor Velleman nv nor its dealers can be held responsible for any damage (extraordinary, incidental, or consequential) resulting from the use of this product.
- Due to constant product improvements, the actual product appearance might differ from the shown images. Product images are for illustrative purposes only.
- DO NOT use this product to violate privacy laws or perform other illegal activities.
- Only use this product in an area legal for remote control flying and free of interfering radio signals.
- Do not switch the device on immediately after it has been exposed to changes in temperature. Protect the device against damage by leaving it switched off until it has reached room temperature.
- Keep this manual for future reference.


### Included:

- Quadcopter
- 4-channel digital proportional transmitter
- 3.7 V, 500 mAh lithium-polymer battery (for quadcopter)
- USB charging cable

## Introduction

To all residents of the European Union Important environmental information about this product



-  This symbol on the device or the package indicates that disposal of the device after its lifecycle could harm the environment. Do not dispose of the unit (or batteries) as unsorted municipal waste; it should be taken to a specialized company for recycling. This device should be returned to your distributor or to a local recycling service. Respect the local environmental rules.  
If in doubt, contact your local waste disposal authorities.
- Keep this device away from children under age 14 and unauthorized users.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children under age 14 shall be supervised to ensure that they do not play with the appliance.
- Keep this device away from rain, moisture, splashing and dripping liquids.
- DO NOT disassemble or open the cover. There are no user-serviceable parts inside the device. Refer to an authorized dealer for service and/or spare parts.
- **Warning:** Do not puncture batteries or throw them in fire as they may explode. Do not attempt to recharge non-rechargeable batteries (alkaline). Dispose of batteries in accordance with local regulations. Keep batteries away from children.


## General Guidelines

Refer to the Velleman® Service and Quality Warranty on the last pages of this manual.

- Keep this device away from dust and extreme temperatures.
- Protect this device from shocks and abuse. Avoid brute force when operating the device.
- Familiarize yourself with the functions of the device before actually using it.
- All modifications of the device are forbidden for safety reasons. Damage caused by user modifications to the device is not covered by the warranty.
- Only use the device for its intended purpose. Using the device in an unauthorised way will void the warranty.
- Damage caused by disregard of certain guidelines in this manual is not covered by the warranty and the dealer will not accept responsibility for any ensuing defects or problems.
- Nor Velleman nv nor its dealers can be held responsible for any damage (extraordinary, incidental or indirect) – of any nature (financial, physical...) arising from the possession, use or failure of this product.
- Due to constant product improvements, the actual product appearance might differ from the shown images. Product images are for illustrative purposes only.

- DO NOT use this product to violate privacy laws or perform other illegal activities.

Documents / Resources

	<p><a href="#">velleman RCQC3 Quadcopter With 720p Wi-fi Fpv Camera</a> [pdf] User Manual</p> <p>RCQC3 Quadcopter With 720p Wi-fi Fpv Camera, RCQC3, Quadcopter With 720p Wi-fi Fpv Camera, With 720p Wi-fi Fpv Camera, Fpv Camera</p>
---	--

References

-  [Velleman – Wholesaler and developer of electronics](#)