



velleman Suction Window Digital Thermometer Instructions

[Home](#) » [Velleman](#) » velleman Suction Window Digital Thermometer Instructions 

Contents

- [1 velleman Suction Window Digital Thermometer](#)
- [2 INSTALLATION INSTRUCTION](#)
- [3 Functions](#)
- [4 Battery Warning](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

velleman

velleman Suction Window Digital Thermometer




INSTALLATION INSTRUCTION

Thank you for purchasing our Suction Window Digital Thermometer. We hope you will be happy with your purchase

Functions

- Displays the precise temperature.
- Measures in Degrees °C and Degrees °F.
- **The Temperature range is from -50 to +70°C(-58-+1 58°F)**
- The Product uses 1 x LR1130 battery (included)




- The roof-shaped cap has been designed to fit tightly to ensure the product remains securely in place.

To open:


1. Grip main body of the thermometer with one hand
2. Using the other hand, grip both ends of the cap firmly and lift upwards

Please note: You may need to apply some pressure. It may be also useful to use a screwdriver to help open the roof cap



How to set time:

- To set the time, firstly you will have to press the MODE button then just after press the SET button.
- You will need to press the °C/ °F button until the correct time is displayed on the screen, you will have to select the correct hour first.
- To select the correct minute you will need to press the MODE button again after selecting the correct hour.
- You will need to press the MODE key again, to bring you back to the temperature display screen.
- The Suction Digital Thermometer will automatically clear the maximum temperature at 8: 00 am every day, and will automatically clear the minimum temperature on 20:00 pm every day.



Battery Warning

- Do not mix alkaline, standard (carbon-zinc) and rechargeable batteries (including hydride)
- Do not mix old and new batteries
- Exhausted batteries are to be removed
- The supply terminals are not to be short-circuited
- Only batteries of the same or equivalent type as recommended are to be used
- Batteries are to be inserted with the correct polarity

Battery Warning:

- The wheelie bin symbol indicates the product and batteries must not be disposed of in domestic waste as they can contain substances that are damaging to the environment.
- Please use designated collection points or recycling facilities when disposing of the item or batteries.
- Batteries should be removed from the product.
- Contact your local waste disposal agency or your retailer for further information
- **Product Code: G141307**
- **Made in China for S&S Enterprises Ltd. 26 Perivale Park Middlesex UB6 7RL**

Documents / Resources

	<p>Velleman Suction Window Digital Thermometer [pdf] Instructions</p> <p>Suction Window Digital Thermometer, Digital Thermometer, Suction Window Thermometer, Thermometer</p>
--	---