

velleman VMM005 Power Module Shield User Manual

[Home](#) » [Velleman](#) » velleman VMM005 Power Module Shield User Manual 

Contents

- [1 velleman VMM005 Power Module Shield](#)
- [2 Introduction](#)
- [3 Safety Instructions](#)
- [4 General Guidelines](#)
- [5 What is micro:bit](#)
- [6 Description](#)
- [7 Layout](#)
- [8 Pin Assignment](#)
- [9 Assembly](#)
- [10 Programming](#)
- [11 Technical Specifications](#)
- [12 Velleman® Service and Quality Warranty](#)
- [13 Documents / Resources](#)
 - [13.1 References](#)
- [14 Related Posts](#)

velleman®

velleman VMM005 Power Module Shield



Introduction

To all residents of the European Union

Important environmental information about this product



This symbol on the device or the package indicates that disposal of the device after its lifecycle could harm the environment. Do not dispose of the unit (or batteries) as unsorted municipal waste; it should be taken to a specialized company for recycling. This device should be returned to your distributor or to a local recycling service. Respect the local environmental rules.

If in doubt, contact your local waste disposal authorities

Thank you for choosing Velleman®! Please read the manual thoroughly before bringing this device into service. If the device was damaged in transit, do not install or use it and contact your dealer.

Safety Instructions

This device can be used by children aged from 8 years and above, and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the device in a safe way and understand the hazards involved. Children shall not play with the device. Cleaning and user maintenance shall not be made by children without supervision.



Indoor use only.

Keep away from rain, moisture, splashing and dripping liquids.

General Guidelines

- Refer to the Velleman® Service and Quality Warranty on the last pages of this manual.
- Familiarise yourself with the functions of the device before actually using it.
- All modifications of the device are forbidden for safety reasons. Damage caused by user modifications to the device is not covered by the warranty.
- Only use the device for its intended purpose. Using the device in an unauthorised way will void the warranty.
- Damage caused by disregard of certain guidelines in this manual is not covered by the warranty and the dealer will not accept responsibility for any ensuing defects or problems.
- Nor Velleman nv nor its dealers can be held responsible for any damage (extraordinary, incidental or indirect) – of any nature (financial, physical...) arising from the possession, use or failure of this product.
- Due to constant product improvements, the actual product appearance might differ from the shown images.
- Product images are for illustrative purposes only.
- Do not switch the device on immediately after it has been exposed to changes in temperature. Protect the device against damage by leaving it switched off until it has reached room temperature.
- Keep this manual for future reference.

What is micro:bit

The BBC micro:bit is a pocket-sized (52 x 42 mm – 2" x 1.75") computer, 70 times smaller and 18 times faster than the original BBC micro computers used in schools. The design is appealing to a young public. It features micro:bit is compatible with different coding languages starting from Block Editor and mobile apps for the starters, to Python for more advanced users.


micro:bit has an accelerometer so it can detect motion and knows when you are on the move. The built-in compass knows which direction you are heading in and it uses a low-energy wireless connection to interact with other devices and the Internet.

Each element is completely programmable via easy-to-use software on a dedicated website (microbit.org) accessible from a PC, tablet or mobile.

Description


This power module is an extension board for micro:bit. It is powered by two CR2025 batteries. An additional buzzer can be used as output connection for the micro:bit.

Layout



1. mounting hole
2. coin cell battery
3. pad connection
4. buzzer
5. external pin header
6. coin cell battery
7. power switch

Pin Assignment




Assembly


Push the countersunk screws through pins 0 and GND.



Line up the Power:bit board with the screws. The back of the Power:bit must face the back of the micro:bit.




Screw the Power:bit and micro:bit boards together. Do the same for pins 1, 2 and 3V.



Place the batteries into their battery holder. Switch on the board.


Programming

Create a demo code to test the Power:bit, the micro:bit and the buzzer. Go to www.makecode.com and click the micro:bit button.




Place the blocks as below:

Drag and drop the [show icon] block in the [on start] block. They will snap together when correct. Select the [happy] icon. Now, drag and drop the [show string] block under the [show icon] block. They will also snap together. Type the text [Lets play a melody, please shake!].



Make a second block. Drag and drop the [on shake] block under the [on start] block. Drag and drop the [show icon] block in the [on shake] block and set the icon to [Yes]. Drag and drop the [start melody – ode – repeating – one] block under the [show icon] block. Set the melody on [ode]. Drag and drop the last [show icon] block under the [start melody] block and set the icon to [Surprised].



When done, click on the [download] button and save the .hex file to the downloads folder C:\downloads. This .hex file is ready to upload to the micro:bit.

Plug the micro:bit into a USB port. Now, drag and drop the .hex file onto the micro:bit [removable device] to upload the programme. When the yellow LED on the micro:bit stops blinking, the programme is uploaded.

Remove the USB cable and power up the Power:bit (set the switch in the on position).

Now, follow the instructions on the micro:bit.

Technical Specifications

- **operating voltage:** 2.7 V – 3.3 V
- **battery:** CR2025
- **dimensions:** 42 x 52 x 5 mm

Use this device with original accessories only. Velleman nv cannot be held responsible in the event of damage or injury resulting from (incorrect) use of this device. For more info concerning this product and the latest version of this manual, please visit our website www.velleman.eu. The information in this manual is subject to change without prior notice.

© COPYRIGHT NOTICE

The copyright to this manual is owned by Velleman nv. All worldwide rights reserved. No part of this manual may be copied, reproduced, translated or reduced to any electronic medium or otherwise without the prior written consent of the copyright holder.

Velleman® Service and Quality Warranty

Since its foundation in 1972, Velleman® acquired extensive experience in the electronics world and currently distributes its products in over 85 countries.

All our products fulfil strict quality requirements and legal stipulations in the EU. In order to ensure the quality, our products regularly go through an extra quality check, both by an internal quality department and by specialized external organisations. If, all precautionary measures notwithstanding, problems should occur, please make appeal to our warranty (see guarantee conditions).

General Warranty Conditions Concerning Consumer Products (for EU):

- All consumer products are subject to a 24-month warranty on production flaws and defective material as from the original date of purchase.
- Velleman® can decide to replace an article with an equivalent article, or to refund the retail value totally or partially when the complaint is valid and a free repair or replacement of the article is impossible, or if the expenses are out of proportion. You will be delivered a replacing article or a refund at the value of 100% of the purchase price in case of a flaw occurred in the first year after the date of purchase and delivery, or a replacing article at 50% of the purchase price or a refund at the value of 50% of the retail value in case of a flaw occurred in the second year after the date of purchase and delivery.
- **Not covered by warranty:**
 - all direct or indirect damage caused after delivery to the article (e.g. by oxidation, shocks, falls, dust, dirt, humidity...), and by the article, as well as its contents (e.g. data loss), compensation for loss of profits;
 - consumable goods, parts or accessories that are subject to an aging process during normal use, such as batteries (rechargeable, non-rechargeable, built-in or replaceable), lamps, rubber parts, drive belts... (unlimited list);
 - flaws resulting from fire, water damage, lightning, accident, natural disaster, etc....;
 - flaws caused deliberately, negligently or resulting from improper handling, negligent maintenance, abusive use or use contrary to the manufacturer's instructions;
 - damage caused by a commercial, professional or collective use of the article (the warranty validity will be reduced to six (6) months when the article is used professionally);
 - damage resulting from an inappropriate packing and shipping of the article;
 - all damage caused by modification, repair or alteration performed by a third party without written permission by Velleman®.
- Articles to be repaired must be delivered to your Velleman® dealer, solidly packed (preferably in the original

packaging), and be completed with the original receipt of purchase and a clear flaw description.


- **Hint:** In order to save on cost and time, please reread the manual and check if the flaw is caused by obvious causes prior to presenting the article for repair. Note that returning a non-defective article can also involve handling costs.
- Repairs occurring after warranty expiration are subject to shipping costs.
- The above conditions are without prejudice to all commercial warranties. The above enumeration is subject to modification according to the article (see article's manual).

Made in PRC





Imported by Velleman nv

Legen Heirweg 33, 9890 Gavere, Belgium www.velleman.eu

Documents / Resources

 <p>The image shows the Velleman VMM005 Power Module Shield, a small electronic board with various components and a USB port. The Velleman logo is visible at the top left of the board.</p>	<p>velleman VMM005 Power Module Shield [pdf] User Manual</p> <p>VMM005 Power Module Shield, Power Module Shield, VMM005 Module Shield, Module Shield, Shield, VMM005</p>
---	--

References

-  [Micro:bit Educational Foundation | micro:bit](#)
-  [Page moved](#)
-  [Page moved](#)
-  [Velleman – Wholesaler and developer of electronics](#)