



## velleman VTLAMP9 Magnifying Lamp Table Clamp User Manual

[Home](#) » [Velleman](#) » velleman VTLAMP9 Magnifying Lamp Table Clamp User Manual 

# velleman®

VTLLAMP9  
MAGNIFYING LAMP  
3 DIOPTRIC GLASS LENSES

### Contents

- [1 VTLAMP9 Magnifying Lamp Table Clamp](#)
- [2 Introduction](#)
- [3 Safety Instructions](#)
- [4 General Guidelines](#)
- [5 Features](#)
- [6 Use](#)
- [7 Replacing the lamp](#)
- [8 Maintenance](#)
- [9 Technical specifications](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)

**VTLAMP9 Magnifying Lamp Table Clamp**



USER MANUAL



VTLAMP9	
	<b>1</b> clamp <b>1a</b> nut <b>1b</b> jaw <b>1c</b> base
	<b>2</b> magnifying lens
	<b>1</b> klem <b>1a</b> moer <b>1b</b> kaken <b>1c</b> voet
	<b>2</b> vergrootglas
	<b>1</b> pince <b>1a</b> écrou <b>1b</b> mâchoires <b>1c</b> pied
	<b>2</b> loupe
	<b>1</b> pinza <b>1a</b> tuerca <b>1b</b> mordazas <b>1c</b> pie
	<b>2</b> lupa
	<b>1</b> Klemme <b>1a</b> Mutter <b>1b</b> Backen <b>1c</b> Fuß
	<b>2</b> Lupe

USER MANUAL

## Introduction

To all residents of the European Union  
 Important environmental information about this product



This symbol on the device or the package indicates that disposal of the device after its lifecycle could harm the environment. Do not dispose of the unit (or batteries) as unsorted municipal waste; it should be taken to a specialized company for recycling. This device should be returned to your distributor or to a local recycling service. Respect the local environmental rules. If in doubt, contact your local waste disposal authorities. Thank you for choosing Velleman! Please read the manual thoroughly before bringing this device into service. If the device was damaged in transit, don't install or use it and contact your dealer.

## Safety Instructions

	Keep the device away from children and unauthorised users.
	Never leave the magnifying lens unattended where direct sunlight may pass through.
	Indoor use only. Keep this device away from rain, moisture, splashing and dripping.
	Always disconnect mains power when the device is not in use or when servicing only.
	There are no user-serviceable parts inside the device. Refer to an authorized dealer.

## General Guidelines

Refer to the Velleman® Service and Quality Warranty on the last pages of this manual.

	Keep this device away from dust and extreme heat.
	Protect this device from shocks and abuse. Avoid brute force when operating the device.

- Familiarise yourself with the functions of the device before actually using it.
- All modifications of the device are forbidden for safety reasons. Damage caused by user modifications to the device is not covered by the warranty.
- Only use the device for its intended purpose. Using the device in an unauthorised way will void the warranty.
- Damage caused by disregard of certain guidelines in this manual is not covered by the warranty and the dealer will not accept responsibility for any ensuing defects or problems.

## Features

- lamp (optional): LAE1B3A, LAE1C3A, LAE1C3H, LAE1D3A, LAE1F3H
- optional: stand with wheels (white) – VTLAMPST, table stand (white) – VTLAMPST1

## Use

Refer to the illustration on page 2 of this manual.

- Open the table clamp [1] by twisting the nut [1a] counter clockwise.
  - Place the base [1c] on a suitable and solid horizontal or vertical surface capable of carrying the weight of the lamp. Do not attach to round objects e.g. tubes.
  - Twist the nut [1a] clockwise until the jaw [1b] clasps the base [1c] securely to the surface.
  - Slide the stem of the lamp into the hole on top of the clamp.
- Note:** the stem must always be vertical in such a way that the weight of the lamp is resting on the clamp [1].
- Screw a suitable lamp (not incl., E27, max. 60W) into the lamp socket.
  - Plug the power cable into a suitable mains outlet.
  - Switch on the lamp with the On/Off button on the power cable.
  - Be extremely cautious when sunlight passes through the magnifying lens – the heat will be focussed in one point creating a fire hazard.

## Replacing the lamp

- Unplug the device from the mains and let the lamp cool down before replacing it.
- Unscrew the light bulb from the socket and replace it with a new one.
- Make sure the switch is in the off-position and plug the power plug into the mains.

## Maintenance

- Unplug the device from the mains and let the lamp cool down before maintenance.
- Wipe the device with a moist soft cloth. Do not use abrasive solutions or solvents.

## Technical specifications

power supply	230Vac / 50~60Hz
lamp	E27, max. 60W
magnifier	3 dioptré
weight	±1100g

Use this device with original accessories only. Velleman nv cannot be held responsible in the event of damage or injury resulted from (incorrect) use of this device. For more info concerning this product and the latest version of this user manual, please visit our website [www.velleman.eu](http://www.velleman.eu). The information in this manual is subject to change without prior notice.

### © COPYRIGHT NOTICE

This manual is copyrighted. The copyright to this manual is owned by Velleman nv. All worldwide rights reserved. No part of this manual may be copied, reproduced, translated or reduced to any electronic medium or otherwise without the prior written consent of the copyright holder.

## **Velleman® Service and Quality Warranty**

Velleman® has over 35 years of experience in the electronics world and distributes its products in more than 85 countries.

All our products fulfil strict quality requirements and legal stipulations in the EU. In order to ensure the quality, our products regularly go through an extra quality check, both by an internal quality department and by specialized external organisations. If, all


precautionary measures notwithstanding, problems should occur, please make appeal to our warranty (see guarantee conditions).

### **General Warranty Conditions Concerning Consumer Products (for EU):**

- All consumer products are subject to a 24-month warranty on production flaws and defective material as from the original date of purchase.
- Velleman® can decide to replace an article with an equivalent article, or to refund the retail value totally or partially when the complaint is valid and a free repair or replacement of the article is impossible, or if the expenses are out of proportion. You will be delivered a replacing article or a refund at the value of 100% of the purchase price in case of a flaw occurred in the first year after the date of purchase and delivery, or a replacing article at 50% of the purchase price or a refund at the value of 50% of the retail value in case of a flaw occurred in the second year after the date of purchase and delivery.
- Not covered by warranty:
  - all direct or indirect damage caused after delivery to the article (e.g. by oxidation, shocks, falls, dust, dirt, humidity...), and by the article, as well as its contents (e.g. data loss), compensation for loss of profits;
  - frequently replaced consumable goods, parts or accessories such as batteries, lamps, rubber parts, drive belts... (unlimited list);
  - flaws resulting from fire, water damage, lightning, accident, natural disaster, etc. ...;
  - flaws caused deliberately, negligently or resulting from improper handling, negligent maintenance, abusive use or use contrary to the manufacturer's instructions;
  - damage caused by a commercial, professional or collective use of the article (the warranty validity will be reduced to six (6) months when the article is used professionally);
  - damage resulting from an inappropriate packing and shipping of the article;
  - all damage caused by modification, repair or alteration performed by a third party without written permission by Velleman®.
- Articles to be repaired must be delivered to your Velleman® dealer, solidly packed (preferably in the original packaging), and be completed with the original receipt of purchase and a clear flaw description.
- Hint: In order to save on cost and time, please reread the manual and check if the flaw is caused by obvious causes prior to presenting the article for repair. Note that returning a non-defective article can also involve handling costs.
- Repairs occurring after warranty expiration are subject to shipping costs.
- The above conditions are without prejudice to all commercial warranties.

The above enumeration is subject to modification according to the article (see article's manual).

The logo for Velleman, featuring the word "velleman" in a stylized, outlined font. The letters are interconnected, with the 'v' and 'e' being particularly prominent. A registered trademark symbol (®) is located at the top right of the 'n'.

	<p><a href="#">velleman VTLAMP9 Magnifying Lamp Table Clamp</a> [pdf] User Manual VTLAMP9 Magnifying Lamp Table Clamp, VTLAMP9, Magnifying Lamp Table Clamp, Lamp Table Clamp, Table Clamp, Clamp</p>
---	---

References

-  [Velleman – Wholesaler and developer of electronics](#)