



# VELOCIFIRE M87 Mac Layout Mechanical Keyboard User Manual

[Home](#) » [VELOCIFIRE](#) » VELOCIFIRE M87 Mac Layout Mechanical Keyboard User Manual

## Contents [ [hide](#) ]

- [1 VELOCIFIRE M87 Mac Layout Mechanical Keyboard](#)
- [2 Specification](#)
- [3 Features](#)
- [4 Installation, Connection and Use](#)
- [5 Charge the keyboard](#)
- [6 Troubleshooting Tips](#)
- [7 FCC Warning:](#)
- [8 Documents / Resources](#)
- [9 Related Posts](#)



## VELOCIFIRE M87 Mac Layout Mechanical Keyboard



## Specification

1. Polling Rate:1000Hz
2. Flash ROM: 64KB
3. Voltage: VDD = 3.0V – 5.5V
4. Temperature: – 40°C – + 85°C
5. Package form: LQFP64

## RGB Backlit Modes

- **FN+Scroll:** Adjust 19 LED-backlit modes
- **FN+Pause:** Adjust lighting color,9 levels
- **FN+↑:** Increase brightness
- **FN+↓:** Decrease brightness
- **FN+→:** Increase speed
- **FN+←:** Decrease speed

## Gaming Interaction Mode

FN+DEL:

- **First mode:** FPS–WASD R←→↑↓ESC blocks light up
- **Second mode:** COD–QWERTASDFGCV1-7 Ctrl Shift blocks light up
- **Third mode:** Car–WASDR Ctrl Shift Alt ←→↑↓ blocks light up
- **Fourth mode:** LOL–QWER DGFBVCtrl Alt Tab~1-6 Es blocks light up

**Note:** The lighting of the 4 preset game modes can be recorded.

### Recording steps

Set the individual keys first, then adjust to the color (red,orange yellow, green, blue, purple,white, pink).

After entering any game mode, press FN+HOME to start recording, the key has no output function at this time, the indicator light flashes, click the key to be recorded, adjust the light color. To finish recording, press FN+HOME to finish recording

### Multimedia Function

- FN+F1:Home
- FN+F2:MyComputer
- FN+F3:Mail
- FN+F4:Music
- FN+F5:Previous Playlist
- FN+F6:Next Playlist
- FN+F7:Play/Pause
- FN+F8:Stop
- FN+F9:Mute
- FN+F10:Volume down
- FN+F11:Volume up
- FN+F12:Lock/Unlock the keyboard
- FN+Esc:Hold for 3 seconds to restore factory settings
- FN+WIN:WIN lock/unlock
- FN+W:WSADis interchanged with ↑↓←→click

- FN+W again to restore to normal

## Package Contents

- 1xMechanical Rechargeable Keyboard
- 1xUSB Nano Receiver
- 1xType-CCable
- 1xUser Manual
- 1xKeycap Puller
- 1xSwitch Puller

## Features

1. Mechanical M87 keyboard
2. 2.4G Wireless+ Wired dual modes
3. Rechargeable battery:4000mA
4. RGB backlit, 19 kinds of lighting modes
5. USB Full Speed 2.0(12Mbps)
6. N-key rollover

## Installation, Connection and Use

### 1. Wired mode

Toggle the switch to the left (the color card shows red) for wired mode Connect the USB charging cable to your computer.

### 2. 2.4G Wireless mode

Charge the battery. Toggle the switch to the right (the color card shows green) for wireless mode. Plug the USB nano receiver into the USB port of your computer.

Once the computer recognizes the keyboard, you're ready to use. In 2.4G Wireless mode, If not use for more than 60 seconds, the RGB backlit will turn off automatically and the keyboard enters power-saving mode.It is better to turn off the keyboard when not used for a long time.

### Build the connection between the USB receiver and keyboard

Toggle the power switch to the right (the color card shows green), press FN+P for 5 seconds, and now the key"P" is flashing. Plug the USB nano receiver into the USB port of your computer. Key"P" stop flashing after building the connection successfully.

## Charge the keyboard

The battery should be charged for at least 6~8 hours before being used for the first time. When the battery is low, the FN keyed light flashes.Connect the USB charging cable to your computer or adapter.The charging indicator is located on the left side of the space bar, the charging status lights up, and it turns off when fully charged.(charging time: around 6~8 hours).

**NOTE:** If you want to use the keyboard when charging, you should choose Wired mode,the power switch must be toggled to the right position.

Troubleshooting Tips

If you experience problems while using the keyboard, here are some helpful troubleshooting tips: Check the power switch is on the right and Check the battery is charged. Check the receiver is properly connected to the USB port. Try reducing the distance between the keyboard and the computer . Remove any large metal objects located between the keyboard and the computer that could interrupt the signal. Product pictures are for reference only.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

**Caution:** Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable exposure conditions without restriction.

Documents / Resources

PDF FILES

1. M87 Mac Layout Mechanical Keyboard

2. M87 Mac Layout Mechanical Keyboard

3. M87 Mac Layout Mechanical Keyboard

4. M87 Mac Layout Mechanical Keyboard

5. M87 Mac Layout Mechanical Keyboard

6. M87 Mac Layout Mechanical Keyboard

7. M87 Mac Layout Mechanical Keyboard

8. M87 Mac Layout Mechanical Keyboard

9. M87 Mac Layout Mechanical Keyboard

10. M87 Mac Layout Mechanical Keyboard

11. M87 Mac Layout Mechanical Keyboard

12. M87 Mac Layout Mechanical Keyboard

13. M87 Mac Layout Mechanical Keyboard

14. M87 Mac Layout Mechanical Keyboard

15. M87 Mac Layout Mechanical Keyboard

16. M87 Mac Layout Mechanical Keyboard

17. M87 Mac Layout Mechanical Keyboard

18. M87 Mac Layout Mechanical Keyboard

19. M87 Mac Layout Mechanical Keyboard

20. M87 Mac Layout Mechanical Keyboard

21. M87 Mac Layout Mechanical Keyboard

22. M87 Mac Layout Mechanical Keyboard

23. M87 Mac Layout Mechanical Keyboard

24. M87 Mac Layout Mechanical Keyboard

25. M87 Mac Layout Mechanical Keyboard

26. M87 Mac Layout Mechanical Keyboard

27. M87 Mac Layout Mechanical Keyboard

28. M87 Mac Layout Mechanical Keyboard

29. M87 Mac Layout Mechanical Keyboard

30. M87 Mac Layout Mechanical Keyboard

31. M87 Mac Layout Mechanical Keyboard

32. M87 Mac Layout Mechanical Keyboard

33. M87 Mac Layout Mechanical Keyboard

34. M87 Mac Layout Mechanical Keyboard

35. M87 Mac Layout Mechanical Keyboard

36. M87 Mac Layout Mechanical Keyboard

37. M87 Mac Layout Mechanical Keyboard

38. M87 Mac Layout Mechanical Keyboard

39. M87 Mac Layout Mechanical Keyboard

40. M87 Mac Layout Mechanical Keyboard

41. M87 Mac Layout Mechanical Keyboard

42. M87 Mac Layout Mechanical Keyboard

43. M87 Mac Layout Mechanical Keyboard

44. M87 Mac Layout Mechanical Keyboard

45. M87 Mac Layout Mechanical Keyboard

46. M87 Mac Layout Mechanical Keyboard

47. M87 Mac Layout Mechanical Keyboard

48. M87 Mac Layout Mechanical Keyboard

49. M87 Mac Layout Mechanical Keyboard

50. M87 Mac Layout Mechanical Keyboard

51. M87 Mac Layout Mechanical Keyboard

52. M87 Mac Layout Mechanical Keyboard

53. M87 Mac Layout Mechanical Keyboard

54. M87 Mac Layout Mechanical Keyboard

55. M87 Mac Layout Mechanical Keyboard

56. M87 Mac Layout Mechanical Keyboard

57. M87 Mac Layout Mechanical Keyboard

58. M87 Mac Layout Mechanical Keyboard

59. M87 Mac Layout Mechanical Keyboard

60. M87 Mac Layout Mechanical Keyboard

61. M87 Mac Layout Mechanical Keyboard

62. M87 Mac Layout Mechanical Keyboard

63. M87 Mac Layout Mechanical Keyboard

64. M87 Mac Layout Mechanical Keyboard

65. M87 Mac Layout Mechanical Keyboard

66. M87 Mac Layout Mechanical Keyboard

67. M87 Mac Layout Mechanical Keyboard

68. M87 Mac Layout Mechanical Keyboard

69. M87 Mac Layout Mechanical Keyboard

70. M87 Mac Layout Mechanical Keyboard

71. M87 Mac Layout Mechanical Keyboard

72. M87 Mac Layout Mechanical Keyboard

73. M87 Mac Layout Mechanical Keyboard

74. M87 Mac Layout Mechanical Keyboard

75. M87 Mac Layout Mechanical Keyboard

76. M87 Mac Layout Mechanical Keyboard

77. M87 Mac Layout Mechanical Keyboard

78. M87 Mac Layout Mechanical Keyboard

79. M87 Mac Layout Mechanical Keyboard

80. M87 Mac Layout Mechanical Keyboard

81. M87 Mac Layout Mechanical Keyboard

82. M87 Mac Layout Mechanical Keyboard

83. M87 Mac Layout Mechanical Keyboard

84. M87 Mac Layout Mechanical Keyboard

85. M87 Mac Layout Mechanical Keyboard

86. M87 Mac Layout Mechanical Keyboard

87. M87 Mac Layout Mechanical Keyboard

88. M87 Mac Layout Mechanical Keyboard

89. M87 Mac Layout Mechanical Keyboard

90. M87 Mac Layout Mechanical Keyboard

91. M87 Mac Layout Mechanical Keyboard

92. M87 Mac Layout Mechanical Keyboard

93. M87 Mac Layout Mechanical Keyboard

94. M87 Mac Layout Mechanical Keyboard

95. M87 Mac Layout Mechanical Keyboard

96. M87 Mac Layout Mechanical Keyboard

97. M87 Mac Layout Mechanical Keyboard

98. M87 Mac Layout Mechanical Keyboard

99. M87 Mac Layout Mechanical Keyboard

100. M87 Mac Layout Mechanical Keyboard

VELOCIFIRE M87 Mac Layout Mechanical Keyboard [pdf] User Manual

M87, 2A5ZZ-M87, 2A5ZZM87, M87 Mac Layout Mechanical Keyboard, Mac Layout Mechanical Keyboard