

VENEUX B0CBBNKT2 Wireless Styling Brush



VENEUX B0CBBNKT2 Wireless Styling Brush Instruction Manual

[Home](#) » [VENEUX](#) » VENEUX B0CBBNKT2 Wireless Styling Brush Instruction Manual 

Contents

- [1 VENEUX B0CBBNKT2 Wireless Styling Brush](#)
- [2 Product Usage Instructions](#)
- [3 Package Contents](#)
- [4 Technical Specifications](#)
- [5 First Use and Charging](#)
- [6 FEATURES AND BENEFITS](#)
- [7 INSTRUCTIONS FOR USE](#)
- [8 Choosing the Proper Temperature](#)
- [9 Maintenance and Cleaning](#)
- [10 FAQ](#)
- [11 Warranty and Service](#)
- [12 Documents / Resources](#)
 - [12.1 References](#)
- [13 Related Posts](#)



VENEUX B0CBBNKT2 Wireless Styling Brush



Product Usage Instructions

To charge for the first use, connect the styling brush with the provided charging cable. Charge the styling brush fully, which will take approximately 3 to 4 hours. A blue indicator light will turn on when the styling brush is fully charged and ready for use.

- Ensure the battery is fully charged before first use.
- Press the unlock button on the side of the styling brush to unlock it for use.
- Press and hold the power button for 2 seconds to activate the styling brush. The LED lights will indicate that the device is heating up. Choose the desired temperature setting by pressing the power button until the preferred temperature lights up. Wait for the light to stop flashing, indicating that the styling brush has reached the set temperature.
- After styling, press and hold the power button for 2 seconds to turn off the styling brush. Allow the device to cool down completely before storing it. Lock the unlock button to keep the styling brush secure.
- Ensure the styling brush is turned off and completely cooled before cleaning. Wipe the brush with a lightly damp cloth. Avoid using harsh cleaning agents or submerging the device in water. Charge the styling brush as recommended to keep it ready for use.

Welcome to VENEUX® Congratulations on the purchase of your VENEUX® Cordless Ceramic Styling Brush. With the latest technology in hair styling, you have chosen a premium product designed for the modern woman who values style, convenience and quality. This manual will guide you step by step to ensure the best possible experience with your new style brush.

Package Contents


Check the contents of the package to ensure that you have received the following items:

- 1x VENEUX® Wireless Styling Brush
- 1x Charging cable
- 1x User Manual

If anything is missing, please contact our customer service department immediately for assistance.

Technical Specifications

- **Brand:** VENEUX®
- **Type:** Cordless Style Brush
- **Technology:** Advanced heat distribution with ion function
- **Battery life:** Up to 2 hours
- **Battery capacity:** 5400 mAh
- **Effective Working Time:** Up to 45 minutes
- **Suitable for:** All hair types
- **Heating element:** 3D Ceramic coated fins
- **Temperature range:** 120°C, 140°C, 160°C, 180°C, 200°C
- **Dimensions:** 20 x 4.5 x 4.5 cm



First Use and Charging

Charging for First Use

- Connect your style brush with the included charging cable.
- Fully charge the style brush, which will take about 3 to 4 hours.
- A blue indicator light will turn on when your style brush is fully charged and ready to use.

FEATURES AND BENEFITS

Features and Benefits Your new VENEUX® style brush combines several features and benefits that combine to

provide an unparalleled hair styling experience:



INSTRUCTIONS FOR USE

- Your VENEUX® styling brush is specially designed for your convenience and safety. Follow the steps below for an optimal styling experience:

Preparing for Use

- Make sure the battery is fully charged before using the style brush for the first time.
- Press the release button on the side of the style brush to unlock it and make it ready for use.

Activating the Style Brush


- Press and hold the power button for 2 seconds.
- The style brush will activate and the LED lights will illuminate to indicate that the device is heating up.
- The rapid heating system ensures that the style brush reaches the desired temperature quickly, so you can start styling immediately.

Choosing the Proper Temperature

- Your VENEUX® style brush has 5 temperature settings to meet all styling needs, regardless of your hair type.

The temperature options are 120°C, 140°C, 160°C, 180°C, and 200°C.

- For fine and delicate hair, start with the lowest temperature setting (120°C or 140°C).
- For normal hair, a medium temperature (160°C or 180°C) is often best.
- For thick or coarse hair, use the higher temperatures (180°C or 200°C).
- Select the temperature by briefly pressing the power button until the desired temperature setting lights up. Wait until the light stops flashing, indicating that the style brush has reached the set temperature.



Styling techniques

- Start with dry hair for best results.
- Take a section of your hair and place the style brush close to the roots.
- Slowly move the brush toward the ends so that the heat is evenly distributed throughout the hair.
- The unique 3D ceramic-coated fins protect your hair from heat and ensure even heat distribution.
- The integrated ion technology will emit negative ions during styling, providing a lint-free and shiny finish.
- Repeat this process section by section until you achieve the desired result.

Safety and Comfort

- The VENEUX® style brush is equipped with anti-burn brushes that protect your scalp while styling.
- The unit also has an automatic shut-off function that kicks in after 30 minutes of inactivity, for added safety and energy savings.

After Use

- After styling, press the power button for 2 seconds to turn off the style brush.

- Wait for the device to cool completely before storing it.
- Turn the release button back to “locked” to keep the style brush secure.

Maintenance and Cleaning

- Make sure the style brush is turned off and completely cooled before you begin cleaning.
- Wipe the brush clean with a slightly damp cloth. Do not use harsh detergents or ever immerse the device in water.
- Charge the style brush as recommended so that it is always ready to use.

Storage and Travel

- The compact size and lightweight design make your VENEUX® style brush the perfect travel companion.
- For extended periods of non-use, store the style brush in a cool, dry place and make sure it is fully charged.

Customer Service and Support

If you have any questions or problems with your VENEUX® style brush, please do not hesitate to contact our customer service team. We are ready to help you with any problem or question. You can reach us through the contact information provided in your user manual, or by visiting our support website, where you can find answers to frequently asked questions and get live chat support.

FAQ

How long does the style brush take to fully charge?

Fully charging the style brush takes about 3 to 4 hours. The blue indicator light shows when the device is ready to use.

Can I use the style brush while it is charging?

No, it is not recommended to use the style brush while it is charging to ensure safety and preserve battery life.

What should I do if my style brush does not heat up?

First, check that the style brush is properly charged and turned on. If the problem persists, contact customer service for further assistance.

How do I know which temperature setting to use?

Select the temperature setting based on your hair type. Use lower temperatures for fine or damaged hair and higher temperatures for thicker or coarser hair. Refer to the “Temperature Adjustments” section of this manual for detailed information.

Warranty and Service

- The VENEUX® style brush comes with a warranty that provides coverage against manufacturing defects and problems arising under normal conditions of use.
- Save your proof of purchase and contact our customer service department for information on warranty claims and terms of service.

Environment and Recycling

At VENEUX®, we are committed to the environment. At the end of the life of your style brush, do not throw it away with your household waste. Take it to a special collection point for electrical and electronic equipment. By doing so, you contribute to the conservation of natural resources and ensure the recycling of the product in an environmentally responsible manner.

IN CONCLUSION

Your VENEUX® Cordless Ceramic Style Brush gives you the freedom to style your hair anywhere with ease and comfort. Whether you need a quick touch-up before an appointment or preparing for a special occasion, your style brush is the ideal tool for a perfect hairstyle. With its ease of use, advanced technology, and elegant design, you are always just minutes away from the hair you desire. We hope you enjoy your new style brush and look forward to your feedback and stories of your styling adventures.



www.VENEUX.com.

Documents / Resources



[VENEUX B0CBBNKT2 Wireless Styling Brush](#) [pdf] Instruction Manual
B0CBBNKT2 Wireless Styling Brush, B0CBBNKT2, Wireless Styling Brush, Styling Brush, Brush

References

- [V Veneux Airstylers: Top Quality & Innovative Hair Styling](#)
- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.