



verizon E3200 Fios Extender and Router User Guide

[Home](#) » [Verizon](#) » verizon E3200 Fios Extender and Router User Guide 

Contents

- [1 verizon E3200 Fios Extender and Router](#)
- [2 Wired](#)
- [3 Troubleshooting](#)
- [4 SETUP DIAGRAM](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)



verizon E3200 Fios Extender and Router



Wired

- A. Connect the Verizon Router to a coax outlet. (If the coax outlet is already in use, use the coax splitter included in the box.)
 - B. Connect the Fios Extender to a coax outlet —ideally in an area with spotty Wi-Fi coverage.
 - C. Connect the power cords from the router and extender to an electrical outlet.
 - D. After 10 minutes, the light on the extender should turn solid white, indicating the connection is complete.
- Note:** If using Ethernet wiring, follow the same steps as above with an Ethernet cable instead of a coax cable.


Troubleshooting

- **Solid yellow** – no connection to the router
- Please check that both the Verizon Router and Fios Extender are using the same type of connection (coax or Ethernet.)


If you need technical support, visit support.verizon.com/wifiextender

- [Reset/Login Instructions](#)

SETUP DIAGRAM



Documents / Resources



[verizon E3200 Fios Extender and Router](#) [pdf] User Guide
E3200, Fios Extender and Router, E3200 Fios Extender and Router

References

- [Fios Network Extenders | Verizon Internet Support](#)