



Verkada Wireless Panic Button User Manual


[Home](#) » [Verkada](#) » Verkada Wireless Panic Button User Manual 

Contents

- [1 Verkada Wireless Panic Button](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Key Features](#)
- [5 Documents / Resources](#)

Verkada

Verkada Wireless Panic Button



Product Information

The Verkada Panic Button is a device designed to provide immediate help in situations that require immediate action, such as armed intruders, assault, or medical emergencies. It enables users to call for help while leveraging other Verkada devices to provide additional context about an incident.

Key Features:

- **Completely Customizable:** The panic button offers various activation options, including single, double, triple, or long-press, to reduce false alarms. Users can decide who will be notified and whether emergency services should be contacted directly.
- **Integrates with Verkada Ecosystem:** The panic button seamlessly integrates with the Verkada ecosystem. Users can easily find camera feeds associated with the panic button's location, initiate a door lockdown procedure, or trigger alarm responses such as sirens or strobe lights, all from the Command dashboard.
- **Monitor Device Status:** Users can have confidence that their devices are working as expected in case of an emergency. They will be notified if a panic button goes offline or reports a low battery.

Key Benefits:

- Ensures the safety of buildings, staff, and visitors
- Reduces costs and simplifies management

Product Usage Instructions

The Verkada Panic Button can be used in various ways depending on individual needs and preferences. Follow the instructions below to use the panic button effectively:

Wearable Usage:

If using the wireless panic button as a wearable device:

1. Attach the panic button to a lanyard.
2. Wear the lanyard around your neck for easy access.
3. In an emergency, press the panic button according to the desired activation option (single, double, triple, or long-press).
4. Emergency services and designated individuals will be notified based on your customization settings.

Mounted Usage:

If mounting the wireless panic button:

1. Choose a suitable location on a wall or under a desk.
2. Securely mount the panic button using the appropriate tools and fixtures.
3. In an emergency, press the panic button according to the desired activation option (single, double, triple, or long-press).
4. Emergency services and designated individuals will be notified based on your customization settings.

Digital Panic Button:

If using the digital panic button accessible from the Command dashboard:

1. Access the Command dashboard on a computer or mobile device.
2. Locate and click on the digital panic button.
3. In an emergency, click the panic button according to the desired activation option (single, double, triple, or long-press).
4. Emergency services and designated individuals will be notified based on your customization settings.

To ensure the proper functioning of your Verkada Panic Button, regularly check for device status notifications, including offline alerts or low battery reports. For further assistance or to request a free trial of our alarm system, including cameras, wireless sensors, and panic buttons with 24/7 professional monitoring and unlimited video verification, contact sales@verkada.com.

Address: Verkada Inc., 405 E 4th Ave, San Mateo, CA, 94401

Email: sales@verkada.com

Panic Button



Call for help, wherever you are

Whether it's an armed intruder, assault, or medical emergency, situations that require immediate action can crop up anytime, anywhere. Verkada's panic button enables you to immediately call for help while leveraging other Verkada devices to provide additional context about an incident.

Wireless panic buttons can be worn on a lanyard or mounted on a wall or under a desk. You also get access to a digital panic button, accessible from the Command dashboard on a computer or mobile device.

Key Features

Easy to Set Up

Wireless panic buttons pair automatically with the Verkada Wireless Alarm Hub. Easily set up and manage settings in the Command cloud dashboard, even on-the-go.

Completely Customizable

Choose from single, double, triple, or long-press to reduce false alarms. Decide who will be notified and whether emergency services should be contacted directly.

Key Benefits

- Customizable button triggers and responses
- Integrates with other Verkada devices for added security and visibility
- Built-in 24/7 professional monitoring with video verification
- LED indicator to signal a successful transmission
- Notifications if a button goes offline
- Up to 5-year battery life
- 10-year warranty on all hardware

Get Started

Verkada Alarms help ensure the safety of your buildings, staff, and visitors while reducing costs and simplifying management. To get started, contact sales@verkada.com to request a free trial of our alarm system, including cameras, wireless sensors, and panic buttons with 24/7 professional monitoring and unlimited video verification.

Integrates with Verkada Ecosystem

Easily find the camera feeds associated with a panic button's location, initiate a door lockdown procedure, or trigger alarm responses such as sirens or strobe lights, all from Command.

Monitor Device Status

Feel confident that your devices are working as expected in case of an emergency. Get notified if a panic button goes offline or reports a low battery.

Verkada Inc. 405 E 4th Ave, San Mateo, CA, 94401

sales@verkada.com

Documents / Resources

	<p>Verkada Wireless Panic Button [pdf] User Manual Wireless Panic Button, Panic Button, Button</p>
---	--