



VEVOR 0010 Larger Built in Floor and Mesh Screen Tent Station User Manual

[Home](#) » [VEVOR](#) » VEVOR 0010 Larger Built in Floor and Mesh Screen Tent Station User Manual 

Contents

- [1 VEVOR 0010 Larger Built-in Floor and Mesh Screen Tent Station](#)
- [2 Product Information](#)
- [3 FAQ](#)
- [4 SAFE INSTRUCTIONS](#)
- [5 PRODUCT INTRODUCTION](#)
- [6 OPERATION GUIDE](#)
- [7 TROUBLESHOOTING, MAINTENANCE, AND REPAIR](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)

VEVOR

VEVOR 0010 Larger Built-in Floor and Mesh Screen Tent Station



Product Information

Specifications

Model	Size	Material	Color	Ventilation Window Size	Pole Size
0010	90*62*62 in	Oxford-fabric 210D	White	60*40cm	8.5mm
0011	120*84*72 in	Oxford-fabric 210D	White	60*40cm	8.5mm

Package Content

The package includes:

- Portable Paint Booth
- Pole (2 pieces)
- Stake (4 pieces)
- Storage Bag
- Plastic Wrap
- User Manual

Product Diagram – Model 0010

No.	Item	Qty
1	Portable Paint Booth	1
2	Pole	2
3	Clip	16
4	Rope	2
5	Front Gauze Curtain	1
6	Foot Clasp	4
7	Ventilation Window	1

Product Diagram – Model 0011

No.	Item	Qty
1	Portable Paint Booth	1
2	Pole	2
3	Clip	16
4	Rope	2
5	Front Gauze Curtain	1
6	Foot Clasp	4
7	Ventilation Window	1

1. Storage Instructions

To store the tent

1. Take out the four corners of the stakes.
2. Untie the knot in two places.
3. Release clips (16pcs).
4. Take out all four corners of the poles, as shown in the picture.
5. Pull the two poles out of the tent.
6. Put the combination rod away as shown in the figure and put it into the storage bag.
7. Lay the tent flat and fold it as shown in the picture.
8. Roll the bagging poles and tent together and load into the large storage bag as shown in the picture.

Product Usage

For detailed instructions on how to use the product, please refer to the user manual provided with the package.

Troubleshooting, Maintenance, and Repair

If you encounter any issues with the product or require maintenance or repair, please refer to the user manual or contact our customer service at CustomerService@vevor.com.

FAQ

Q: Where can I find support and an e-warranty certificate

A: You can find support and e-warranty certificates at <https://www.vevor.com/support>.

CustomerService@vevor.com

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

SAFE INSTRUCTIONS

Warning:

- Spray paints and solvents can be dangerous if inhaled. Ensure you have good ventilation at all times
- Keep away from heat, sparks, and open flames when painting. Don't smoke.
- When painting, make sure to keep the ventilation.
- Paint is harmful to the body. Avoid contact with eyes and skin. Please take good

protection

- When painting, avoid prolonged exposure to the sun.
- When painting, lighting and electrical devices must be properly protected to avoid

accidents or personal injury.

- For best results, avoid painting in hot, humid weather.
- Recycle the used paint cans to avoid environmental damage.

CAUTION: Carefully read instructions and procedures for safe operations.

PRODUCT INTRODUCTION

Model SPEC.	0010	0011
Size	90*62*62 in	120*84*72 in
Material	Oxford-fabric 210D	Oxford-fabric 210D
Color	White	White
Ventilation window	60*40cm	60*40cm
Pole	φ8.5mm	φ8.5mm

PACKAGE CONTENT

Model		
Parts	0010	0011
Portable Paint Booth	×1	×1
Pole	×2	×2
Stake	×6	×6
Storage Bag	×1	×1
Plastic Wrap	×1	×1
User Manual	×1	×1

program diagram




No.	Item	Qty
1	Portable Paint Booth	1
2	Pole	2
3	Clip	16
4	Rope	2
5	Front Gauze Curtain	1
6	Foot Clasp	4
7	Ventilation Window	1



No.	Item	Qty
1	Portable Paint Booth	1
2	Pole	2
3	Clip	16
4	Rope	2
5	Front Gauze Curtain	1
6	Foot Clasp	4
7	Ventilation Window	1

INSTALLATION INSTRUCTION

- Unfold the tent and spread it out on a clean and level surface with the opening oriented towards the front
- Lay out two of the long poles and interlock all segments
- Insert poles through the tent sleeves, forming an "X" shape on the sides of the tent.



- Insert the four ends of the two poles into the bottom of the four corners of the tent, as shown in the picture
- Attach frame clips located in the tent section to the tent and clip them into place.
- Tie a bow on the side of the tent where the two poles form an "X".



- If you need to use the tent on grass, please fasten the tent with stakes at the bottom loops and corners.



Storage

- Take out the four corners of the stake
- Untie the knot in two places
- Release clips (16pcs)




- Take out all four corners of the poles, as shown in the picture
- Pull the two poles out of the tent.
- Put the combination rod away as shown in the figure and put it into the storage bag.

Lay the tent flat and fold it as shown in the picture.



Roll the bagging poles and tent together and load into the large storage bag as shown in the picture.



OPERATION GUIDE

- Assemble the portable paint booth.
- Roll up the front gauze curtain.
- Cover the bottom with the plastic wrap.
- The portable paint booth is ready for use.

Attention This product is not waterproof. Please do not use it outdoors in rainy days. For larger furniture, it is recommended to paint the front and top first and then dry the bottom and back. For Small furniture, it is recommended to configure a rotating tray, small furniture placed on the rotating tray spray paint.



TROUBLESHOOTING, MAINTENANCE, AND REPAIR


- To remove stains, clean with cold water and use mild remover if necessary. Do not use a strong stain remover to avoid damage to the fabric or local fading.
- Do not use a washing machine or dryer to clean the tent to avoid causing fabric damage.
- After cleaning, please spread the tent indoors or outdoors in a cool place to dry; Do not expose it to the sun to avoid damage to the fabric.
- Check the tent regularly to see if there is any damage. If there is any damage, please repair it in time. You can use a waterproof repair subsidy to repair the damaged parts.
- Check the pole after each use. If damaged, replace it in time.
- Please store the tent in a dry and cool place, away from direct sunlight and damp places.
- When the tent is stored, try to let it loose naturally, which can extend the service life of the tent, and put some desiccant to moisture-proof.

Manufacturer: Zhejiang Roy Industrial Co., Ltd
Add: No.8, Juhai Second Road, Qujiang District, Quzhou City, Zhejiang Province

Support and E-Warranty Certificate <https://www.vevor.com/support>

We continue to be committed to offering tools at competitive prices. “**Save Half**”, “**Half Price**”, or any other similar expressions used by us only represent an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and do not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when placing an order with us if you are saving half in comparison with the top major brands.

Documents / Resources

	VEVOR 0010 Larger Built in Floor and Mesh Screen Tent Station [pdf] User Manual 0010, 0011, 0010 Larger Built in Floor and Mesh Screen Tent Station, Larger Built in Floor and Mesh Screen Tent Station, Mesh Screen Tent Station, Screen Tent Station
--	---

References

-  [Contact Us – Official VEVOR Support](#)
- [User Manual](#)