





VEVOR XL3069 Impact Socket Set User Manual

Home » VEVOR » VEVOR XL3069 Impact Socket Set User Manual 🖫



Contents

- 1 VEVOR XL3069 Impact Socket
- 2 Specifications
- **3 Product Usage Instructions**
- **4 SAFETY INSTRUCTION**
- 5 Model list
- 6 Maintenance
- 7 FAQ
- 8 Documents / Resources

8.1 References



VEVOR XL3069 Impact Socket Set



Specifications

• Model: XL3069

• Type: Impact Socket Set

Socket List:

10: 3/8DR. Pneumatic sleeve: 10, 11, 12, 13, 14, 15, 17, 18, 19, 21mm
9: 3/8DR. Pneumatic sleeve: 1/4, 5/16, 3/8, 7/16, 1/2, 9/16, 5/8, 11/16, 3/4

Product Usage Instructions

Safety Instructions and Precautions

WARNING: Comply with safety operating procedures before use.

Select and Use

Refer to the model list provided in the manual to select the appropriate socket size for your task.

Maintenance

- 1. After using the socket, clean it promptly and apply lubricating oil to prolong its service life.
- 2. If the socket is not used for an extended period, store it in a dry and ventilated place to prevent rusting.
- 3. Regularly inspect the socket for wear and damage, replacing any damaged components promptly.

Technical Support and E-Warranty Certificate www.vevor.com/support

We continue to be committed to provide you tools with competitive price. "Save Half", "Half Price" or any other similar expressions used by us only represents an estimate of savings you might benefit from buying certain tools with us compared to the major top brands and does not necessarily mean to cover all categories of tools offered by us. You are kindly reminded to verify carefully when you are placing an order with us if you are actually saving half in comparison with the top major brands.



Photo for reference

NEED HELP? CONTACT US!

Have product questions? Need technical support? Please feel free to contact us: Technical Support and E-Warranty Certificate www.vevor.com/support

This is the original instruction, please read all manual instructions carefully before operating. VEVOR reserves a clear interpretation of our user manual. The appearance of the product shall be subject to the product you received. Please forgive us that we won't inform you again if there are any technology or software updates on our product.

SAFETY INSTRUCTION

PRECAUTIONS

WARNING:

- 1. Comply with safety operating procedures: Before use, thoroughly understand the usage methods and safety precautions of the tool to prevent accidents.
- 2. Regular inspection and maintenance: Regularly check the wear and tear of tools, replace damaged parts in a timely manner, and ensure stable tool performance.
- 3. Storage method: Place the tools in a dry, ventilated, and dark environment to avoid factors such as moisture, high temperature, and collision that may affect the tool's lifespan.
- 4. Classified storage: Classify and store various tools for easy and quick access during use

Select and Use

- 1. Choose a socket that is suitable for your own use. Different work purposes and working conditions require the selection of different sockets.
- 2. Choose standardized sockets as much as possible for easy replacement and maintenance.

- 3. Before using the socket, check whether the axis of the socket and the tool are consistent to ensure correct application.
- 4. When using the socket, it is important to follow the correct operating method and avoid excessive twisting to avoid damaging the tool.
- 5. When using a socket, an appropriate wrench should be used instead of other tools.
- 6. When using a socket, the correct torque and speed should be selected according to the work needs,


Model list

SN	Model	Qty	Туре	Socket List
				10: 3/8DR. Pneumatic sleeve: 10, 11, 12, 13, 14,
				15, 17, 18, 19, 21mm
				9: 3/8DR. Pneumatic sleeve: 1/4, 5/16, 3/8, 7/16,
				1/2, 9/16, 5/8, 11/16, 3/4"
				9: 3/8DR. Pneumatic long sleeve: 10, 11, 12, 13,
				14, 15, 17, 18, 19mm
				9: 3/8DR. Pneumatic long sleeve: 1/4, 5/16, 3/8,
				7/16, 1/2, 9/16, 5/8, 11/16, 3/4"
				14: 1/2DR. Pneumatic sleeve: 10, 11, 12, 13, 14,
			1/4"	15, 16, 17, 18, 19, 21, 22, 24, 27mm
1	XL3069	18	1/2" 3/8" Metri c/ SAE	13: 1/2DR. Pneumatic sleeve: 3/8, 7/16, 1/2, 9/16, 5/8, 11/16, 3/4, 13/16, 7/8, 15/16, 1,
				1-1/16, 1-3/16"
				16: 1/2DR. Pneumatic long sleeve: 10, 11, 12, 13,
				14, 15, 16, 17, 18, 19, 21, 22, 23, 24, 25, 27mm
				12: 1/2DR. Pneumatic long sleeve: 3/8, 7/16,
				1/2, 9/16, 5/8, 11/16, 3/4, 13/16, 7/8, 15/16, 1,
				1-1/16"
				7: 1/2DR E-shaped pneumatic sleeve: E12, E14,
				E16, E18, E20, E22, E24mm

21:1/2DR. Pneumatic screwdriver head sleeves: T40, T45, T47, T50, T55, T60, T70, H8, H10, H11, H12, H13, H14, H15, H3/8, H 7/16, H1/2, 9/16, 5/8, 11/16, H3/4"
5: Pneumatic conversion head: 3/8 "(F) * 1/4" (M), 3/8 "(F) * 1/2" (M), 1/2 "(F) * 3/8" (M), 3/4
"(F) * 1/2" (M), 1/2 "(F) * 3/4" (M)
3: 3/8DR pneumatic extension rod: 3 ", 6", 10"
2: 1/2DR pneumatic extension rod: 3 ", 5"

Maintenance

- 1. After using the socket, it should be cleaned in a timely manner and coated with an appropriate amount of lubricating oil to extend the service life of the socket.
- 2. After not using the socket for a long time, it should be placed in a dry and ventilated place to avoid rusting and affecting its use.
- 3. Regularly check the wear and damage of the socket, and replace damaged components in a timely manner.
- Address: Shuangchenglu 803nong11hao1602A-1609shi, baoshanqu, shanghai 200000 CN.
- Imported to AUS: SIHAO PTY LTD. 1 ROKEVA STREET, EASTWOOD NSW 2122 Australia
- Imported to USA: Sanven Technology Ltd. Suite 250, 9166 Anaheim Place, Rancho Cucamonga, CA 91730



Mainzer Landstr.69, 60329 Frankfurt am Main.



C/O YH Consulting Limited Office 147, Centurion House, London Road, Staines-upon-Thames, Surrey, TW18 4AX

Technical Support and E-Warranty Certificate www.vevor.com/support

FAQ


Q: Where can I find technical support for the product?

A: Contact Technical Support and E-Warranty Certificate at www.vevor.com/support for assistance.

Q: How should I select the right socket size for my task?

A: Refer to the model list in the user manual to choose the appropriate socket size based on your needs.

Documents / Resources



References

- O Contact Us Official VEVOR Support
- O Contact Us Official VEVOR Support
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.