



ViewSonic PD1213 Pen Display User Guide


[Home](#) » [Viewsonic](#) » ViewSonic PD1213 Pen Display User Guide 

Contents

- [1 ViewSonic PD1213 Pen Display](#)
- [2 Quick Start Guide](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)






ViewSonic PD1213 Pen Display






Quick Start Guide


Choose direction



2



ViewSonic Micro USB 2 in 1
Câble Micro USB 2 en 1 ViewSonic
Cable ViewSonic Micro-USB 2 en 1



Power Adapter
Adaptateur secteur
Adaptador de alimentación




Download Driver

<https://www.viewsonic.com/global/products/pendisplay/PD1213#downloads>



Install DisplayLink and PenDisplayDriver

For ViewSian Console, please visit: https://manuals.viewsonic.com/Pen_Display_Software

Set as extended display



Handwriting area mapping



ViewSonic Pen Display Website: www.viewsonic.com
 Customer service contact information: www.viewsonic.com

Documents / Resources

	ViewSonic PD1213 Pen Display [pdf] User Guide PD1213, PD1213 Pen Display, PD1213 Display, Pen Display, PD1213, Display
--	--

References

- [ViewSonic](#)
- [User Manual](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.